

VOLVO

Service Manual

Design

Function


Section 2

Engine B234F

740, 1988-19 . . .

TP 31304/2 09.88

ProCarManuals.com



Volvo Car Corporation

Contents


	Page
Important information	2
Specifications	4
Special tools	16
Group 20 General (belt tension gauge)	23
Group 21 Engine and mountings	26
Group 22 Lubrication system	211
Group 25 Intake and exhaust system	218
Group 26 Cooling system	235
Group 27 Engine management	246

See page 255 for Index

Part number: TP 31311/1

The right to introduce changes without prior notice is reserved.

Important information



Tightening torques

The torques specified in this manual are shown in one of two ways:


1. Values which **must** be applied with a torque wrench are indicated in bold print, thus: Tighten to **40 Nm** (29 ft.lb).
2. Recommended values which **need not** be applied with a torque wrench are shown in ordinary print, thus: Tighten to 40 Nm (29 ft.lb).



Ignition system

Warning! The ignition system operates at **high power**, with **dangerous** voltages in both the low-tension and high-tension circuits.


Dangerous voltage levels occur **in all parts of the ignition system**, including connectors and similar fittings.



Compression testing

Disconnect the lead from **terminal 1** on the ignition coil to prevent flashover to the electrical system wiring.

Disconnect the injector connectors to avoid flooding the engine, diluting the engine oil etc.



Battery


Do not disconnect the battery leads while the engine is running.

Disconnect the battery leads when boost charging.

Do not use a supply higher than **15 A/16 V** when jump starting the engine.

Radios with microprocessors


To avoid damage to the microprocessor, the **radio must be switched off** before disconnecting the battery earth lead.



Timing and balance shaft belts

It is essential that the timing and camshaft belts be tensioned **exactly** to the values stated in the specifications. (See page 11.)

Belt tension gauge **998 8500** must be used for this purpose.




Liquid sealing compound

The joint between the camshaft carrier and cylinder head on the B 204 E and B 234 F engines is sealed with a liquid sealing compound (liquid gasket).


It is essential that the joint faces be **thoroughly cleaned** and that all traces of oil be removed before applying the compound.

The compound is applied with a short-haired roller.



Suspended engine

Caution! Before carrying out work on a suspended engine, ensure that the lifting equipment is **securely attached** and is in **perfect condition**.



Coolant

Genuine Volvo coolant diluted with **clean** water in proportions of **50/50** is the only coolant which can be guaranteed by Volvo. This mixture prevents corrosion and freezing damage.


Type C coolant (blue-green) must not be mixed with any other type.

The coolant must be changed **every second year** to ensure continued protection against corrosion.

Use only **type C** coolant as a replacement.

Specifications

Group 20 General



141 057

PLATES AND LABELS

Product plate

Located over right-hand headlamp.

Information includes identification number (type designation).

Identification plate (type designation)

Scandinavia: Located on upper rear member in boot.

USA, Canada: Located at top left of instrument panel.

Other markets: No plate.

USA/Canada

⊕ Y V 1 D X 89 4 X K1 000000 ⊕

Other

⊕ Y V 1 7 0 4 29 2 K1 001234 ⊕

↑
Engine type

↑
Model year designation

↑
Chassis number 146 588

Key to identification number (type designation)

Engine type


29 = B 204 E

89 = B 234 F

Model year designation

J = 1988

K = 1989




146 589

Engine serial and part numbers

Punched on left-hand side of cylinder block.

The transmission (timing) cover also carries a label specifying the engine type, part number and serial number.

Group 21 Engine



129 826


CYLINDER HEAD

Max. distortion

Max. distortion without machining:
 Longitudinal **0.50 mm** (0.02 in)
 Lateral **0.25 mm** (0.01 in)

The cylinder head must be replaced if the distortion exceeds **1.0 mm** (0.04 in) along the length or **0.50 mm** (0.02 in) across the width.

Height of cylinder head
 as new **103.50±0.5 mm** (4.07±0.04 in)
 Minimum height after
 machining **102.5 mm** (4.035 in)



130 346

CYLINDER BLOCK

Bores

Standard	B 204	B 234
Bore marked C.....	88.90 mm (3.5000 in)	96.00 mm (3.7795 in)
Bore marked D.....	88.91 mm (3.5004 in)	96.01 mm (3.7799 in)
Bore marked E.....	88.92 mm (3.5008 in)	96.02 mm (3.7803 in)
Bore marked G.....	88.94 mm (3.5016 in)	96.04 mm (3.7811 in)


Oversize

Oversize 1	89.29 mm (3.5154 in)	96.30 mm (3.7913 in)
Oversize 2	89.67 mm (3.5303 in)	96.60 mm (3.8031 in)

CRANKSHAFT ASSEMBLY

Crankshaft journals

Max. out-of-round **0.01 mm** (0.0003 in)
 Max. taper **0.01 mm** (0.0003 in)
 Diameter, standard **49.00 mm** (1.9646 in)
 undersize 1 **48.75 mm** (1.9193 in)
 undersize 2 **45.50 mm** (1.7913 in)
 Bearing seat width. **25.00±1.1 mm** (0.9834±0.0433 in)




129 452

PISTONS

Piston diameter

Engine type	Dimensions, mm (in)		
	A	B	C
B 204	67.1 (2.64)	39.1 (1.54)	13.4 (0.53)
B 234	68.7 (2.70)	39.9 (1.57)	11.0 (0.43)



137 551

- A = Total height of piston
 B = Height from gudgeon pin centre to crown
 C = Piston diameter to be measured at right-angles to gudgeon pin hole, at distance C from edge of skirt
 D = Piston diameter

Piston diameter (D)

Standard	B 204	B 234
Pistons marked C.....	88.88 mm $^{+0.01}_0$ (3.4992 in $^{+0.0004}_0$)	95.98 mm $^{+0.01}_0$ (3.7787 in $^{+0.0004}_0$)
Pistons marked D.....	88.89 mm $^{+0.01}_0$ (3.4996 in $^{+0.0004}_0$)	95.99 mm $^{+0.01}_0$ (3.7791 in $^{+0.0004}_0$)
Pistons marked E.....	88.90 mm $^{+0.01}_0$ (3.5000 in $^{+0.0004}_0$)	96.00 mm $^{+0.01}_0$ (3.7795 in $^{+0.0004}_0$)
Pistons marked G.....	88.91 mm $^{+0.01}_0$ (3.5004 in $^{+0.0004}_0$)	96.02 mm $^{+0.01}_0$ (3.7803 in $^{+0.0004}_0$)
Oversize		
Oversize 1.....	89.27 mm $^{+0.01}_0$ (3.5146 in $^{+0.0004}_0$)	96.28 mm $^{+0.01}_0$ (3.7906 in $^{+0.0004}_0$)
Oversize 2.....	89.65 mm $^{+0.01}_0$ (3.5295 in $^{+0.0004}_0$)	96.58 mm $^{+0.01}_0$ (3.8024 in $^{+0.0004}_0$)

Piston weight

B 204	460±7 g (16.2±0.25 oz)
B 234	530±7 g (18.7±0.25 oz)

Max. difference in weight between pistons in same engine:..... 14 g (0.5 oz)

Piston clearance

B 204, B 234..... 0.010–0.030 mm (0.0004–0.0012 in)

Piston rings, side clearance

Upper compression ring


B 204	0.040–0.072 mm (0.0016–0.0028 in)
B 234	0.060–0.092 mm (0.0024–0.0036 in)

Lower compression ring


B 204	0.030–0.062 mm (0.0012–0.0024 in)
B 234	0.040–0.072 mm (0.0016–0.0028 in)

Oil scraper ring

B 204	0.020–0.055 mm (0.0008–0.0022 in)
B 234	0.030–0.065 mm (0.0012–0.0026 in)



129 521



Piston ring gap


Piston ring gap is measured with crown of inverted piston 15 mm (0.6 in) from bottom of cylinder.

Upper and lower compression rings

B 204..... 0.30–0.50 mm (0.012–0.020 in)
B 234..... 0.30–0.55 mm (0.012–0.022 in)


Oil scraper ring

B 204..... 0.25–0.50 mm (0.010–0.020 in)
B 234..... 0.30–0.60 mm (0.012–0.024 in)



Piston/connecting rod, side clearance

B 204, B 234 0.15–0.45 mm (0.006–0.018 in)




Gudgeon pin, fit in con rod

The gudgeon pin should slide through the hole without noticeable play when pressed gently with the thumb.


B 204, B 234

Gudgeon pin diameter 23.0 mm (0.9055 in)




Connecting rods, big end bearing seat


Bearing seat diameter 52.0 mm (2.047 in)
Max. out-of-round..... 0.03 mm (0.0012 in)



146 008




144 930



9802

146 009



146 027

VALVE ASSEMBLIES

Valve guides

Lift valve approx. 2–3 mm (1/10 in) clear of seat when checking guides.

Clearance between new components:

Intake 0.03–0.06 mm (0.0012–0.0024 in)
 Exhaust 0.04–0.07 mm (0.0016–0.0028 in)

Max. clearance, used components:

Intake/exhaust 0.15 mm (0.0059 in)


Marking and dimensions of valve guides

Guide, P/N 1 378 960–7
Standard: Outside dia. 12.0 mm (0.4724 in)
 No. of grooves: 0
 Guide, P/N 1 378 958–1
Oversize: Outside dia. 12.1 mm (0.4764 in)
 No. of grooves: 1

Valve springs

Outside dia. 26.2 mm (1.0315 in)
 Inside dia. 18.1 mm (0.7126 in)

Length, mm (in)	Load, N (lb)
L: 43.0 (1.69)	0 (0)
L1: 37.0 (1.46)	232±20 (52±4.5)
L2: 26.5 (1.04)	640±40 (144±9)




129 453

Valve seats

Since the seats are not marked, the dimensions must be measured.

Valve seat diameter	Intake	Exhaust
B 234		
Standard	36.14 mm (1.4228 in)	33.14 mm (1.3047 in)
Oversize	36.64 mm (1.4425 in)	33.64 mm (1.3244 in)
B 204		
Standard	34.14 mm (1.3441 in)	31.14 mm (1.2260 in)
Oversize	34.64 mm (1.3638 in)	31.64 mm (1.2457 in)




Valve seats, machining

Machine valve seats to following angles:

Seating face, intake/exhaust	45°
Relief angle, upper	15°
Relief angle, lower	70°

Valve seat width (a)

Intake.....	1.3–1.9 mm (0.051–0.075 in)
Exhaust.....	1.7–2.3 mm (0.067–0.091 in)




Valves, machining

Machine-grind intake valves to following angles:

Seating face.....	44.5°
Edge width, new valve.....	1.5 mm (0.059 in)
Min. edge width after grinding	1.2 mm (0.047 in)


Caution! Exhaust valves are stellite-coated and must be ground only with grinding paste (carborundum).



Valve stems

Valve stem height... ..	49.4±0.4 mm (1.9449±0.0157 in)
Max. machining allowance.....	0.4 mm (0.0157 in)
Length, new valve:	
Intake.....	122.45±0.2 mm (4.8209±0.0079 in)
Exhaust.....	122.25±0.2 mm (4.8130±0.0079 in)

N.B. Correct valve stem height is essential to satisfactory operation of hydraulic tappets.



144 964


CAMSHAFTS

Axial clearance

Place camshafts in bearing seats.

Replace rear bearing caps and tighten nuts.

Axial clearance **0.05–0.40 mm** (0.0020–0.0157 in)



133 662


Marking, lift height

The camshafts are marked at the rear.

Camshaft profile

Intake.....	U1
Exhaust.....	U

Marking




144 896

Timing belt, tensioning spring

Inside diameter	10.5 mm	+0.5
		0
	(0.4134 in)	+0.0197
		0

Length, mm (in)	Load, N (lb)
75.6 (2.98)	0 (0)
65.0 (2.56)	153 (34.5)
52.0 (2.05)	340 (76.5)



146 370

BALANCE SHAFTS

Axial clearance


Axial clearance **0.06–0.19 mm** (0.0024–0.0075 in)

Belt tension – table of values

Coolant temp.	Timing belt			Balance shaft belt	
	Check measurement, limiting values*	Existing belt	New belt	Existing belt	New belt
20°C (68°F)	< 2,5 > 3,5	3,2±0,3	3,8±0,3	3,4±0,2	3,8±0,2
40°C (104°F)	< 3,2 > 4,2	3,9±0,3	4,4±0,3	3,9±0,2	4,3±0,2
87°C (187°F)	< 4,6 > 5,3	5,1±0,2	5,5±0,2	4,6±0,2	4,9±0,2

*Check to be carried out **10 000 km**(6 250 miles) (USA: 5 000 miles) after belt replacement

< = less than
> = greater than




OIL PUMP

Axial clearance of rotors

Axial clearance of inner and outer rotors in pump housing:
Specified clearance . **0.05–0.10 mm** (0.0020–0.0040 in)
(Measured with pump dry)

Group 22 Lubrication system



Engine oil

Capacity, excl. oil filter..... **3.5 l** (3.7 US qt)
 incl. oil filter..... **4.0 l** (4.2 US qt)


When replacing filter only:
 Top up with 0.5 l (0.5 US qt).

GRADE OF OIL

As per API-Service..... min. **SF***
 As per CCMC..... class **G2/G3**

* Oils designated SF/CC and SF/CD fulfil this requirement.

Volvo does not recommend the use of additives, since these may have an adverse effect on engine life.





OIL PRESSURE (min)

15 r/s (900 r/min)..... **0.10 MPa** (14.5 lb/in²)
 33 r/s (2000 r/min) **0.25 MPa** (36 lb/in²)
 50 r/s (3000 r/min) **0.50 MPa** (72.5 lb/in²)

Max. oil pressure (relief valve setting)..... **0.80 MPa** (116 lb/in²)
 (1 MPa = 145 lb/in²)

Relief valve spring (length at different loads):


Load, N (lb)	Length, mm (in)
0	47.6 (1.87)
44±4 (10±0.9)	32.0 (1.26)
61±6 (14±1.4)	26.0 (1.02)



Relief valve

Tightening torque..... **40±4 Nm** (29.5±3 ft.lb)

Group 25 Intake and exhaust system




Air cleaner

Damper setting at different outside temperatures:

A = $< +5^{\circ}\text{C}$ (41°F) (heated air only)

B = approx. $+10^{\circ}\text{C}$ (50°F)

C = $+15^{\circ}\text{C}$ (59°F) (cold air only)




Catalytic converter

The catalytic converter has the effect of reducing the CO content on reaching ignition temperature ($450^{\circ}\text{C}/840^{\circ}\text{F}$).

Tightening of flange bolts

The catalytic converter mounting flange bolts must be pulled up after the first 1 000–2 000 km (625–1 250 miles) of driving.

Group 26 Cooling system



128 187

Coolant – composition – warranty


Genuine Volvo coolant diluted with clean water in proportions of 50/50 is the only coolant guaranteed by Volvo to prevent corrosion and freezing damage.

Type C (blue-green) coolant may not be mixed with any other type.

The coolant must be changed every second year to ensure protection against corrosion.

Only type C coolant should be used as a replacement.

Capacity, manual gearbox **9.5 l** (10 US qt)
Capacity, automatic gearbox **9.3 l** (9.8 US qt)




146 779

Expansion tank

The relief valve in the cover opens at:
overpressure **150 kPa** (22 lb/in²)
underpressure **7 kPa** (1 lb/in²)

Thermostat

Marking **87**
Opening commences at **86–88°C** (187–190°F)
Full opening at **97°C** (207°F)



146 472

Auxiliary drive belts

On cars with AC, the compressor and servo pump are driven by twin drive belts.

1. Crankshaft pulleys
2. Alternator
3. Radiator fan
4. Servo pump
5. AC compressor

Alternator **HC 47*1288*1**
Servo pump **HC 50*1063*1**
AC compressor/servo pump **HC 50*1188*2**


Special tools

115	Description – use
8263-2	Starter switch: for turning engine
8280-6	Milling tool: for machining valve seats
8281-4	Piston ring compressor: for fitting pistons in block
8540-3	L155 extension sleeve: for compression tester


998	Description – use
5424-2	Piston ring holder: for removing/refitting piston rings
5496-0	Pressure tester: for pressure testing cooling system
6045-5	Mira valve seat milling tool
6052-0	Valve clamp: for removing/refitting valve collets
8500-6	Belt tension gauge: for checking tension of timing/balance shaft belts

999	Description – use
1426-0	Drift: for fitting clutch release bearing
1801-3	Standard handle: for attachment to drifts
2413-6	Counterhold: for replacement of con rod bushings
2520-8	Stand: for fixtures
2810-3	Lifting yoke: used when removing and installing engine
2903-6	Filter wrench: for removing oil filter
4090-3	Extractor: for removing clutch release bearing
5006-5	Lifting yoke: for lifting engine
5021-4	Press tool: for removing/replacing camshaft
5025-5	Assembly tool: for fitting camshaft seal
5033-9	Lifting bars: for lifting engine
5035-4	Attachment: for lifting engine
5039-6	Counterhold: for removing/replacing oil pump rotors
5098-2	Protractor: for tightening cylinder head bolts to specified angle
5111-3	Centering tool: for centering clutch plate
5112-1	Gear sector: for locking flywheel
5115-4	Lifting hook: for lifting engine
5185-7	Lifting hook: for lifting engine
5186-5	Lifting hook: for lifting engine
5199-8	Counterhold: for removing/replacing camshaft pulley
5219-4	Valve guide retainer: for removing/replacing valve guide seals
5222-8	Gauge: for measuring valve stem length
5244-2	15 mm socket: for removing/replacing universal joint bolts
5267-3	Lifting lug: for removing/installing engine
5270-7	Oil pressure gauge
5276-4	Drift: for fitting crankshaft rear oil seal
5283-0	Drift: for fitting crankshaft front oil seal
5284-8	Counterhold: for removing/replacing vibration damper
5297-0	Fixture: for holding engine in stand 2520
5309-3	Drift: for replacing con rod bushings


999	Description – use
5361-9	Assembly tool: for replacing oil pump seal
5362-2	Counterhold: for removing/replacing balance shaft drive pulley
5363-0	Fixture: for removing/replacing valve guides
5364-8	Drift: for removing/replacing valve guides
5365-5	Drift: for removing/replacing valve guides
5366-3	Drift: for removing/replacing valve guides
5367-1	Reamer: for reaming valve guides internally
5368-9	Drift: for fitting intake valve seats
5369-7	Drift: for fitting exhaust valve seats
5373-9	Reamer: for oversize valve guides
5376-2	Extractor: for removing balance shaft housing
5377-0	Drift: for fitting intake valve seats
5378-8	Drift: for fitting exhaust valve seats
5379-6	Drift: for fitting valve stem seals
5871-2	Lifting lug: for removing/installing engine
5872-0	Guide: spacer for 5284
5972-8	Fixture: for removing/installing gearbox
5996-7	Assembly tool: for fitting balance shaft seals
9639-9	Dial gauge: for internal measurements
9678-7	Honing tool: dia. 60–105 mm
9689-4	Compression tester: for petrol engines
9701-7	Micrometer: 0–25 mm
9702-5	Micrometer: 25–500 mm
9704-1	Micrometer: 75–100 mm
9802-3	Spring tester: for measuring spring load/length
9921-1	Volvo Monotester




115 8281




115 8263




115 8280




115 8540




998 5424




998 5496




998 6045




998 6052




998 8500




999 1426




999 1801



999 2413




999 2520




999 2810




999 2903




999 4090




999 5006




999 5021




999 5025




999 5033




999 5035




999 5039




999 5098




999 5111




999 5112




999 5115




999 5185




999 5986




999 5199




999 5219




999 5222




999 5244




999 5267




999 5270




999 5276




999 5283




999 5284




999 5297




999 5309




999 5361




999 5362




999 5363




999 5364




999 5365




999 5366




999 5367




999 5368, 5369




999 5373




999 5376




999 5377/5378




999 5379




999 5871




999 5872




999 5972



999 5996




999 9639




999 9678

Special tools




999 9689




25 – 50 mm

999 9701




50 – 75 mm

999 9702




75 – 100 mm

999 9704



999 9802




999 9921

Group 20 General

Belt tension gauge – use and calibration


It is essential that the belts be **correctly tensioned** to ensure maximum reliability and long life. Gauge 998 8500 must be used to adjust the tension to the correct value.



146 032


Components of gauge

- 1. Indicator
- 2. Indication marker
- 3. Marker adjuster
- 4. Movable guide latch



146 033

- 5. Movable guide
- 6. Sensing roller
- 7. Fixed guide




146 034

Measurement

Check that gauge is zeroed

Turn dial to zero indicator.


Release movable guide.



146 035

Place gauge on belt


Position sensing roller between two teeth.



146 036

Raise movable guide


Raise guide until it locks in upper position.



146 037

Hold gauge in neutral position against belt


Hold gauge without pressing upwards or downwards.
Set indication marker to coincide with indicator.



146 038


Release movable guide

Pull out movable guide latch.



146 039

Remove gauge from belt and read indicated value



146 040

Calibration

Gauge must be calibrated


- after prolonged use (approx. 100 measurements),
- following exposure to minor shocks.

Check that gauge is zeroed

Turn dial until indicator reads zero.

Place calibration plate in position

Position plate with projections in contact with guides.
Press movable guide upwards until locked in upper position.




146 041

Calibration value

Gauge should now read **4.0** units.

If value is incorrect: Adjust using 1.5 mm Allen key inserted in hole 1 in bottom of gauge.

Caution! Adjustment must be limited to within ± 1 unit of the calibration value. If error is greater, return instrument to Volvo Parts for repair.




146 042

Group 21 Engine and mountings

Contents

	Procedure	Page
Design/function	-	27
Compression testing	A1-9	34
Timing belt, checking/adjustment	B1-11	37
Timing/balance shaft belts, replacement	C1-37	40
Timing belt tensioner, inspection/replacement	D1-6	51
Balance shaft seals, replacement	E1-6	53
Camshaft seals, replacement	F1-24	55
Oil pump seal, replacement	G1-4	63
Oil pump, replacement	H1-7	64
Oil pump, inspection	I1-9	66
Valve cover gaskets, replacement	J1-6	69
Camshafts/tappets, replacement	K1-26	71
Tappets, inspection	L1-6	79
Camshaft carrier/cylinder joint, resealing	M1-6	81
Cylinder head gasket, replacement	N1-21	83
Cylinder head, dismantling/inspection	O1-10	89
Cylinder head, overhaul	P1-26	92
Cylinder head, reassembly	Q1-4	99
Balance shaft housing, replacement/overhaul	R1-49	101
Engine mountings, overhaul	S1-19	114
Engine, removal	T1-30	119
Engine replacement, transfer of components	U1-35	127
Engine, installation	V1-31	137
Oil sump, gasket replacement	W1-25	146
Crankshaft assembly, dismantling	X1-32	153
Crankshaft assembly, inspection/cleaning	Y1-22	162
Crankshaft assembly, reassembly	Z1-46	169
Stripped engine, removal	AA1-25	181
Crankshaft main bearings, replacement	AB1-25	188
Ring gear, replacement	AC1-8	195
Crankshaft rear seal, replacement	AD1-31	198
Crankshaft pulley (vibration damper), replacement	AE1-4	207
Crankshaft front seal, replacement	AF1-9	208

Design/function Engine




Features common to B 204 and B 234 engines:

- In-line, 4-cylinder, liquid-cooled engine
- Inclined 20° to right for installation purposes
- Cast iron cylinder block with cylinders bored directly in block
- Cast light-alloy pistons
- Forged steel connecting rods and crankshaft
- Light-alloy cylinder head
- Cross-flow configuration i.e. intake and exhaust passages located on opposite sides of combustion chambers
- Twin overhead camshafts
- Four valves per cylinder
- Two externally-mounted balance shafts
- Camshafts, balance shafts and oil pump driven by toothed belts


Differences between basic B 204 engine and B 234:

- Cubic capacity (2.0 litre)
- Pistons (smaller diameter)
- Valves (smaller diameter)
- Balance shafts (lower moment of inertia)



Four valves per cylinder

The introduction of four valves per cylinder improves engine 'breathing'. Gas flow conditions in the cylinders are improved, producing more complete combustion of the fuel/air mixture and improving the efficiency of the engine.




Output and torque diagram for 1988 B 234 F engine

As the curves show, maximum output is achieved at 5800 r/min while maximum torque is developed at 4450 r/min.

Overrun protection operates at 6200 r/min. (Maximum speed varies somewhat depending on market and model variant.)

ProCarManuals.com

146 690




Twin overhead camshafts

The valves are operated by twin overhead camshafts through hydraulic tappets. The oil-filled tappets are self-adjusting.


Since the valve guides are inclined at an angle of 19° to the vertical, the use of a special tool is recommended when replacing the components.

Valve cover gaskets

The valve cover is provided with two types of gasket, one for sealing the spark plug wells and the other the outer perimeter of the joint.



146 692




144 981

The joint between the camshaft carrier and cylinder head is sealed in two ways:

- The spark plug wells are sealed using four O-rings and a liquid sealing compound (liquid gasket).
- A **liquid sealing compound** is used to seal the flat mating surfaces between the components.

It is essential that the surfaces be thoroughly **cleaned** and that all traces of oil be removed before applying new sealing compound.

The compound is applied with a short-haired roller.




Hydraulic tappets

The valves are operated by twin overhead camshafts through hydraulic tappets. The oil-filled tappets are self-adjusting.


Each tappet is held in contact with the camshaft by a spring in the tappet cylinder. The spring force is lower than that of the valve spring to ensure that the valve is free to expand linearly.

A non-return valve prevents the escape of oil when the camshaft is operating the tappet and when the oil pressure in the tappet cylinder is higher than the engine oil pressure.




Tappet in contact with base circle of cam

Oil from the camshaft carrier is forced into the tappet through a groove and a series of holes in the side, entering the plunger through a slot in the top. Since the engine oil pressure is higher than that in the tappet cylinder when the tappet is not operated by the cam, the oil flows through the non-return valve into the tappet cylinder.



Tappet operated by cam


The oil pressure in the tappet cylinder now exceeds the engine oil pressure, closing the non-return valve and effectively making the assembly a solid component.



146 696

Tappet resumes contact with base circle of cam


The engine oil pressure again exceeds that in the tappet cylinder, opening the non-return valve and admitting oil to maintain the tappet in contact with the cam.



146 697

Combustion chamber

The 'pent-roof' combustion chamber features squish zones which force the fuel/air mixture towards the centre of the chamber as the piston approaches top dead centre (TDC) on the compression stroke – a feature which promotes excellent mixing as the fuel approaches the spark plug. The resultant short combustion path promotes rapid combustion, reducing the risk of self-ignition (or knock) and enabling a high compression ratio to be used. This, in turn, yields high performance at low fuel consumption.




146 698

Balance shafts


The vibrations caused by the reciprocating movement of the pistons are counterbalanced by two counter-rotating balance shafts running at twice the engine speed.

Each of the two externally-mounted balance shaft housings is split. Made of die-cast aluminium, the housings are located at different heights on the block. The block casting is provided with bosses which are milled out to provide a press fit for the housings. Securely located, the housings are then bolted in position. The right-hand housing also supports the drive belt tensioner.


The joint between the housing halves is sealed with a liquid sealing compound in the same manner as that between the camshaft carrier and cylinder head.



146 699



146 700



146 701

Equalization of upward and downward forces

In a 4-cylinder engine, vibrations are caused by the reciprocating action of the pistons as they move upwards and downwards in pairs. The two outermost pistons (1 and 4) are at top dead centre (TDC) when the inside pair (2 and 3) are at bottom dead centre (BDC), and vice versa. However, since the forces developed by each pair of pistons differ, they do not cancel each other completely. (The force due to a piston and crankshaft is greater at TDC than at BDC since, in the latter position, the mass of that portion of the crankshaft above the centre line is partly counterbalanced by that below.)

The purpose of the balance shafts is to increase the force developed by the piston pair reversing at BDC, thereby equalizing that due to the pair at TDC.

Since two piston reversals occur during each revolution of the crankshaft, the balance shafts rotate at twice the speed of the engine. The balance weights mounted on the shafts reach their lowermost position each time one of the piston pairs reverses at BDC.

As a result, the force developed by this particular pair is increased, equalizing that of the pair at TDC and producing smoother running.

Equalization of lateral forces

The lateral forces produced by the action of the pistons at TDC and BDC cause the engine to pivot about an axis located approximately at the mid-point of the block.


The balance shafts are located at different heights on the block to counteract the resultant moment. The forces due to the balance weights combine to exert a moment which opposes that produced by the pistons.

Cancelling the moments produces smoother running in this respect also.

Lubrication of balance shaft

Pressurized oil is supplied to the rear balance shaft bearings, each of which is an extra heavy-duty shell type. The rear section of the shaft is subject to the highest stresses since the balance weights are located at that end.

The front bearing is machined in the housing and is lubricated from the rear bearing through a channel formed by matching grooves formed in the two halves. The oil is discharged through an outlet in the bottom half of the housing.




Camshaft and balance shaft drives

Camshaft drive

The camshaft drive consists of a conventional single-toothed belt which drives both camshafts and the oil pump.


The belt tension is controlled by a spring-loaded tensioner, while alignment is maintained by two idler pulleys.



Balance shaft drive

Rotating in opposite directions, the two balance shafts are driven from the crankshaft by a double-toothed belt.


The left-hand shaft is driven by the inside teeth and the right-hand shaft by the outside teeth.



Tensioning of balance shaft belt

A tensioner mounted eccentrically on the housing below the right-hand balance shaft is used to control the belt tension, the alignment of which is maintained by an idler. Since tensioning of the balance shaft belt must be carried out with the greatest accuracy, the instructions in the workshop manual must be followed exactly.

Overtensioning of the belt may damage the balance shaft housings, while insufficient tension may cause misalignment.



Crankshaft

The crankshaft main bearings are 63 mm in diameter. The 35.5 mm wide thrust bearing (rear main bearing) is of the flanged shell type with a bearing surface of 2x36°. The big-end bearings on the **connecting rods** are of the low-friction type, while the gudgeon pins are located in a high position in the pistons – a feature which minimizes friction and vibration, although imposing greater demands in terms of cooling and lubrication. The engine is fitted with a 'heavy' **flywheel** weighing 12.7 kg (28 lb).

A. Compression testing


Special tools: 9689, 115 8263, 115 8540



Ignition system

Warning! The ignition system operates at **high power**, with **dangerous** voltages in both the low-tension and high-tension circuits.


Dangerous voltage levels occur in **all parts of the ignition system**, including connectors and similar fittings.



Measure compression at full throttle with engine hot

Normal value **0.9-1.1 MPa** (131-160 lb/in²)

N.B. Above value applies when engine is hot, throttle is fully open and engine is turned at 4.2-5.0 r/s (250-300 r/min) using starter motor.




A1

Disconnect:

- lead from terminal 1 on ignition coil (to prevent flashover to electrical system wiring)
- injector connectors (to prevent flooding of engine and dilution of engine oil)

A2



144 852


Remove:

- ignition lead cover plate
- ignition leads from plugs
- plugs from cylinder head

Clean spark plug wells as required before removing plugs. Check condition of plugs.

N.B. Always grip ignition leads by **caps** when removing to avoid damage to leads.

A3



144 853

Lock throttle in fully open position


Use tool such as screwdriver for this purpose.

A4

Connect starter switch

Use special tool 115 8263-4.

Connect switch in series with alternator (+) and service point on left-hand wheel housing.




144 854

A5


Measure compression

Use compression tester 9689 and extension sleeve 115 8540.

Measure compression in all cylinders.



144 855




144 856

A6

Disconnect/remove:

- starter switch
- throttle 'lock'

Check that throttle cable is seated in pulley groove.




144 851

A7

Reconnect:

- injector connectors
- lead to terminal 1 on ignition coil

ProCarManuals.com



144 857

A8

Install spark plugs

Screw in each plug until sealing ring is in firm contact with cylinder head.


Alt. 1
Tighten new plugs through further 90°. Tighten used plugs through further 30°.

Alt. 2
Tightening torque 25 ± 5 Nm (18.5 ± 4 ft.lb)

A9

Install:

- ignition leads (in correct firing order)
- ignition lead cover plat



144 858


B. Timing belt, checking/adjustment

Special tool: 998 8500


To be carried out **10000 km (6250 miles)** (USA: 5000 miles) following belt replacement.

Procedure to be carried out with engine warm to touch (approx. **40°C/104°F**).


Caution! See table in specifications if checking/adjustment is carried out at **other** engine temperature.



144 860



144 865



144 861

Checking

B1

Turn engine to TDC in No. 1 cylinder

Remove upper transmission cover (1).

Check that markings on camshaft pulleys are opposite markings on transmission mounting plate.

Check that marking on crankshaft is opposite TDC marking.

B2

Check belt tension

Position gauge **998 8500** between exhaust camshaft pulley and tensioner.

Read gauge.

If belt tension is correct, reading should be between 3.2 and 4.2 units.

If tension is correct, install transmission cover (1).

If tension is incorrect, belt **must** be adjusted as described in operations **B3-B10**.


Adjustment

B3

Slacken tensioner locknut

Remove protective rubber cap in transmission cover.

Slacken locknut.




144 862

B4

Turn crankshaft clockwise through one revolution

Camshaft pulley markings should again coincide with markings on transmission mounting plate.

N.B. Engine must not be rotated counterclockwise during belt tensioning procedure.




144 863

B5

Turn engine further clockwise

Turn engine until camshaft pulley markings are 1 1/2 teeth past markings on transmission mounting plate.


N.B. Rotate crankshaft smoothly.



144 864

B6

Tighten tensioner locknut




144 862

B7

Turn crankshaft clockwise to complete one revolution

Turn crankshaft to return to TDC.
Check that all markings coincide.

B8



Recheck belt tension


Position gauge **998 8500** between exhaust camshaft pulley and idler pulley.

Read gauge.

Belt tension should now agree with specified value of 3.9 ± 0.3 units.

N.B. If reading is still **outside** correct range, adjust as described in operation **B11**.

B9



Tighten tensioner locknut

Tighten to **50 Nm (37 ft.lb)**


Install:

- protective rubber cap over tensioner locknut
- upper transmission cover (1)

B10

Check operation

Test run engine.



B11

Tension timing belt

Slacken tensioner locknut.

Position gauge in measuring zone.

Insert screwdriver between tensioner pulley and end of spring carrier pin.

If belt tension is too low:

Move pulley to adjust reading to 4.4 ± 0.3 units.


If belt tension is too high:

Adjust to obtain reading of 3.4 ± 0.3 units.

Tighten tensioner locknut.

Recheck belt tension as per operations **B7-B8**.

Complete adjustment as per **B9-B10**.




C. Timing/balance shaft belts, replacement

Special tool: 998 8500

Important

See table in specifications in belt replacement is carried out at engine temperature **other** than that specified.




144 868

C1

Remove:

- battery (-) lead
- alternator drive belt
- radiator fan and pulley
- fan shroud
- servo pump and (if fitted) AC compressor drive belts




144 869

C2

Remove all three transmission covers

Remove all bolts.
Remove covers, starting with topmost (1).



144 870


C3

Turn engine until camshaft/crankshaft markings coincide

Turn engine to TDC in No. 1 cylinder.

Check that markings on camshaft pulleys coincide with those on transmission mounting plate.

Check that marking on belt guide plate on crankshaft is opposite TDC marking on cylinder block.



144 871


Removal of timing belt

C4

Remove timing belt

- Slacken tensioner locknut.
- Compress tensioner spring.
- Tighten tensioner locknut.
- Remove belt.

Caution! Crankshaft and camshafts must **not** be rotated while timing belt is slack or has been removed.




144 872

C5

Check tensioner

- Spin tensioner pulley and listen for bearing noise.
- Check that pulley surface in contact with belt is clean and smooth.




144 873

C6

Check timing belt idler pulleys

- Spin pulleys and listen for bearing noise.
- Check that pulley surfaces in contact with belt are clean and smooth.
- Check pulley mountings. Torque: 25 Nm (18.5 ft.lb).




Removal of balance shaft belt

C7

Remove balance shaft belt idler pulley


Check pulley surface and bearing for faults.



C8

Slacken belt tensioner

Slacken locknut.




C9

Remove balance shaft belt

Slide belt off drive pulleys and tensioner.

Work belt out under crankshaft pulley assembly.

Check tensioner bearing and inspect for oil leakage from shaft seals.




144 877

Check balance shaft and crankshaft markings

Check that balance shaft markings coincide with markings on transmission mounting plate.

Check that crankshaft marking is opposite TDC marking on cylinder block.

C10

Installation of balance shaft belt


144 878

Balance shaft belt markings (3)

- A. RH balance shaft (yellow dot).
- B. Lower marking on crankshaft (blue dot).
- C. LH balance shaft (yellow dot).

A-B = 18 teeth
B-C = 34 teeth

C11



144 876

Install balance shaft belt

Carefully work belt in **under** crankshaft pulley assembly.





Ensure that blue dot (marking B) is opposite **bottom** (TDC) marking on belt guide plate (at bottom of crankshaft).

Fit belt **around** left-hand (upper) balance shaft with marking C opposite marking on pulley.

Fit belt **on** right-hand (lower) balance shaft with marking A opposite marking on pulley.

Fit belt **around** tensioner.

C12



C13

Check balance shaft and crankshaft markings

Check that markings are still aligned.

C14

Tighten tensioner

Tension belt using Allen key inserted in adjusting hole (1) in tensioner.

Turn crankshaft **carefully** through a few degrees on either side of the TDC position to ensure that belt engages properly in pulleys.

Return crankshaft to TDC position.

Adjusting hole in tensioner must be **immediately below** '3 o'clock' when tightening locking bolt.

Tighten locking bolt (2) to **40 Nm** (29.5 ft.lb). Use Allen key inserted in adjusting hole (1) as **counterhold**.

C15

Check belt tension

Use gauge **998 8500**.

Position gauge immediately above location of dismantled idler.

Belt tension **must** be within **1-4** unit range.

N.B. If belt tension is outside above range, slacken tensioner and repeat operation C14.

Installation of timing belt

C16

Install timing belt

Align double-line marking on belt with **top** marking on belt guide plate (at top of crankshaft).


N.B. Arrows on belt should point towards front (i.e. away from engine).

Stretch belt around crankshaft pulley and place **over** tensioner and **right-hand** idler.

Place belt on camshaft pulleys. Both single-line markings should coincide with pulley markings.

Place belt **around** oil pump drive pulley and press belt onto **left-hand** idler.

C17




144 870

Check markings

Check that **all** markings are aligned and that engine is turned to TDC in No. 1 cylinder.


C18



144 882

Slacken tensioner locknut

C19




144 883

Turn crankshaft clockwise

Crankshaft pulleys should rotate one turn until **pulley markings** again coincide with those on transmission mounting plate.

N.B. Engine must **not** be rotated counterclockwise while belt is being tensioned.

C20




144 863

Turn crankshaft further clockwise


Turn crankshaft further clockwise until pulley markings are **1 1/2 teeth** past markings on housing.

N.B. Rotate crankshaft smoothly.



C21

Tighten tensioner locknut



C22

Check/adjust balance shaft belt tension

Use gauge **998 8500**. Measure tension above location of dismantled idler.


Belt tension should be 3.8 ± 0.2 units at 20°C (68°F).

If belt tension is too low: Correct by adjusting tensioner clockwise.

N.B. Tensioner may be adjusted **clockwise** only. Only small adjustments are required.

If belt tension is too high: Repeat operations **C14-C15**.


Turn crankshaft through one revolution and recheck/adjust belt tension.



C23

Install:

- guide (i.e. ensure that guide is in position)
- middle transmission cover (3)
- fan shroud
- heater hose tie
- radiator fan and pulley
- all auxiliary drive belts
- battery (-) lead




C24

Check operation

Run engine until thermostat opens.

Stop engine.

Caution! Remember that transmission covers (1) and (2) have **not been replaced at this point**.



Check/adjust timing belt tension after thermostat has opened

C25

Check belt tension

Use gauge **998 8500**.


Rotate crankshaft to bring engine to TDC position in No. 1 cylinder.

Position gauge between exhaust camshaft pulley and idler.

Read gauge.

Belt tension **must** be within the 5.5 ± 0.2 unit range.


N.B. If belt tension is **correct**, proceed to operation C30. If reading is **outside** above range, carry out operations C27-C29.



C26

Slacken tensioner locknut

Remove protective rubber cap over locknut.



C27

Tension timing belt

Position gauge in measuring zone.

Insert screwdriver between tensioner pulley and spring carrier pin.

If belt tension is too low:

Move roller to adjust belt tension to 6.0 ± 0.2 units.

If belt tension is too high:


Adjust to obtain reading of 5.0 ± 0.2 units.

Tighten tensioner locknut.

C28

Turn crankshaft clockwise

Turn crankshaft to rotate camshaft pulleys through one revolution.




144 888

C29

Measure belt tension

Belt tension should now agree with specified value of 5.5 ± 0.2 units.




144 865


C30

Tighten tensioner locknut

Tighten to **50 Nm (37 ft.lb)**.
Replace protective cap over locknut.



144 889



144 890

Check/adjust balance shaft belt tension after opening of thermostat

C31


Check belt tension

Use gauge 998 8500.

Position gauge above location of dismantled idler.

Belt tension **must** be within the 4.9 ± 0.2 unit range.

N.B. If belt tension is **correct**, proceed to operations C35-C37.
 If belt tension is too **low**, carry out operations C32-C34.
 If belt tension is too **high**, repeat operations C14-C15 and continue with operations C32-C34.




146 459

C32

Turn tensioner clockwise and read indication on gauge

N.B. Tensioner may be turned **clockwise** only. Only small movements are necessary.




144 888

C33

Turn crankshaft clockwise

Turn crankshaft clockwise through one revolution.

C34



144 890


Check belt tension

Belt tension should now agree with specified value of 4.9 ± 0.2 units.

C35

Install idler

Remount idler in position.




144 892

C36

Install:

- lower transmission cover (2)
- upper transmission cover (1)




144 893

C37

Check operation


Test run engine.



144 867

D. Timing belt tensioner, inspection/replacement

Special tool: 9802




Remove timing belt as described in operations C1-C4.

D1

Check tensioner

Spin pulley and listen for noise. Check manually for bearing play.

Check that pulley surface in contact with belt is clean and smooth.




D2

Remove tensioner

Compress tensioner spring and lock with 3 mm drill bit.

Remove:

- tensioner locknut
- pulley (pull straight off)



D3


Dismantle tensioner

Clamp tensioner between soft jaws in vice.

Compress spring by hand and remove drill bit.

Release spring **slowly**. Separate pulley bracket and spring carrier pin.

D4




Check tensioner spring

Check spring using tool 9802.

Inside diameter:..... **10.5 mm** ^{+0.5}₀
 (0.41 in ^{+0.02}₀)

Length, mm (in)	Load, N (lb)
75.6 (2.98)	0 (0)
65.0 (2.56)	153 (34.5)
52.0 (2.05)	340 (77.5)

ProCarManuals.com




D5

Reassemble tensioner

Clamp spring carrier pin and spring between soft jaws in vice.

Compress spring by hand and hold in position with 3 mm drill bit.



D6

Install tensioner

Mount tensioner on cylinder block.

Tighten tensioner locknut.

Remove drill bit.

Replace timing belt as described in operations C16-21, C23-30 and C36-37.

N.B. See table of tension values in specifications (page 11) if replacing existing timing/balance shaft belts.

E. Balance shaft seals, replacement

Special tools: 5362, 5996


E1

Check that flame trap is not blocked

Flame trap blockage restricts crankcase ventilation and increases crankcase pressure.

Symptoms of flame trap blockage:


- Oil dipstick tends to lift in tube.
- Oil leakage from cylinder block seals.
- Seals do not always require renewal if leakage is due to this cause. Overhaul flame trap, clean engine and reinspect for seal leakage.
- Engine knocks.



E2

Remove:


- timing and balance shaft belts as described in operations C1-C10.




E3

Remove balance shaft pulley

Use counterhold 5362.



E4



144 901


Remove seal

Prise out seal **carefully** with screwdriver, taking care to avoid damaging seating faces on shaft and housing.

Place paper or waste underneath to soak up leakage oil.

Clean seating in housing and check shaft end for grooving, indicating wear.

E5



144 902

Fit new seal


Use assembly tool **5996**.

Grease seal.

Press seal into shaft housing. Press in lightly with tool **5996** and use centre bolt together with tool to press home fully.

N.B. Face of seal should normally be flush with chamfered edge in housing. However, if shaft end shows signs of wear, seal may be located approx. 2 mm further in.

E6



144 903

Install balance shaft pulley

Use counterhold **5362**.

Tighten centre bolt to **50 Nm (37 ft.lb)**.

N.B. Slot in pulley should engage guide pin on shaft.
Shallower side of pulley should face inwards.


Replace timing and balance shaft belts as described in operations **C12-37**.

N.B. See table of tension values in specifications (page 11) if replacing existing timing/balance shaft belts.

F. Camshaft seals, replacement

Special tools: 5025, 5199

On later versions of engines, seals may be replaced without removing transmission mounting plate.



144 898


F1

Check that flame trap is not blocked

Flame trap blockage restricts crankcase ventilation and increases crankcase pressure.

Symptoms of flame trap blockage:

- Oil dipstick tends to lift in tube.
- Oil leakage from cylinder block seals.
- Seals do not always require renewal if leakage is due to this cause. Overhaul flame trap, clean engine and reinspect for seal leakage.
- Engine knocks.




144 904

F2

Remove:

- battery earth lead
- alternator drive belt
- radiator fan and pulley




144 893

F3

Remove transmission covers (1) and (2)

Remove upper (1) and lower (2) transmission covers.

F4




144 905

Align camshaft/crankshaft markings

Turn engine to TDC position in No. 1 cylinder.
Check that markings on camshaft pulleys are aligned with those on transmission mounting plate.

F5




144 886

Slacken tensioner locknut

Remove protective rubber cap over tensioner locknut.
Slacken locknut.

F6



144 906


Compress tensioner spring

Compress tensioner spring.
Press timing belt outwards between right-hand idler and tensioner.
Tighten tensioner locknut.

F7

Remove timing belt from crankshaft pulleys


Caution! Crankshaft and camshaft **must not** be rotated while timing belt is slack or has been removed.



F8

Remove timing belt idlers


Check pulley surfaces and bearings.



F9

Remove camshaft drive pulleys


Use counterhold 5199.




F10

Remove upper section of transmission mounting plate

Remove bolts between camshafts and under right-hand idler.



F11




Remove seal

Prise out seal **carefully** using a screwdriver, taking care to avoid damaging shaft ends and seating surfaces in camshaft carrier.

Clean seats in camshaft carrier and check shafts for grooving, indicating wear.

F12



Fit new seals


Use assembly tool 5025.

Grease seals.

Press in seals.

N.B. Camshafts must **not** be allowed to rotate when fitting seals. Face of seal should normally be flush with chamfered edge in camshaft carrier. However, if shaft end shows signs of wear, seal may be located approx. 2 mm further in.

F13



Replace upper section of transmission mounting plate


Adjust plate so that camshafts are centred in holes.

Replace bolts between camshafts and under right-hand idler.

F14

Replace idlers

Tighten to **25 Nm** (18.5 ft.lb.).




F15

Install camshaft drive pulleys

Use counterhold **5199**.

Replace centre bolts and tighten to **50 Nm** (37 ft.lb.).

N.B. Camshafts must **not** be allowed to rotate when replacing the centre bolts.




F16

Replace timing belt


Position belt so that double-line marking coincides with **top** marking on belt guide plate (at top of crankshaft).

Place belt on camshaft pulleys, ensuring that single-line markings coincide with pulley markings.

Place belt in position over **right-hand** and then over **left-hand** idler.



F17




144 905

Check markings

Check that **all** markings coincide and that the engine is turned to TDC in No. 1 cylinder.


F18



144 913

Slacken tensioner locknut

F19




144 888

Turn crankshaft clockwise

Crankshaft pulleys should rotate one turn until **pulley markings** again coincide with those on transmission mounting plate.

N.B. Engine must **not** be rotated counterclockwise while belt is being tensioned.

F20




Turn crankshaft further clockwise

Turn crankshaft further clockwise until pulley markings are $1\frac{1}{2}$ teeth past markings on housing.

N.B. Rotate crankshaft **smoothly**.

F21

Tighten tensioner locknut




F22

Install:

- lower transmission cover (2)
- radiator fan and pulley
- alternator drive belt
- battery earth lead


Continue with operations **C24-25**.

N.B. See table of belt tensioning values in specifications (page 11) if refitting original timing belt.



F23


Install upper transmission cover (1)



F24


Check operation

Test run engine.



G. Oil pump seal, replacement

Special tools: 5039, 5361




Remove timing belt as described in operations C1-4.

G1

Remove oil pump drive pulley

Use counterhold 5039.




G2

Remove seal

Clean area around drive shaft and seal.

Pry out seal **carefully** using a screwdriver, taking care to avoid damaging shaft end and housing.

Clean seat in housing and check shaft for signs of wear.



G3

Fit new seal

Use assembly tool 5361.

N.B. Face of seal should normally be flush with chamfered edge in housing. However, if shaft end shows signs of wear, seal may be located approx. 2 mm further in.

G4

Install drive pulley

Use counterhold 5039.


Rotate pulley to align locating chamfer. Tighten centre bolt to **20 Nm** (15 ft.lb) and through a further **60°**.

Install timing belt as described in operations C16-21, C23-30 and C36-37.

N.B. See table of belt tensioning values in specifications (page 11) if refitting original timing belt.

H. Oil pump, replacement

Special tool: 5039




Remove timing belt as described in operations **C1-4**.

H1


Remove oil pump drive pulley

Use counterhold 5039.



H2

Clean area in vicinity of pump joint




H3

Remove oil pump

Remove pump mounting bolts.

Place paper or container on engine splashguard to collect leakage oil.

Remove pump.



H4

Remove seal

Remove seal from seating groove in cylinder block.


Clean joint face and groove.

Check rear contact faces of rotors.

H5

Fit new seal

Seat seal in groove.



H6


Install oil pump

Lubricate rotors generously.

Position pump on cylinder block.

Tighten mounting bolts to **10 Nm** (7.5 ft.lb.).

N.B. Take care not to turn pump so that rotor shaft falls out of position in housing.



H7

Install drive pulley

Use counterhold **5039**.


Rotate pulley to align locating chamfer.

Tighten centre bolt to **20 Nm** (15 ft.lb) and through a further **60°**.

Clean and remove paper/oil container.


Install timing belt as described in operations **C16-21**, **C23-30** and **C36-37**.

N.B. See table of belt tensioning values in specifications (page 11) if refitting original timing belt.



I. Oil pump, inspection

Special tools: 5039, 5361




Remove timing belt as described in operations C1-4.
Remove oil pump as described in operations H1-4.

11

Remove rotors and shaft seal from oil pump housing

Mark outer rotor with felt pen to ensure same direction of rotation on reassembly.




Clean and inspect components

Inspect pump housing, rotors and rotor mating faces for visible signs of wear.

N.B. Note marking of outer rotor.

12




Check pump housing joint for distortion

Use steel rule/sliding calipers.

13

14




Check axial clearance of rotors

Check axial clearance of outer and inner rotors in pump housing.

Correct clearance: **0.05–0.10 mm** (0.0020–0.0040 in) (with pump dry).

15




Lubricate rotors and inside of pump housing

Remove rotors. Apply generous lubrication to rotors and inside of pump housing.

Replace rotors in housing.


16



Fit new seal


Seat seal in groove.

17



Replace oil pump


Tighten mounting bolts to **10 Nm** (7.5 ft.lb).



Fit new seal

Use assembly tool **5361**.

N.B. Face of seal should normally be in line with chamfered edge in housing. However, if shaft end shows signs of wear, seal may be located approx. 2 mm further in.



Replace drive pulley

Use counterhold **5039**.

Rotate pulley to align locating chamfer.


Tighten centre bolt to **20 Nm** (15 ft.lb) and through a further **60°**.

Clean and remove paper/oil container.

Replace timing belt as described in operations **C16–21**, **C23–30** and **C36–37**.

N.B. See table of belt tensioning values in specifications (page 11) if refitting original timing belt.

J. Valve cover gaskets, replacement




J1

Remove/disconnect:

- ignition lead cover plate
- ignition leads from plugs


N.B. Always grip ignition leads by **caps** when removing to avoid damage to leads.



J2

Remove valve cover and gaskets

Remove remains of gaskets and clean joint faces.
Inspect rubber seal at rear of exhaust valve camshaft.




J3

Apply sealer at front and rear camshaft bearing caps

Use silicone sealer.

Apply bead of sealer to angle between cap and joint face.

J4



Install new gaskets and replace valve cover


Position spark plug well gasket with arrow pointing to No. 1 cylinder and marking facing upwards.

Shape outer gasket to fit camshaft bearing caps.

Place gasket in position and replace valve cover.

N.B. Remember to connect earth lead to distributor.


J5



Install:

- ignition leads (in correct firing order)
- ignition lead cover plate

J6




Check operation

Check operation/sealing.

K. Camshafts and tappets, replacement

Special tools: 5021, 5199



Replacement of camshafts due to wear

It is imperative that engine be flushed clean before installing new components.

In most cases, damage to tappets and camshafts is due to engine oil contamination.

Flush engine


Change oil and filter.

Run engine for approx. 10 minutes.

Drain oil and remove filter.

Install camshafts.

Fit new filter and fill engine with fresh oil of correct grade.



Removal of camshafts

N.B. Procedure describes removal of all tappets. To ensure sealing function of liquid sealing compound between camshaft carrier and cylinder head, tappets should be exposed only on one side at a time.

K1


Remove/disconnect:


- battery earth lead
- alternator drive belt
- radiator fan and pulley

K2

Remove transmission covers (1) and (2)

Remove upper (1) and lower (2) transmission covers.






K3

Align camshaft/crankshaft markings

Turn engine to TDC position in No. 1 cylinder.

Check that markings on camshaft pulleys are aligned with those on transmission mounting plate.



K4


Slacken tensioner locknut

Remove protective rubber cap over locknut.

Slacken locknut.

Compress tensioner spring.


Tighten locknut.



K5

Remove timing belt from crankshaft pulleys

Caution! Crankshaft and camshafts must not be rotated while timing belt is slack or has been removed.




K6

Remove timing belt idlers

Check pulley surfaces and bearings.


K7



Remove camshaft drive pulleys

Use counterhold 5199.

K8




Remove:

- upper section of transmission mounting plate
- ignition lead cover plate
- ignition leads at plugs and distributor cap
- ignition coil high-tension lead at distributor cap

N.B. Always grip ignition leads by caps when removing to avoid damage to leads.


K9



Remove valve cover and gaskets


Remove gasket remains and clean joint faces.

K10



Detach distributor housing from camshaft carrier

N.B. Remove ignition lead clip beside left-hand bolt.




K11

Remove camshaft centre bearing caps

Plug openings in camshaft carrier (around spark plug wells) with paper.

Remove camshaft centre bearing caps (No. 3 on intake side, No. 8 on exhaust side). Mark caps as required.

Remove third nut in central bolted joint.



K12

Remove exhaust side camshaft


Use press tool **5021**. Place tool in No. 8 bearing cap position.

Clamp press tool on camshaft.

Remove remaining bearing cap nuts and caps (6, 7, 9 and 10).

Inspect bearing surfaces for signs of wear.

Remove press tool **5021** and lift out camshaft.



K13

Remove intake side camshaft


Use press tool **5021**. Place tool in No. 3 bearing cap position.

Clamp press tool on camshaft.

Remove remaining bearing cap nuts and caps (1, 2, 3 and 5).

Inspect bearing surfaces for signs of wear.

Remove press tool **5021** and lift out camshaft together with distributor.



K14

Remove tappets from camshaft carrier

Magnet or suction cup may be used to facilitate tappet removal.

Inspect tappets for signs of wear.


N.B. Store tappets upside down to prevent drainage of oil. Ensure tappets are placed in order – they must not be interchanged.

K15

Clean/inspect camshaft carrier

Clean and inspect camshaft bearings and tappet bores for signs of wear.

Camshaft axial clearance



Camshaft axial clearance

K16

Check camshaft axial clearance

Place camshafts in position.


Install rear bearing caps and tighten nuts.

Axial clearance **0.05–0.40 mm** (0.0020–0.0157 in)

Measure clearance with feeler gauges.

Install new rear bearing cap if clearance is excessive.

Remove bearing caps and camshafts.




Camshaft installation

K17

Oil components


Oil bearings and sliding surfaces on camshaft carrier, bearing caps, camshafts and tappets.




K18

Insert tappets

Tappets **must** be replaced in original order.





K19

Install exhaust side camshaft

Place camshaft in camshaft carrier with pulley guide pin facing upwards.


Press camshaft into place with press tool 5021 (using rear bearing cap as guide).

Install bearing caps in original order.

Apply liquid sealing compound to joint face between camshaft carrier and front bearing cap (No. 6).

Install bearing cap nuts in stages.

Remove press tool 5021 and install centre bearing cap (8).



K20

Install intake side camshaft

Place camshaft in camshaft carrier with pulley guide pin facing upwards.

N.B. Turn distributor shaft to align driver with markings on distributor housing.

Fit housing and rotor shaft with **new** O-rings.

Press camshaft into position with press tool 5021 (using rear bearing cap as guide).


Install bearing caps in original order.

Apply liquid sealing compound to joint faces between camshaft carrier and front and rear bearing caps (Nos. 1 and 5).

Install bearing cap nuts in stages.

Remove press tool 5021 and install centre bearing cap (8).

Install camshaft carrier centre nut.




K21

Tighten bearing cap nuts and centre nut

Tighten to 20 Nm (15 ft.lb).

K22




Refit distributor

Reconnect high-tension lead between distributor cap and ignition coil.

Remove paper in camshaft carrier openings.

N.B. Replace ignition lead clip beside left-hand bolt.

K23




Seal front and rear camshaft bearing caps

Use silicone sealer.

Apply bead of sealer to angle between cap and joint face.

K24



Install new gaskets and replace valve cover


Inspect rubber seal behind camshaft **on exhaust side**.

Position spark plug well gasket with arrow pointing to No. 1 cylinder and marking facing upwards.

Shape outer gasket to fit camshaft bearing caps.

Place gasket in position and replace valve cover.


N.B. Remember to connect earth lead to distributor.



K25

Install:

- ignition leads (in correct firing order)
- ignition lead cover plate



K26


Fit camshaft front oil seals

Fit seals as described in operations F12-24.

N.B. Install new oil filter and fill engine with fresh oil of correct grade.

Caution! Some noise may be heard from tappets when engine is first started. However, this will disappear as tappets are filled with oil.
Engine **must not** be run at speed higher than **3000 r/min** while tappet noise is present.

L. Hydraulic tappets, inspection



If noise is heard from tappets:


Check tappets for 'spongy' feeling. No play is permissible between camshafts and tappets.

Flush engine

Change engine oil and filter.
Run engine for approx. 10 minutes.
Drain oil and remove filter.
Fit new filter and fill engine with fresh oil of correct grade.

Immediately prior to above, run engine at **2000-3000 r/min** for approx. **15 min** at correct oil level and pressure.

N.B. Engine must not be run at speed higher than **3000 r/min** if noise is heard from any of tappets.




Remove:

- ignition lead cover plate
- ignition leads from plugs


N.B. Always grip ignition leads by **caps** when removing to avoid damage to leads.

L1



Remove valve cover

L2




L3

Turn engine to TDC (ignition) in No. 1 cylinder

Cam pairs on intake/exhaust sides of No. 1 cylinder should be facing away from tappets.

N.B. Check is carried out with tappet in contact with **base circle** of cam (i.e. cam profile must not be in contact with tappet).




L4

Check tappets

Depress tappets firmly with thumb or brass rod.

Check following tappets:

- No. 1 cylinder intake/exhaust
- No. 2 cylinder intake
- No. 3 cylinder exhaust




L3

Turn engine to TDC (ignition) in No. 4 cylinder

Check following tappets:

- No. 2 cylinder exhaust
- No. 3 cylinder intake
- No. 4 cylinder intake/exhaust



L6

Replace any tappet which feels spongy


Tappet replacement:

Remove as described in operations **K1-8** and **K10-15**.
Replace as described in operations **K17-26**.

If tappets are in satisfactory condition:

See operations **J3-6**.

M. Camshaft carrier/cylinder head joint, resealing




Remove camshafts as described in operations K1-14.

M1

Separate camshaft carrier from cylinder head

Remove four remaining nuts from central bolted joint. Detach carrier from head. Tap carrier **carefully** with plastic mallet if component is stuck to head.

Remove O-rings around spark plug wells.



M2

Clean camshaft carrier/bearing seats and cylinder head


Plug openings in cylinder head with paper.

Dissolve remains of sealing compound with solvent.

Carefully scrape joint surfaces clean with plastic putty knife or similar implement.

Blow camshaft carrier **completely** clean with compressed air.

Wipe surfaces with degreasing agent.



M3


Apply liquid sealing compound

Apply compound to joint between camshaft carrier and cylinder head, and to bearing cap joint faces (1, 5 and 6).

Apply compound with a short-haired roller.

N.B. Remove excess compound from oilways prior to reassembly.


144 981



M4

Install camshaft carrier


Fit new O-rings in grooves around spark plug wells.
Position camshaft carrier on cylinder head and replace nuts 1, 2, 4 and 5 in central bolted joint.
Plug openings around spark plug wells with paper.



M5

Insert tappets and install camshafts as described in operations K17-20

(Liquid sealing compound has already been applied to camshaft bearing caps.)



M6

Tighten five nuts on camshaft carrier and all bearing caps


Tighten five nuts in central bolted joint and on all bearing caps.

Tighten to **20 Nm (15 ft.lb)**.

Carry out operations **K22-26** and **F12-24**.


N. Cylinder head gasket, replacement

Special tool: 5098



N1

Disconnect battery earth lead



N2

Drain coolant


Remove heat shield over exhaust manifold.

(Only the two bottom bolts on the plate need be removed.)

Remove expansion tank cap.

Drain coolant through cock on right-hand side of cylinder block. Fit tube to cock to facilitate collection of coolant.

Remove tube and close drain cock on completion of drainage.




N3

Strip right-hand side of cylinder head

Unbolt exhaust pipe from bracket.

Remove manifold nuts.

Detach manifold from cylinder block.



N4

Strip left-hand side of cylinder head


Remove support under intake manifold. Remove bottom bolt in cylinder block.

Detach and tie up manifold in suitable manner.

Disconnect temperature sensor connectors.

Disconnect heating hose under No. 3 and 4 cylinder intake branches.


Disconnect upper coolant hose at thermostat.



N5

Strip front and top of cylinder head

Carry out operations K1-14.




N6

Separate camshaft carrier from cylinder head

Remove four remaining nuts from central bolted joint.

Detach carrier from head. Tap carrier **carefully** with plastic mallet if component is stuck to head.

Remove O-rings around spark plug wells.



N7


Remove cylinder head

Wipe remaining oil from cylinder head.

Undo bolts in order shown, commencing at rear of engine.

Remove cylinder head and gasket.

Caution! Cylinder head is made of aluminium. Place on pair of clean wooden blocks or similar supports to avoid scoring.




N8

Clean and inspect all cylinder head joint faces

See operation M2 regarding cleaning of camshaft carrier and removal of sealing compound.

Clean and inspect cylinder block joint faces.




N9

Clean and inspect cylinder head bolts

Bolts should be replaced if any evidence of elongation is observed. (This will be indicated by thinning of mid-section.)

Bolts should be used no more than 5 times.


Replace bolts if in any doubt regarding above.



N10

Fit:


- new cylinder head gasket
- new O-ring seal for water pump



N11

Place cylinder head in position

Lower head carefully into position over guides, taking care to **avoid damaging gasket**.



N12

Tighten cylinder head bolts

Use protractor 5098.


Oil bolts.

Insert and tighten bolts in three stages, in order shown.

1 = 20 ± 2 Nm (15 ± 1.5 ft.lb)

2 = 40 ± 5 Nm (30 ± 4 ft.lb)

3 = Tighten through further $115^\circ \pm 10^\circ$.



N13

Install exhaust manifold


Use new gasket.

Place manifold in position. Replace and install nuts.

Bolt lifting lug in position between No. 2 and 3 exhaust branches.

Reattach front exhaust pipe to bracket.

Install bottom heat shield.




N14

Reconnect:

- temperature sensor connectors
- heating hose under No. 3 and 4 cylinder intake branches
- upper coolant hose to thermostat.

Caution! Note marking on hose. Clearance between hose and alternator drive belt must be at least 25 mm (1 in).



N15

Fill cooling system

Check system for leaks.


N16

Install intake manifold

Use new gasket.

Screw in bottom bolts a few turns.

Place intake manifold and lifting lugs in position. Tighten manifold from centre outwards.




N17

Reattach support under intake manifold

Install cable clip.

Check connections on and underneath manifold.




N18

Apply liquid sealing compound

Apply compound to joint between camshaft carrier and cylinder head, and to bearing cap joint faces (1, 5 and 6).

Apply compound with a short-haired roller.

N.B. Remove excess compound from oilways prior to reassembly.





N19

Install camshaft carrier

Fit new O-rings in grooves around spark plug wells.

Position carrier on cylinder head and replace nuts 1, 2, 4 and 5 in central bolted joint.






N20

Insert tappets and install camshafts as described in operations K17-20

(Liquid sealing compound has already been applied to camshaft bearing caps.)



N21

Tighten five nuts on camshaft carrier and all bearing caps

Tighten five nuts in central bolted joint and on all bearing caps.

Tighten to **20 Nm** (15 ft.lb).

Carry out operations **K22-26** and **F12-24**.

O. Cylinder head, dismantling/inspection

Special tools: 5219, 9802, 998 6052, 115 8280

Remove cylinder head as described in operations N1-7


Caution! Cylinder head is made of aluminium. Place on pair of clean wooden blocks or similar supports to avoid scoring.

Stripping

O1

Remove:

- spark plugs
- temperature sensors and pipe branches
- thermostat housing and thermostat




O2

Remove:

- valve collets, using clamp 998 6052
- upper spring collars
- valve springs
- valves


N.B. Ensure that **position** of every part removed is **identified**. Parts must not be interchanged.




O3

Remove:

- valve stem seals, using tool 5219
- lower spring collars






Cleaning and inspection

04

Clean:

- joint faces

Remove all traces of liquid sealing compound as described in operation M2.



05


Clean:

- combustion chambers
- intake/exhaust passages
- valve seats

Clean all valve seats.

Use tool 115 8280 with 7 mm dia. spindle and 45° cutter.


N.B. Ensure that tool is clear of combustion chamber walls.



06

Clean:

- spark plug mating threads
- valves
- valve springs and spring collars




07

Inspect cylinder head and dismantled components

Inspect head and components visually for signs of wear or damage.

O8



Measure cylinder head distortion

Use steel rule and feeler gauges.


Max. distortion without machining:

Longitudinal **0.50 mm** (0.0197 in)
 Lateral..... **0.25 mm** (0.0098 in)

Cylinder head must be replaced if distortion exceeds **1.0 mm** (0.0394 in) along length or **0.50 mm** (0.0197in) across width.

Height of cylinder head as new **103.50±0.5 mm**
 (4.0780±0.0197 in)

Minimum height after machining **102.5 mm**
 (4.0354 in)



O9

Measure valve guide wear

Use magnetic stand and dial gauge.

Lift valve **approx. 2–3 mm** (1/10 in) clear of seat when checking guide.

Clearance between new components:

Intake **0.03–0.06 mm** (0.0012–0.0024 in)
 Exhaust **0.04–0.07 mm** (0.0016–0.0028 in)

Max. clearance, used components:

Intake/exhaust **0.15 mm** (0.0059 in)

O10

Measure valve springs

Use spring tester **9802**.

Outside dia..... **26.2 mm** (1.0315 in)
 Inside dia. **18.1 mm** (0.7126 in)

Length, mm (in)

Load, N (lb)

L: 43.0 (1.69)


0 (0)

L1: 37.0 (1.46)

232±20 (52±4.5)


L2: 26.5 (1.04)

640±40 (144±9)



P. Cylinder head, overhaul

Special tools: 5222, 5363, 5364, 5365, 5366, 5367, 5368, 5369, 5373, 5377, 5378, 998 6045




Replacement of valve guides

P1

Mount cylinder head on fixture 5363

Adjust angle of inclination. Use locating holes No. 2 in fixture supports.

Clamp head to fixture. Use locating holes No. 2 on face.




Press out guides to be replaced. (Procedure is carried out in three stages)

P2

1. Free guide using drift 5364

Press slowly until drift bears against valve spring seat.




P3

2. Press out further using drift 5365

Press slowly until drift bears against valve spring seat.
Inspect upper section of guide bore.

P4



3. Place new valve guide on drift 5366 and press home

Press guide **slowly** into head until drift bears against valve spring seat.


Top of guide should project by **15±0.2 mm**
(0.5906±0.0079 in)

(Height is set by tool.)

Important! Press force must be at least **9000 N (2025 lb)**. If force is lower, guide must be removed and bore reamed out for fitting oversized guide.

P5

Remove cylinder head from fixture 5363




P6

Ream valve guides internally

Use reamer **5367**.

Ream from combustion chamber side.

N.B. Valve and seat must be ground in following installation of new guide.




Installing oversized valve guides


Important! Oversized guides must be fitted if press force is less than **9000 N (2025 lb)** or if guide bores in cylinder head are damaged.

P7

Press out guide using drift 5364

Press **slowly** until drift bears against valve spring seat.






P8


Press out further using drift 5365

Press slowly until drift bears against valve spring seat.



P9

Tap out guide using drift




P10

Ream out guide bore

Use reamer 5373.

Ream from combustion chamber side.



P11

Press in new guide using drift 5366


Top of guide should project by 15 ± 0.2 mm
(0.5906 ± 0.0079 in)

(Height is set by tool)

P12

Ream valve guides internally


Use reamer 5367.
Ream from combustion chamber side.



P13

Marking and dimensions of valve guides

Guide P/N 1 378 960-7
Standard: Outside dia. 12.0 mm (0.4724 in)
No. of grooves: 0
Guide P/N 1 378 958-1
Oversize: Outside dia. 12.1 mm (0.4764 in)
No. of grooves: 1




Replacement of valve seats

Important! Valve guide must always be replaced before replacing seat.

P14

Clean valve seat


Ensure that edge of seat is clearly visible.




P15

Remove valve seat

Use seat miller such as Mira P/N 998 6045-5.






Set milling cutter

Adjust cutter diameter to slightly less than **standard diameter** of seat recess in cylinder head.

Seat recess diameter	Intake	Exhaust
B 234 mm	35.9 ⁰ _{-0.05} (1.4144 in ⁰ _{-0.0020})	32.9 ⁰ _{-0.05} (1.2953 in ⁰ _{-0.0020})
B 204 mm	33.9 ⁰ _{-0.05} (1.3346 in ⁰ _{-0.0020})	30.9 ⁰ _{-0.05} (1.2165 in ⁰ _{-0.0020})

P16




Mill out valve seat

Blow clean with compressed air and inspect work continuously.

Remove remains of seat.

Seat will become loose just before max. milling depth is reached.


P17



Check valve seat recess

If damaged, recess must be machined for oversized valve seat.

P18



Measure seat recess diameter

Use internal micrometer.

Measure diameter all around circumference.

Seat should be **0.10-0.14 mm** (0.0039-0.0055 in) **larger** than recess in cylinder head.

If interference fit is less than above, recess must be milled out to take oversized seat.


P19

P20

Heat cylinder head

Heat head in oven at approx. 100°C (212°F).

N.B. Use heavy protective gloves when handling hot cylinder head.



P21

Cool valve seat

Place seat on appropriate drift:

B 234: Intake **5368** Exhaust **5369**
B 204: Intake **5377** Exhaust **5378**

Cool seat using dry ice or similar medium.

Use grease to hold seat to drift **5369**.

N.B. Use heavy protective gloves when handling chilled assembly tool.

P22

Insert valve seat in cylinder head

Operation **must be carried out quickly** to maintain maximum possible temperature difference between components.

Check that recess in cylinder head is clean.

Use hammer to tap seat fully home in recess.

Important! After replacing valve seat:
Seat face **must be milled**.
Seat and valve must be inspected and ground in as required.




P23


Valve seat dimensions

Since seats are not marked, dimensions must be measured.

Valve seat diameter

	Intake	Exhaust
B 234		
Standard ... mm	36.14 _{-0.016} (1.4228 in _{-0.0006})	33.14 _{-0.016} (1.3047 in _{-0.0006})
Oversize.... mm	36.64 _{-0.016} (1.4425 in _{-0.0006})	33.64 _{-0.016} (1.3244 in _{-0.0006})
B 204		
Standard ... mm	34.14 _{-0.016} (1.3441 in _{-0.0006})	31.14 _{-0.016} (1.2260 in _{-0.0006})
Oversize.... mm	34.64 _{-0.016} (1.3638 in _{-0.0006})	31.64 _{-0.016} (1.2457 in _{-0.0006})





Valve seats, machining

P24


Machine valve seats to following angles:

Seating face, intake/exhaust	45°
Relief angle, upper	15°
Relief angle, lower	70°

Valve seat width (a)

Intake.....	1.3–1.9 mm (0.051–0.075 in)
Exhaust.....	1.7–2.3 mm (0.067–0.091 in)

N.B. Check that milling cutter is clear of combustion chamber walls.




Machining of valves

P25

Machine-grind intake valves as follows:

Seating face angle.....	44.5°
Edge width, new valve.....	1.5 mm (0.059 in)
Min. edge width after grinding	1.2 mm (0.047 in)

Caution! Exhaust valves are stellite-coated and must be ground only with grinding paste.






Check valve stem height

- Use gauge 5222 and sliding callipers.
- Place camshaft carrier on cylinder head.
- Place gauge across camshaft bearing seats.
- Measure valve stem height by inserting callipers through hole in gauge.
- Valve stem height... **49.4±0.4 mm** (1.9449±0.0157 in)
- Max. machining allowance..... **0.4 mm** (0.0157 in)
- Length, new valve:
- Intake..... **122.45±0.2 mm** (4.8209±0.0079 in)
- Exhaust..... **122.25±0.2 mm** (4.8130±0.0079 in)

N.B. Correct valve stem height is essential to satisfactory operation of hydraulic tappets.

Q. Cylinder head, reassembly

Special tools: 5379, 998 6052



Installation of valves

Check that cylinder head and other components are clean.

Q1

Install:

- lower valve spring collars
- valves (in correct positions), oiling valve stems and guides
- intake and exhaust valve stem seals

Always use protective sleeve included in gasket set.

Place sleeve over valve stem.

Push down seal onto stem.

Remove protective sleeve.


Press home seal using assembly tool 5379.

Q2

Install:

- valve spring and upper spring collar, using clamp 998 6052
- collets

Q3




146 031

Install:

- thermostat and thermostat housing
- temperature sensors and pipe branch
- spark plugs (after balance shaft and timing belts have been fitted)

Q4



144 985

Install cylinder head

Install cylinder head as described in operations N9-21.


R. Balance shaft housing, replacement/overhaul

Special tools: 5006, 5033, 5115, 5186, 5362, 5376

Left-hand side..... R1-15

Right-hand side..... R16-35

Overhaul R36-49



144 870

Replacement of complete left-hand housing

R1

Remove timing and balance shaft belts

See operations C1-9.


R2

Remove balance shaft pulley


Use counterhold 5362.

R3

Remove air mass meter and inlet hose




146 360



146 361

Group 21 Engine

Balance shaft housing, replacement/overhaul




R4

Unbolt alternator and servo pump bracket

Undo bracket under intake manifold.

Tie bracket and assembly to wheel housing.

N.B. Protect wheel housing from scratches.




R5

Remove:

– bolts securing balance shaft housing to cylinder block.

Place container underneath joint (or place paper on front crossmember) to collect oil spillage from housing.



R6


Remove balance shaft housing

Use extractor 5376.

Position tool over rear mounting point.

Separate housing from cylinder block carefully. Use tool (e.g. 5196) simultaneously to prise loose **front mounting** to assist in removing housing.

Caution! If housing is to be reused, it must be removed **evenly** from front and rear mountings.



R7

Clean mounting points


Clean joint faces on cylinder block.

R8

Place O-rings in position

Place O-rings in grooves around housing oilways.

Fix O-rings in position by packing grooves with grease and lubricate housing joint faces with thin coating of grease.



146 366

R9

Install balance shaft housing


Ensure housing is replaced evenly on front and rear mountings. Max. permissible deviation between mounting faces with reference to block is 1 mm (0.04 in).

Tighten bolts **alternately** in **diagonal** pattern. Tighten each bolt by **max. 1/2** turn at a time.

Tighten bolts to **20 Nm** (15 ft.lb).

Slacken and retighten to **10 Nm** (7.5 ft.lb) and through a further **90°**.

N.B. Check that shaft **does not seize** in housing during tightening procedure.




146 367

R10

Tighten bolted joint between housing halves

Tighten to **8 Nm** (6 ft.lb).



146 368


R11

Install drive pulley


Use counterhold **5362**.

N.B. Slot in pulley hub must be aligned with guide pin on shaft end. **Shallower** side of pulley must face inwards.

Tighten centre bolt to **50 Nm** (37 ft.lb). Use tool **5362** as counterhold.



146 369




146 370

R12

Check axial clearance of balance shaft

Measure clearance using dial gauge mounted on magnetic stand.

Axial clearance **0.06–0.19 mm** (0.0024–0.0075 in)



146 371


R13

Install alternator and servo pump bracket

Check alternator and servo pump connections.

Reattach support under intake manifold.

N.B. Remember to attach cable tie (clamp) to bottom bolt on support.



146 372

R14

Install:

- air mass meter with air inlet hose and connections


N.B. Lower engine if unit has been raised to provide access to right-hand balance shaft housing.

R15


Install timing/balance shaft belts

See operations C12–37.

N.B. See table of tension values in specifications (page 11) if replacing existing timing/balance shaft belts.



144 899




144 870

Replacement of complete right-hand housing

R16

Remove timing/balance shaft belts

See operations C1-9.




146 373

R17

Remove drive pulley

Use counterhold 5362.




146 374

R18

Remove:


- balance shaft belt tensioner
- bolt between rear section of transmission mounting plate and balance shaft housing



146 361

R19


Remove air mass meter and air inlet hose



R20

Remove:

- air preheating hose from bottom heat shield under exhaust manifold
- nuts securing right-hand engine mounting to member




R21

Lift engine using right-hand lifting lug

Use lifting yoke **5006**, two support bars **5003**, and lifting hooks **5115** and **5186**.


N.B. Check clearance between master cylinder and intake manifold.



R22

Remove engine mounting

Remove complete mounting (including insulating pad and lower mounting plate) from block.




R23

Remove:

- bolts attaching balance shaft housing to cylinder block.

Place container underneath joint (or place paper on front crossmember) to collect oil spillage from housing.



R24


Remove balance shaft housing

Use extractor **5376**.

Position tool over rear mounting point.

Separate housing from cylinder block carefully. Use tool (e.g. 5196) simultaneously to prise loose **front mounting** to assist in removing housing.


Caution! If housing is to be reused, it must be removed **evenly** from front and rear mountings.



R25

Clean mounting points

Clean joint faces on cylinder block.




R26

Place O-rings in position

Place O-rings in grooves around housing oilways.

Fix O-rings in position by packing grooves with grease and lubricate housing joint faces with thin coating of grease.



R27

Install balance shaft housing


Ensure housing is aligned evenly on front and rear mountings. Max. permissible deviation between mounting faces with reference to block is **1 mm** (0.04 in).

Tighten bolts **alternately** in **diagonal** pattern. Tighten each bolt by **max.** 1/2 turn at a time.

Tighten bolts to **20 Nm** (15 ft.lb).

Slacken and retighten to **10 Nm** (7.5 ft.lb) and through a further **90°**.


N.B. Check that shaft **does not seize** in housing during tightening procedure.



R28

Tighten bolted joint between housing halves

Tighten to **8 Nm** (6 ft.lb).




R29

Install drive pulley

Use counterhold **5362**.

N.B. Slot in pulley hub must be aligned with guide pin on shaft end. **Shallower** side of pulley must face inwards.

Tighten centre bolt to **50 Nm** (37 ft.lb). Use tool **5362** as counterhold.




R30

Check axial clearance of balance shaft

Measure clearance using dial gauge mounted on magnetic stand.

Axial clearance **0.06–0.19 mm** (0.0024–0.0075 in)



R31

Install engine mounting


Install mounting complete with insulating pad and lower mounting plate.

R32

Lower engine into position on front crossmember


Use studs on member to guide lower engine mounting plate into position.

Remove lifting attachments.



R33


Install air mass meter with air inlet hose and connections



R34

Retighten:

- engine mounting
- air preheating hose





R35

Install:

- bolt in rear section of transmission mounting plate
- belt tensioner, tightening bolt so that pulley is movable when belt is placed in position
- timing/balance shaft belts as described in operations C12-37.

N.B. See table of tension values in specifications (page 11) if replacing existing timing/balance shaft belts.





Balance shaft housing, reconditioning

Remove balance shaft housing


Remove **left-hand** housing as described in operations R1–7.

Remove **right-hand** housing as described in operations R16–25.

Balance shaft housing, dismantling

R36

Remove bolts in housing joint




R37

Separate housing halves

Prise housing halves apart using heavy screwdriver inserted between projections at four points around joint.


N.B. Prise **carefully** at each point in turn, ensuring that deviation in parallelism between joint faces does not exceed **1 mm (0.0040 in)**.



R38

Lift out balance shaft


Remove front sealing ring from shaft.



R39

Remove sealing plate

Remove O-ring from groove in sealing plate.




146 394

R40

Remove bearing shells

Remove rear bearing shells from housing halves.



146 395


R41

Clean housing and other components

Use solvent to remove remains of liquid sealing compound.

Carefully scrape surfaces clean using plastic putty knife.


Wipe components with degreasing agent and blow clean thoroughly with compressed air.




146 396

R42

Inspect joint and bearing surfaces



146 397




Balance shaft housing, assembly

R43

Install rear bearing shells

Position shells flush with joint surfaces.




R44

Apply liquid sealing compound

Apply compound to housing half not fitted with guide sleeves.

N.B. Excess sealing compound **must** be removed from oil-ways and bearing surfaces prior to assembly.




R45

Lubricate balance shaft bearings

Oil bearing shells in both housing halves.

N.B. Lubricant **must not** be allowed to come in contact with liquid sealing compound or joint faces.



R46

Place balance shaft in position


Place shaft in housing half to which liquid sealing compound has been applied.

R47

Install rear sealing plate

Fit **new** O-ring in groove in sealing plate.

Position seal in housing half with balance shaft.




R48

Reassemble balance shaft housing

Tighten bolted joint all around to ensure halves are pulled together evenly.

Tighten to **5 Nm** (3.7 ft.lb).

Ensure that shaft does not seize in housing.




R49

Install balance shaft housing

Install **left-hand** housing as described in operations R8-15.


Install **right-hand** housing as described in operations R26-35.

N.B. Balance shaft front seal is replaced as described in E6 when housing has been tightened in position as per operation R11 or R27.



S. Engine mountings, replacement


Special tools: 5006, 5033, 5115, 5186



Left-hand side

S1

Disconnect battery earth lead



S2

Remove:

- air mass meter and air inlet hose
- engine mounting bottom nut

N.B. Undo bottom nut from underneath on cars equipped with an AC compressor. Remove front splashguard.


5006

S3


Raise engine using left front lifting lug

Use lifting yoke 5006, two support bars 5033 and lifting hook 5115.

N.B. Ensure that fan blades are not damaged by contact with shroud.




S4



Remove:

- three bolts securing mounting to cylinder block
- mounting complete with insulating block


S5



Install:

- mounting with new insulating block
- cable clip and support at top bolt

S6




Lower engine into position and remove lifting attachments


Guide bottom bolt of mounting into bracket.

S7


Install engine mounting bottom nut

N.B. Tighten nut from underneath on cars equipped with an AC compressor. Install front splashguard.






S8
Install air mass meter with air inlet hose and connections




S9
Check operation

Test run engine.



Right-hand side

S10
Disconnect battery earth lead




S11
Disconnect/remove:

- air preheating hose from bottom heat shield
- four nuts securing bottom mounting plate

S12


Disconnect air inlet hose from throttle housing



S13

Raise engine using right front lifting lug


Use lifting yoke 5006, two support bars 5033, and lifting hooks 5115 and 5186.



N.B. Check clearance between master cylinder and inlet manifold, and between fan blades and shroud.


S14


Remove engine mounting and bottom mounting plate



S15

Install new engine mounting and bottom mounting plate






S16

Lower engine into position and remove lifting attachments


Guide upper mounting plate and mounting into position.



S17

Install/reconnect:


- four nuts securing engine mounting and bottom mounting plate
- air preheating hose to bottom heat shield



S18

Reconnect air inlet hose to throttle housing

Check other connections to air inlet hose.



S19


Check operation

Reconnect battery earth lead.

Test run engine.

T. Engine, removal


Special tools: 2810, 5006, 5033, 5035, 5115, 5186, 5244



Procedure for cars with manual gearboxes

Removal of automatic gearbox is described in procedure AD.

Caution! Since operations T29-30 are carried out with engine freely suspended, ensure that lifting equipment is securely attached and in perfect condition.




T1

Disconnect battery leads

Disconnect

- earth (negative) lead
- leads connected to terminal lug of battery positive lead
- battery positive lead
- earth lead connection to top of side member
- bolted connection to exhaust manifold front bracket




T2

Support engine at rear

Use two support bars 5033, lifting yoke 5006, and lifting hooks 5115 and 5186.


Raise engine using rear left lifting lug.

Cut cable tie and position wiring clear of lifting lug.




Drain engine oil
Remove splashguard under engine
Cut air preheating hose ties.

T3



Release battery leads from body
Undo clips on front crossmember and right-hand side member.
Work wiring free of anti-roll bar.


T4



Release front left-hand engine mounting
Undo bottom nut.

T5

N.B. On cars equipped with AC: Remove AC compressor from mounting bracket.




Remove clutch slave cylinder
Remove cylinder circlip.
Withdraw cylinder carefully from location in housing.

T6

N.B. Rubber boot retains plunger in cylinder. Secure boot with circlip.


T7



Remove propeller shaft

Use socket 5244.
Separate front and rear universal joints.
Unbolt centre support bearing from member.
Withdraw propeller shaft backwards.


T8



Free gearbox wiring

Cut rear tie at gear lever mounting.
Separate wiring connectors.


T9



Release gear lever


Undo lever locking bolt.
Remove pivot pin between lever and gear selector rod.
Remove circlip from lever sleeve under mounting.
Push up lever.
Remove bearing bushings and O-ring.

T10



Undo bolted joint at front of catalytic converter


Release oxygen sensor lead from rear clip.



T11

Remove front exhaust pipe


Remove nuts in bolted joint with exhaust manifold.



T12

Remove gearbox support member

Remove gearbox bump stop nut and bolts attaching member to side members.



T13

Support gearbox on jack

Remove lifting attachments (5006, 5033, 5115 and 5186).




T14

Remove:

- top heat shield from exhaust manifold
- air preheating hose from bottom heat shield
- top nut on right-hand engine mounting

T15



Drain coolant


Remove expansion tank cap.

Drain coolant through cock on right-hand side of cylinder block.

Fit tube to cock to facilitate collection of coolant.

Remove tube and **close** drain cock on completion of drainage.

T16



Remove distributor cap

Remove high-tension supply lead from cap.

Remove ignition leads from cap.


Undo cap retaining screws (three).

Remove cap and distributor rotor.

Disconnect braided earth lead from engine.

N.B. Always grip ignition leads by **caps** when removing to avoid damage to leads.

T17




Release wiring harness at rear of engine

Open cable clips on bulkhead.

Separate wiring connectors at right-hand suspension strut housing and disconnect lead to terminal 1 on ignition coil.

T18




Undo hose connections at left-hand side of bulkhead

Disconnect heater hoses from pipe branches on bulkhead.

Open union between hose and pipe on fuel line.

Soak up fuel spillage with paper.


N.B. Seal open ends to prevent entry of dirt into fuel line.



T19

Disconnect speed pick-up lead


Open cable clip on bulkhead.
Open connector.



T20

Remove air mass meter and air inlet hose


Disconnect air mass meter wiring and hoses connected to inlet hose.



T21

Release throttle cable from pulley


Release locking clip on cable tensioner.
Unhook cable from pulley.



T22

Remove:

- brake servo vacuum hose from branch on intake manifold
- EVAP valve hose from branch on bottom of intake manifold
- return line from fuel distribution pipe




146 214

T23

Release engine wiring harness on left-hand side

Cut steering servo hose and wiring harness ties.
 Undo cable clip at left-hand wheel housing.
 Unhook servo reservoir from mounting bracket.
 Open cable clip at connectors.
 Separate wiring connectors at servo reservoir.




146 215

T24

Disconnect knock sensor lead

Open cable clips on left-hand suspension strut housing.
 Separate connectors at diagnostic unit.
 Work wiring free of servo hoses.




146 216

T25

Remove coolant hoses

Disconnect upper coolant hose at thermostat housing.
 Disconnect lower coolant hose at water pump.




146 217

T26

Remove:

- alternator, servo pump and (if fitted) AC compressor drive belts
- radiator fan and drive pulley
- fan shroud



T27

Remove servo pump


Remove pump from mounting bracket.

Place pump on left-hand wheel housing.

Use paper or other material to protect wheel housing from scratches.

On cars with AC, Tie compressor out of way.

N.B. Do not undo AC or servo unit hose connections.




T28

Attach lifting gear

Use bracket **5035** with side arm bolted to hole configuration No. 2.

Attach tool first to front left lifting lug, hook fast at rear and finally attach to side lifting lug.

N.B. Position wiring harnesses so as to **avoid damage** when lifting.




T29

Lift engine

Use lifting tool **2810**.

Adjust lifting yoke to ensure engine is balanced.

Remove jack under gearbox.



T30


Lift out engine and gearbox

Adjust angle of lift throughout operation.

N.B. Carefully check that drive unit is free of radiator, body and extra equipment (if any).

U. Engine replacement, transfer of components

Special tools: 2520, 2820, 5035, 5111, 5112, 5927



146 283


The following procedure assumes that the engine has been removed as described in operations T1-30.

Procedure applies to cars with manual gearboxes

Removal of automatic gearbox is described in procedure AD.

Caution! Since operations U1-4 and U30-34 are carried out with engine freely suspended, ensure that lifting equipment is **securely attached** and in **perfect condition**.

Stripping of engine




146 222

U1

Remove reinforcing bracket

Unbolt bracket between engine and gearbox.




146 223

U2

Remove gearbox

Detach gearbox from engine by separating flywheel housing from cylinder block.

Inspect clutch release bearing and seal on input shaft.




146 224

U3

Remove pressure plate and clutch plate

Use gear sector **5112**. Undo pressure plate joint evenly all round.

Inspect clutch components.



146 225


U4

Remove speed pick-up and flywheel

Use gear sector **5112**.

Remove flywheel.

N.B. Speed pick-up must be removed before flywheel.




146 226

U5

Mount engine in stand

Use stand **2520** and fixture **5297**.

Remove lifting tool **2810** and bracket **5035**.




146 227

U6

Remove starter motor

Disconnect starter motor leads.

U7




Remove oil trap

Disconnect oil trap hoses.

Remove trap and withdraw wiring harness between balance shaft housing and trap.


U8



Disconnect:

- knock sensor
- temperature sensors under intake manifold.


U9



Disconnect alternator leads

Remove protective cap over terminal B+.


U10



Remove cable clip at left-hand engine mounting

Remove engine mounting.

Remove wiring harness bracket on transmission cover.




U11

Release wiring harness on right-hand side

Remove bracket under right-hand balance shaft and disconnect earth lead at cylinder block.

Remove oil pressure switch connector.

Undo cable clip at bottom front of transmission cover.




U12

Remove alternator

Remove auxiliary mounting bracket from cylinder block.

On cars equipped with AC: Remove compressor mounting bracket.




U13

Remove intake manifold

Remove bolts securing manifold to cylinder head.

Remove complete manifold and engine wiring harness.




U14

Remove oil trap

Remove O-rings between oil trap and cylinder block.


U15



Remove:


- distributor housing
- heater hoses
- ignition lead cover plate
- ignition leads

U16



Remove:

- exhaust manifold and lower heat shield
- right-hand engine mounting




Remounting components on replacement engine

Use:

- new gaskets and seals
- new flywheel bolts
- new **flame trap**

Inspect and renew as required:

- hoses and clips
- auxiliary drive belts
- clutch components




U17

Install oil trap in cylinder block

Use new O-rings.

ProCarManuals.com




U18

Install intake manifold assembly and wiring harness

Use **new** gasket at joint with cylinder head.

Tighten bottom bolts a few turns.

Fit intake manifold and lifting lugs. Tighten mounting bolts from centre outwards.




U19

Mount oil trap

Position engine wiring harness between oil trap and balance shaft housing.

Insert oil trap and tighten in position.


Install flame trap and hoses, and connect to branch on bottom of intake manifold.



U20

Reconnect connectors under intake manifold

Connect knock sensor and temperature sensors.




U21

Install left-hand engine mounting

Reattach cable clip at upper bolt of engine mounting/intake manifold support.

Install wiring harness bracket and cable clip on transmission cover.




U22

Install alternator and auxiliary mounting bracket

Reconnect alternator leads.

Replace protective cap over terminal B+.


On cars equipped with AC: Install compressor mounting bracket.



U23

Reconnect heater hoses

Connect heater hoses to cylinder head and to distribution manifold from water pump.




U24

Install distributor housing

Use new O-rings in housing and on rotor shaft.

N.B. Install ignition lead clip beside left-hand mounting bolt.




U25

Install wiring harness bracket under right-hand balance shaft

Connect earth lead to cylinder block and reconnect oil pressure switch.


Install pressure switch cable clip at front of transmission cover.



U26

Install right-hand engine mounting

Reattach upper bracket to cylinder block.




U27

Install exhaust manifold and bottom heat shield

Use new gasket in joint with cylinder head.

Attach lifting lug to centre stud.




146 249

U28

Turn crankshaft to TDC (ignition) in No. 1 cylinder

Align crankshaft pulley (vibration damper) marking with 0 mark on transmission cover.

Check that slot in distributor rotor shaft is at '10 o'clock' or that No. 1 cylinder exhaust cams are pointing upwards at approx. 60° to engine centre line.



146 250


U29

Lift engine from stand

Use attachment 5035 and lifting yoke 2810.

Position engine wiring harness to avoid risk of damage.

Caution! Since operations and U30–34 are carried out with engine freely suspended, ensure that lifting equipment is securely attached and in perfect condition.



146 251

U30

Install flywheel

Use gear sector 5112.


At TDC, mark on flywheel should be positioned between the two lower bolt holes on right-hand side of cylinder block.

Caution! If flywheel is not marked, new position is indicated by pins A and B at rear.

Pins A and B are located respectively approx. 15° on either side of marking position.

Use new bolts and thread locking compound.

Tighten to 70 Nm (52 ft.lb).



146 252


U31

Install clutch plate and pressure plate

Use centering tool 5111 and gear sector 5112.

Tighten pressure plate in stages. Work around circumference tightening diagonally-opposite bolts alternately.

Remove centering tool and gear sector.



146 253


U32

Install speed pick-up

Use thread locking compound.

Tighten to 5 Nm (3.5 ft.lb).

Check that cylinder block guide pins are in position.



146 254


U33

Install gearbox and starter motor

Lubricate input shaft splines with thin coating of grease.

Reconnect starter motor leads.

N.B. Remember to install exhaust manifold front mounting bracket.




146 222

U34

Install reinforcing bracket

Tighten bracket in stages.

Attach bracket first to flywheel housing and then to cylinder block.



146 284


U35

Install engine in car

Installation is carried out as described in operations V1-31.

V. Engine, installation


Special tools: 2810, 5006, 5033, 5035, 5115, 5186, 5244



Procedure applies to cars with manual gearboxes

Removal of automatic gearbox is described in procedure AD.

Caution! Since procedure is carried out with engine freely suspended, ensure that lifting equipment is **securely attached** and in **perfect condition**.




V1

Attach lifting equipment

Use attachment **5035** with side arm bolted to hole configuration No. 2.

Attach tool first to front left lifting lug, hook in position at rear and finally attach to side lifting lug.

N.B. Position wiring harnesses so as to **avoid damage** when lifting.



V2


Lower engine and gearbox into position

Use lifting tool **2810**.

Adjust lifting yoke to ensure engine is balanced.

Adjust angle of lift throughout operation.


N.B. **Carefully** check that drive unit is free of radiator, body and extra equipment (if any).



V3

Guide front engine mountings into position


Guide mountings into brackets on front crossmember.



V4

Support gearbox on jack

Remove lifting yoke 2810 and attachment 5035.




V5

Raise rear of engine slightly

Use two support bars 5033, lifting yoke 5006, lifting hooks 5115 and 5186.

Lift engine using rear left lifting lug.

Remove jack under gearbox.



V6

Replace gearbox support member


Tighten bolts securing member to side members.
Tighten bump stop nut.

Ensure that oxygen sensor lead is positioned above member.

V7

Remove lifting attachments

Remove items 5006, 5033, 5115 and 5186.




V8

Install front exhaust pipe

Use **new** gasket in joint between pipe and exhaust manifold.

Secure pipe to exhaust manifold and to flanged joint at front of catalytic converter.

Secure **oxygen sensor** lead in clip.




V9


Install gear lever

Insert gear lever sleeve in mounting.

Install:

- bearing bushings and O-ring on gear selector rod; install circlip on rod
- selector rod/gear lever pivot pin; tighten set screw
- circlip on gear lever sleeve; pull selector rod downwards when fitting circlip






V10

Reconnect gearbox wiring

Reconnect wiring connectors and replace cable tie.




V11

Install propeller shaft

Use socket 5244.

Tighten front and rear universal joints.


Reattach intermediate bearing to member.



V12

Install clutch slave cylinder

Secure cylinder with circlip.




V13

Tighten left-hand engine mounting

On cars equipped with AC: Replace compressor.

V14




Reconnect battery leads

Run wiring between anti-roll bar support and front crossmember.

Install cable clips on crossmember and right-hand side member.

Install splashguard under engine.


V15



Install/reconnect:

- earth lead to top of right-hand side member
- right-hand engine mounting nut
- upper heat shield
- air preheating hose on lower heat shield
- exhaust manifold front mounting bolt


V16



Reconnect:

- bottom coolant hose to coolant pump
- upper coolant hose to thermostat

Important! Note marking on upper hose. Clearance between hose and alternator belt **must** be at least 25 mm (1 in).



V17


Install servo pump

Mount pump on auxiliary equipment bracket.

Refit belt and adjust tension.

Tighten pump housing.


On cars equipped with AC: Refit twin drive belts.



V18

Install:

- cable ties under fan shroud
- fan shroud
- air preheating hose; tighten ties
- belt pulley and fan
- alternator drive belt; adjust belt tension and tighten alternator




V19

Reconnect rear wiring harness

Secure wiring in cable clips on bulkhead.

Reconnect connectors behind right-hand suspension strut tower and reconnect lead to terminal 1 on ignition coil.

Use cable tie to secure lead to rear left lifting lug.




V20

Install/reconnect:

- distributor rotor
- distributor cap
- high-tension lead between ignition coil and distributor cap
- ignition leads in correct firing order
- ignition lead cover plate
- braided earth lead to distributor


V21



Reconnect left-hand wiring harness

Attach cable clips to wheel housing.
Reconnect connectors at suspension strut tower.
Secure wiring in cable clips.
Install servo reservoir.


V22



Reconnect knock sensor lead

Reconnect connector at diagnostic unit.
Secure cable in clips around suspension strut tower.


V23



Reconnect speed pick-up lead


Reconnect connectors on bulkhead.
Secure lead in clip on bulkhead.

V24



Reconnect:


- brake servo vacuum hose to branch on intake manifold
 - EVAP valve hose to branch on intake manifold
 - return line to fuel distribution pipe
- Secure servo hoses and wiring harness with cable tie.



V25

Reconnect hoses to left-hand side of bulkhead


Reattach heater hoses to branches on bulkhead.
Reconnect union between pipe and hose on fuel line.



V26

Reattach throttle cable to pulley


Hook cable onto pulley.
Attach clip to cable tensioner.
Check stop functions and throttle switch operation.



V27

Install air mass meter, complete with air inlet hose and connections

N.B. Connect hose from oil trap under inlet hose.




V28

Fill engine with coolant

Use genuine **type C** Volvo coolant.
Approx. capacity **9 l** (9.5 US qt)
Set heater control in car to max. heat.
Check system for leaks.


V29



Fill engine with engine oil

Capacity excl. filter 3.5 l (3.7 US qt)
incl. filter 4.0 l (4.2 US qt)

V30



Reconnect battery leads

Reconnect positive lead, and lead between right-hand wheel housing and positive terminal.

Install protective cap on positive terminal.

Reconnect earth lead.


V31

Check operation

Start and run engine until thermostat opens.


Check and top up oil and coolant levels as required.

Important! Some noise may be heard from tappets when replacement engine is started for the first time. This will disappear as tappets are filled with oil.



W. Oil sump, gasket replacement


Special tools: 5006, 5003, 5115



Disconnect/remove:

- battery earth lead
- oil dipstick


W1



Remove air mass meter and air inlet hose

Loosen fan shroud.


W2



Remove front crossmember bolts

Remove bolts at both ends of crossmember.


W3



W4

Relieve weight on engine mountings by lifting at front


Use lifting yoke **5006**, two support bars **5033** and lifting hook **5115**.



W5

Undo right-hand engine mounting


Unbolt bottom mounting plate from front crossmember.



W6

Undo left-hand engine mounting

Unbolt upper mounting plate from cylinder block.




W7

Drain engine oil

Replace plug on completion of drainage, using new seal.


Tighten to **60 Nm (44 ft.lb)**.



W8

Remove:


- splashguard under engine
- bottom nut from left-hand engine mounting
- wiring harness bracket from transmission cover



W9

Separate steering shaft from steering gear


- Remove lower clamping bolt and loosen upper bolt.
- Mark position of splined joint.
- Slide driver up steering shaft.



W10

Remove:

- bump stop on front crossmember
 - reinforcing bracket between engine and gearbox
- Undo bolted joint at front of catalytic converter.




W11

Raise engine

- Check **clearance** to lifting tool 5006 and bulkhead. Ensure that wiring and hoses are not **strained**.
- Remove left-hand engine mounting.


W12



Remove oil sump

Remove all sump mounting bolts.
Lift off, turn and remove sump.
Remove gasket and clean joint faces.


W13



Install oil sump

Fit new gasket.
Position gasket with tab on starter motor side. Turn and lift sump into position.
Install all fasteners: Tighten to 11 Nm (8 ft.lb).


W14



Install reinforcing bracket


Tighten bracket in stages.
Attach bracket first to flywheel housing and then to cylinder block.
Install bump stop on front crossmember.

W15



Reattach front crossmember


Lift member into position against side members and insert bolts (tightening a few turns).



W16

Tighten front crossmember

Tighten to **95 Nm (70 ft.lb)**.




W17

Install left-hand engine mounting

Secure mounting plate to cylinder block.

N.B. Remember to replace cable clip on upper bolt.




W18

Lower engine into position

Guide engine mountings into position.

Remove lifting attachments.



W19

Tighten right-hand engine mounting


Secure mounting plate to front crossmember.

Check connection of air preheating hose.

W20

Tighten fan shroud


Adjust position of bottom bracket and tighten shroud to radiator.



W21

Tighten:

- left-hand engine mounting
- wiring harness bracket on transmission cover
- splashguard under engine
- bolted joint at front of catalytic converter



W22


Reassemble steering shaft and steering gear

Assemble splined joint as indicated by markings.

Insert and tighten bottom bolt. Tighten to 21 Nm (15.5 ft.lb).


Tighten upper bolt. Tighten to 21 Nm (15.5 ft.lb).



Install spring clips.



W23

Install air mass meter with air inlet hose and connections





W24

Fill engine with oil

Capacity excl. filter 3.5 l (3.7 US qt)
incl. filter 4.0 l (4.2 US qt)

W25


Check operation

- Reconnect battery earth lead.
- Check oil level.
- Start engine.
- Check operation and inspect for leaks.



X. Crankshaft assembly, dismantling

Special tools: 5006, 5021, 5033, 5115, 5199, 5267



When pistons, piston rings or bearings have been renewed due to wear:

It is imperative that engine be flushed clean before installing new components.

In most cases, damage to tappets and camshafts is due to engine oil contamination.


Flush engine

Change engine oil and filter.

Run engine for approx. 10 minutes.


Drain oil and remove filter.

Fit new filter and fill engine with fresh oil of correct grade (on completion of procedure).



X1

Disconnect battery earth lead



X2

Drain coolant


Remove heat shield over exhaust manifold.

(Only the two bottom bolts on the plate need be removed.)

Remove expansion tank cap.

Drain coolant through cock on right-hand side of cylinder block. Fit tube to cock to facilitate collection of coolant.


Remove tube and **close** drain cock on completion of drainage.



X3

Undo right-hand engine mounting


Disconnect air preheating hose from heat shield.
Unbolt bottom mounting plate at front crossmember.



X4

Strip right-hand side of cylinder head


Unbolt exhaust pipe from bracket.
Remove nuts holding manifold.
Detach manifold from cylinder block.



X5

Remove:

- air mass meter and air inlet hose
- oil dipstick




X6

Strip left-hand side of cylinder head

Remove support under intake manifold. Remove bottom bolt in cylinder block.
Detach and tie up manifold in suitable manner.
Disconnect temperature sensor connectors.
Disconnect heating hose under No. 3 and 4 cylinder intake branches.
Disconnect upper coolant hose at thermostat.


X7



Remove:

- alternator drive belt
- radiator fan and pulley
- upper (1) and lower (2) transmission covers

X8




Align camshaft/crankshaft markings

Turn engine to TDC position in No. 1 cylinder.

Check that markings on camshaft pulleys are aligned with those on transmission mounting plate.

X9



Slacken tensioner locknut


Remove protective rubber cap over tensioner.

Slacken locknut.

Compress tensioner spring.


Tighten tensioner locknut.

X10



Remove timing belt from crankshaft pulleys


Caution! Crankshaft and camshafts must **not** be rotated while timing belt is slack or has been removed.



X11

Remove timing belt idlers


Check roller surfaces and bearings.



X12

Remove camshaft pulleys

Use counterhold 5199.




X13

Remove/disconnect:

- upper section of transmission mounting plate
- ignition lead cover plate
- ignition leads at plugs and distributor cap
- high-tension lead at distributor cap

N.B. Always grip ignition leads by caps when removing to avoid damage to leads.



X14


Remove valve cover and gaskets

Remove remains of gaskets and clean joint faces.

X15

Detach distributor housing from crankshaft carrier

N.B. Remove ignition lead clip beside left-hand bolt.




X16

Remove camshaft centre bearing caps

Plug openings in camshaft carrier (around spark plug wells) with paper.

Remove camshaft centre bearing caps (No. 3 on intake side, No. 8 on exhaust side). Mark caps as required.

Remove third nut in central bolted joint between bearing caps.



X17

Remove exhaust side camshaft


Use press tool 5021. Place tool in No. 8 bearing cap position.

Clamp press tool on camshaft.

Remove remaining bearing cap nuts and caps (6, 7, 9 and 10).

Inspect bearing surfaces for signs of wear.

Remove press tool 5021 and lift out camshaft.



X18

Remove intake side camshaft


Use press tool 5021. Place tool in No. 3 bearing cap position.


Clamp press tool on camshaft.

Remove remaining bearing cap nuts and caps (1, 2, 4 and 5).

Inspect bearing surfaces for signs of wear.

Remove press tool 5021 and lift out camshaft together with distributor.






X19

Remove tappets from camshaft carrier

Magnet or suction cup may be used to facilitate tappet removal.

Inspect tappets for signs of wear.

N.B. Store tappets upside down to prevent drainage of oil. Ensure tappets are placed in order – they must not be interchanged.



X20


Separate camshaft carrier from cylinder head

Remove four remaining nuts from central bolted joint.

Detach carrier from head. Tap carrier **carefully** with plastic mallet if component is stuck to head.

Remove O-rings around spark plug wells.

ProCarManuals.com




X21

Clean/inspect camshaft carrier

Clean carrier and inspect camshaft bearing and tappet bores for signs of wear or damage.

(Check axial clearance of camshafts as described in operation K16.)



X22

Remove cylinder head

Wipe remaining oil from cylinder head.

Undo bolts in order shown, commencing at rear of engine.

Remove cylinder head and gasket.


Caution! Cylinder head is made of aluminium. Place on pair of clean wooden blocks or similar supports to avoid scoring.

X23

Clean and inspect all cylinder head joint faces

See operation **M2** regarding cleaning of camshaft carrier and removal of sealing compound.

Clean and inspect cylinder block joint faces.



X24


Clean and inspect cylinder head bolts

Bolts should be replaced if any evidence of elongation is observed.

(This will be indicated by thinning of mid-section.)

Bolts should be used no more than **5 times**.

Replace bolts if in any doubt regarding above.




X25

Relieve load on engine mountings

Use lifting yoke **5006**, two support bars **5033**, lifting hook **5115** and lifting lug **5267**.

Attach lifting lug **5267** to upper mounting bolt of alternator bracket.





X26

Drain engine oil

Install plug on completion of drainage, using **new** seal.

Tighten to **60 Nm (44 ft.lb)**.






X27

Remove:


- splashguard under engine
- wiring harness bracket and cable clip on left-hand side of transmission casing
- left-hand engine mounting; remove nut under mounting and bolts attaching mounting to block



X28

Raise engine

N.B. Ensure that wiring and hoses are not strained. Check clearance between drive unit and other equipment.



X29

Remove reinforcing bracket

Remove bracket between cylinder block and flywheel housing.


Remove bump stop on front crossmember.



X30

Remove oil sump


Lower sump and draw straight backwards.



X31

Remove crankshaft bearing caps

Check markings on bearing caps and crankshaft.
Mark as required.



X32

Remove pistons from cylinder block

Polish bores to remove shoulders caused by piston reversal.

Press out pistons **carefully** from underneath (until ring friction is released).

Lift out pistons and connecting rods.

N.B. Press connecting rods with brass or wooden implement to **avoid damage** to bearing and contact surfaces.

Y. Crankshaft assembly, inspection/cleaning


Special tools: 9639, 9678, 9701, 9702, 9704, 998 6052

Cylinder bores and crankshaft

Y1

Wipe cylinder bores clean

Cover crankshaft with paper to prevent dirt from entering oilways.




Y2

Measure cylinder bores

Use inside dial gauge 9639 (50-100 mm), micrometer 9704 (75-100 mm) and a micrometer stand.

Set micrometer to bore diameter plus **max.** tolerance as marked on cylinder block.

Calibrate dial gauge using micrometer.




Y3

Measure wear


Check for **maximum wear** at right-angles to centre line of engine immediately below TDC.

Check for **minimum wear** in direction of centre line at BDC.

Remove engine and gearbox from car if measurements indicate that rebore is necessary. (See operations AA1-25.)



Y4



Y5



In the event of excessive piston clearance in cylinders marked C, D or E:

Hone bore to next largest oversize.

Use honing tool 9678.

Clean bore thoroughly after honing.

N.B. Turn crankshaft to ensure that honing tool is clear of crank throws.



129 452

Classification

Each cylinder is identified by a classification marking (C, D, E or G) punched in the block.

Oversized bores may be designated OS1 or OS2 as appropriate. This designation must be added after reboring.

Cylinder bore diameters

Standard	B 204	B 234
Bore marked C .	88.90 mm $^{+0.01}_0$ (3.5000 in $^{+0.0004}_0$)	96.00 mm $^{+0.01}_0$ (3.7795 in $^{+0.0004}_0$)
Bore marked D .	88.91 mm $^{+0.01}_0$ (3.5004 in $^{+0.0004}_0$)	96.01 mm $^{+0.01}_0$ (3.7799 in $^{+0.0004}_0$)
Bore marked E .	88.92 mm $^{+0.01}_0$ (3.5008 in $^{+0.0004}_0$)	96.02 mm $^{+0.01}_0$ (3.7803 in $^{+0.0004}_0$)
Bore marked G .	88.94 mm $^{+0.01}_0$ (3.5016 in $^{+0.0004}_0$)	96.04 mm $^{+0.01}_0$ (3.7811 in $^{+0.0004}_0$)

Oversize

Oversize 1.....	89.29 mm $^{+0.01}_0$ (3.5154 in)	96.30 mm $^{+0.01}_0$ (3.7913 in)
Oversize 2.....	89.67 mm $^{+0.01}_0$ (3.5303 in)	96.60 mm $^{+0.01}_0$ (3.8031 in)

Reboring should be carried out when wear reaches 0.01 mm (0.0039 in).


Y6

Measure crankshaft

Use micrometer 9701. Measure out-of-round and taper of crank pins. Use micrometer and measure at several points around circumference and along length.

Crank pins

Max. out-of-round.....	0.01 mm (0.0003 in)
Max. taper.....	0.01 mm (0.0003 in)
Diameter, standaard.....	49.00 mm $^{+0.005}_{-0.016}$ (1.9646 in $^{+0.0002}_{-0.0006}$)
undersize 1.....	48.75 mm $^{+0.005}_{-0.016}$ (1.9193 in $^{+0.0002}_{-0.0006}$)
undersize 2.....	45.50 mm $^{+0.005}_{-0.016}$ (1.7913 in $^{+0.0002}_{-0.0006}$)
Bearing seat width.....	25.00 ± 1.1 mm (0.9834 ± 0.0433 in)



146 409

Pistons and connecting rods

Y7

Clean and inspect pistons


Use piston ring pliers **998 5424**.

Remove piston rings.

Remove all carbon deposits. Clean piston ring grooves by scraping with a special scraping tool or part of an old ring ground to suit.

Inspect pistons for:

- damage
- wear
- cracking



146 410

Check piston ring side play

Use new rings.

Y8

Upper compression ring

B 204.....	0.040–0.072 mm (0.0016–0.0028 in)
B 234.....	0.060–0.092 mm (0.0024–0.0036 in)

Lower compression ring

B 204.....	0.030–0.062 mm (0.0012–0.0024 in)
B 234.....	0.040–0.072 mm (0.0016–0.0028 in)

Oil scraper ring

B 204.....	0.020–0.055 mm (0.0008–0.0022 in)
B 234.....	0.030–0.065 mm (0.0012–0.0026 in)

Replace piston if play is excessive.


Y9

Measure piston ring gap

Use feeler gauges.

Place ring in cylinder bore and use inverted piston to locate it in correct position for measurement.

Piston ring gap is measured with crown of inverted piston **15 mm**(0.6 in) from bottom of cylinder.




129 520

Upper and lower compression rings

B 204.....	0.30–0.50 mm (0.012–0.020 in)
B 234.....	0.30–0.55 mm (0.012–0.022 in)

Oil scraper ring

B 204.....	0.25–0.50 mm (0.010–0.020 in)
B 234.....	0.30–0.60 mm (0.012–0.024 in)




137 551 Y12

Check con rod/piston side clearance

Use feeler gauges.

Specified con rod/piston axial clearance for B 234, B 204 **0.15-0.45 mm**
(0.0059-0.0177 in)



131 370

Measure piston diameter

Use micrometer **9704** and feeler gauges.

A = Total height of piston

B = Height from gudgeon pin centre to crown

C = Piston diameter to be measured at right-angles to gudgeon pin hole, at distance C from edge of skirt

D = Piston diameter

Enginetype	Dimensions, mm (in)		
	A	B	C
B 204	67.1 (2.64)	39.1 (1.54)	13.4 (0.53)
B 234	68.7 (2.70)	39.9 (1.57)	11.0 (0.43)

Piston diameter (D)

Standard	B 204	B 234
Pistons marked C*	88.88 mm ^{+0.01} / ₀ (3.4992 in ^{+0.0004} / ₀)	95.98 mm ^{+0.01} / ₀ (3.7787 in ^{+0.0004} / ₀)
Pistons marked D	88.89 mm ^{+0.01} / ₀ (3.4996 in ^{+0.0004} / ₀)	95.99 mm ^{+0.01} / ₀ (3.7791 in ^{+0.0004} / ₀)
Pistons marked E*	88.90 mm ^{+0.01} / ₀ (3.5000 in ^{+0.0004} / ₀)	96.00 mm ^{+0.01} / ₀ (3.7795 in ^{+0.0004} / ₀)
Pistons marked G*	88.91 mm ^{+0.01} / ₀ (3.5004 in ^{+0.0004} / ₀)	96.02 mm ^{+0.01} / ₀ (3.7803 in ^{+0.0004} / ₀)

* Production only (non-stocked)


Oversize	B 204	B 234
Oversize 1	89.27 mm ^{+0.01} / ₀ (3.5146 in ^{+0.0004} / ₀)	96.28 mm ^{+0.01} / ₀ (3.7906 in ^{+0.0004} / ₀)
Oversize 2	89.65 mm ^{+0.01} / ₀ (3.5295 in ^{+0.0004} / ₀)	96.58 mm ^{+0.01} / ₀ (3.8024 in ^{+0.0004} / ₀)

Max. difference in weight between pistons in same engine..... **14 g** (0.5 oz)

Calculate piston clearance


Example:

Cylinder bore, measured diameter	Min. 96.02 mm (3.7803 in)	Max. 96.03 mm (3.7807 in)
Less piston diameter as measured.....	-96.01 mm (3.7799 in)	-96.00 mm (3.7795 in)
Piston clearance	0.010 mm (0.0004 in)	0.030 mm (0.0012 in)
Specified piston clearance for B 234, B 204.....	0.010 mm (0.0004 in)	0.030 mm (0.0012 in)



146 411

Y13




146 412

Separate con rods and pistons

Before separating, check that each piston and con rod is marked. Mark as required.

Carefully prise out locking circlip with a screwdriver. Press out gudgeon pin by hand.

Y14




146 413

Clean and inspect con rods, bearing caps and bolts

Check for:

- damage
- wear
- cracks

Y15




141 327

Check fit of gudgeon pins in pistons

No play is permissible. Gudgeon pin should slide through hole without play when pressed gently with thumb.

Replace piston if play is present.

Y16



141 326


Check fit of gudgeon pins in con rods

Gudgeon pin should slide through hole without noticeable play when pressed gently with thumb.

If play is excessive, measure gudgeon pin and fit new con rod bushing, if necessary. Use micrometer **9701**.

Specified gudgeon pin diameter for
B 204, B 234... **23.00 mm** $\begin{matrix} 0 \\ -0.006 \end{matrix}$ (0.9055 in $\begin{matrix} 0 \\ -0.0002 \end{matrix}$)

Y17



146 414

Check big end bearing seats


Inspect bearing shells visually.
If in doubt, measure out-of-round.
Use inside micrometer **9639**.

Tighten bearing cap on con rod as indicated by markings.

Bearing seat diameter **52.00 mm** $^{+0.01}_0$ (2.9472 in $^{+0.0004}_0$)

Max. permissible out-of-round **0.03 mm** (0.0012 in)

Y18




116 220

Check con rod in alignment gauge

Check for straightness and twisting.

Important! Ensure that clamping surface of fork is round and free of burrs.
Release and tighten expander at big end between each alignment check.

Y19



146 415


Check length of con rod bearing bolts

Use sliding callipers.

Max. length **55 mm** (2.1654 in)

Con rod bushing replacement

Y20



141 328

Replacing con rod bushing


Press out bushing

Use drift **5309**.

Position drift correctly with short end downwards.

Use **2413** as counterhold.

Y21



Press in new bushing


Use drift 5309.

Position drift correctly with long end downwards.

Press drift down fully.

Important! Ensure that hole in bushing is aligned with oil-way in con rod.

Y22



Check fit of gudgeon pin in new bushing

Gudgeon pin should slide through hole without noticeable play when pressed gently with thumb.

Adjust bushing as required.

Z. Crankshaft assembly, reassembly

Special tools: 5006, 5021, 5025, 5033, 5098, 5115, 5199, 5267, 115 8221, 998 5424, 998 8500

Pistons, con rods

Z1


Assemble piston and con rod

Arrow on piston crown must point towards front of engine.

Numerical designation on con rod must face towards right-hand side of block (oil filter side).

Ensure that con rods and pistons are assembled in matched pairs.

N.B. Fit gudgeon pin circlip, ensuring that circlip is fully seated in groove.




146 416

Z2

Install piston rings

Use piston ring pliers **998 5424**.

Turn rings so that gaps are positioned approx. 120° apart.



146 417


Z3

Place bearing shells in con rod big end and bearing cap


Wipe bearing seats clean.

Place shells in position in con rod and bearing cap.

Oil cylinder bore, piston and bearing shells.



146 418



Z4

Fit piston in bore


Use piston ring compressor **115 8281**.

When fitting piston, turn crankshaft so that corresponding crankshaft throw is pointing straight downwards.

Insert piston in bore.

Push down piston (using implement such as hammer handle).

N.B. Arrow on piston crown **must** point towards front.



Z5

Install bearing cap


Ensure that bearing shell remains in position.

Check markings. Markings on con rod must agree with those on bearing cap.

Oil bolts.

Tighten bolts in two stages:

1. **20 Nm** (15 ft.lb)
2. Tighten through further **90°**



Z6


Install oil sump

Clean inside of sump as required.

Use **new** sump gasket. Ensure that tab on gasket is pointing towards engine mounting.

Tighten sump in position.

Tighten bolts to **11 Nm** (8 ft.lb).



Z7


Install reinforcing bracket

Tighten bracket in stages.

Secure bracket first to flywheel housing and then to cylinder block.

Install bump stop on front crossmember.


Z8



Install left-hand engine mounting

Tighten **two** lower bolts in cylinder block.

Z9




Lower engine

Guide engine mountings into position.

Remove lifting gear (5006, 2 × 5033, 5115, 5267).

Z10




Tighten left-hand engine mounting

Install bottom nut.


Reattach wiring harness bracket and cable clip on transmission casing.

Z11



Install:


- **new** cylinder head gasket
- **new** water pump O-ring



Z12

Place cylinder head in position

Carefully lower head over guides, taking care to avoid damage to gasket.



Z13


Tighten cylinder head bolts

Use protractor 5098.

Oil bolts.

Insert and tighten bolts in three stages in order illustrated.

1. 20 ± 2 Nm (15 ± 1.5 ft.lb)
2. 40 ± 5 Nm (29.5 ± 3.5 ft.lb)
3. Tighten through further $115^\circ (\pm 10^\circ)$



Z14

Install exhaust manifold

Use new gasket.


Install manifold.

Attach lifting lug between No. 2 and 3 exhaust branches.

Connect front exhaust pipe to bracket.

Secure right-hand engine mounting to front cross-member.

Install heat shield.




Z15

Reconnect:

- temperature sensor connectors
- heater hose under No. 3 and 4 intake branches
- upper coolant hose to thermostat housing.


Important! Note marking on upper hose. Clearance between hose and alternator belt must be at least 25 mm (1 in).

Z16



Fill engine with coolant

Inspect for leaks.




Z17

Install intake manifold

Use **new** gasket.

Screw in bottom bolts a few turns.

Place manifold and lifting lugs in position. Tighten manifold from centre outwards.




Z18

Reattach support under intake manifold

Install cable clip.

Secure support to engine mounting.

Install air mass meter complete with air inlet hose and connections.




Z19

Apply liquid sealing compound

Apply compound to joint between camshaft carrier and cylinder head, and to bearing cap joint faces (1, 5 and 6).

Apply compound with a short-haired roller.

N.B. Remove excess compound from oilways prior to reassembly.




Z20

Install camshaft carrier

Fit new O-rings in grooves around spark plug wells.

Position carrier on cylinder head and install nuts 1, 2, 4 and 5 in central bolted joint.

Plug openings around spark plug wells with paper.




Z21

Oil

Oil bearings and sliding surfaces on camshaft carrier, bearing caps, camshafts and tappets.


ProCarManuals.com



Z22

Insert tappets

Tappets **must** be replaced in original order.




Z23

Turn engine to TDC in No. 1 cylinder

Check that TDC markings on vibration damper are aligned with zero marking on transmission cover.

Z24



Install exhaust side camshaft

Place camshaft in camshaft carrier with guide pin for pulley facing upwards.

Press down camshaft with press tool **5021** (using rear bearing cap as guide).

Install bearing caps in original order.

Apply liquid sealing compound to joint face between camshaft carrier and front bearing cap (No. 6).

Install bearing cap nuts in stages.

Remove press tool 5021 and replace centre bearing cap (8).

Z25

Install intake side camshaft

Place camshaft in camshaft carrier with guide pin for pulley facing upwards.

N.B. Turn distributor shaft to align driver with markings on the housing.

Fit housing and rotor spindle with **new** O-rings.

Press down camshaft with press tool **5021** (using rear bearing cap as guide).


Install bearing caps in original order.

Apply liquid sealing compound to joint faces between camshaft carrier and front and rear bearing caps (Nos. 1 and 5).

Install bearing cap nuts in stages.

Remove press tool 5021 and replace centre bearing cap (8).


Install camshaft carrier centre nut.




Z26

Tighten bearing cap nuts and centre nut

Tighten to **20 Nm** (15 ft.lb).






Z27

Remount distributor

Replace high-tension lead between distributor cap and ignition coil.

Remove paper in camshaft carrier openings.

N.B. Replace ignition lead clip beside left-hand bolt.




Z28

Apply sealer at front and rear camshaft bearing caps

Use silicone sealer.

Apply bead of sealer to angle between cap and joint face.



Z29

Install new gaskets and replace valve cover


Inspect rubber seal behind camshaft on exhaust side.

Position spark plug well gasket with arrow pointing to No. 1 cylinder and markings facing upwards.

Shape outer gasket to fit camshaft bearing caps.

Place gasket in position and replace valve cover.


N.B. Remember to connect earth lead to distributor.



Z30

Install:

- ignition leads (in correct firing order)
- ignition lead cover plate




Z31

Fill engine with oil

Use **new** oil filter.

Capacity, incl. filter **4.0 l** (4.2 US qt)

Insert dipstick and check oil level.



Z32


Fit camshaft front oil seals

Use assembly tool **5025**.

Grease seals.

Press seals home.

N.B. Camshafts must **not** be rotated while fitting seals.




Z33

Install transmission mounting plate

Adjust position of plate to avoid contact with camshafts.


Insert bolts between camshafts and under right-hand idler.



Z34

Install idlers

Tighten to **25 Nm** (18.5 ft.lb).



Install camshaft drive pulleys


Use counterhold **5199**.

Insert centre bolts and tighten to **50 Nm (37 ft.lb.)**.

Check that pulley markings are aligned with markings on transmission mounting plate.

N.B. Camshafts must not be allowed to rotate when replacing the centre bolts.

Z35




Install timing belt

Position belt so that double-line marking coincides with **top** marking on belt guide plate (at top of crankshaft).

Place belt on camshaft pulleys, ensuring that single-line markings coincide with pulley markings.

Place belt in position over **right-hand** and then over **left-hand** idler.


Z36



Check markings

Check that **all** markings coincide and that the engine is turned to TDC in No. 1 cylinder.

Z37



Slacken tensioner locknut


Z38

Z39

Turn crankshaft clockwise

Crankshaft pulleys should rotate one turn until markings again coincide with those on the transmission mounting plate.

N.B. Engine must **not** be rotated counterclockwise while belt is being tensioned.




Z40

Turn crankshaft further clockwise


Continue to turn crankshaft until pulley markings are $1\frac{1}{2}$ teeth past markings on housing.

N.B. Rotate crankshaft **smoothly**.



Z41


Tighten tensioner locknut




Z42

Install:

- lower transmission cover (2)
- radiator fan and pulley
- alternator drive belt
- battery earth lead






Z43

Check operation

Run engine until thermostat opens.

Stop engine.

Caution! Remember that transmission cover (1) is **not** replaced at this point.



Z44

Check belt tension

Use gauge 998 8500.


Rotate crankshaft to bring engine to TDC position in No. 1 cylinder.

Position gauge between exhaust camshaft pulley and idler.

Read gauge.

Belt tension **must** be within 5.1 ± 0.2 unit range (5.5 ± 0.2 units for new belt).

If reading is **outside** above range, carry out operations C26–C30.




Z45

Tighten tensioner locknut

Tighten to 50 Nm (37 ft.lb).

Install protective cap over locknut.

Install upper transmission cover (1).



Z46

Check operation


Test run engine.

Inspect for oil and coolant leaks.

Install splashguard under engine.

AA. Stripped engine, removal

Special tools: 2810, 5006, 5033, 5115, 5185, 5186, 5871




Assuming bores, crankshaft etc. have been found to be in need of overhaul:

Remove engine complete with gearbox.

Following procedure applies to engines with manual gearboxes.

Automatic gearboxes are removed as described in procedure AD.


Caution! Since operations AA24-25 are carried out with engine freely suspended, ensure that lifting equipment is **securely attached** and in **perfect condition**.



AA1

Install left-hand engine mounting and support under intake manifold

Tighten components to cylinder block.




AA2

Remove lifting attachments

Lower engine onto engine mountings.

Remove hook 5115 and lifting yoke 5006.




AA3

Release wiring harness at rear of engine

Open cable clips on bulkhead.


Separate connectors at right-hand suspension strut tower and disconnect lead to terminal 1 on ignition coil.



AA4

Disconnect:


- leads connected to terminal lug of battery positive lead
- battery positive lead
- earth lead connection to top of side member
- lower coolant hose from water pump



AA5

Remove fan shroud

Cut tie around air preheating hose.



AA6

Undo hose connections at left-hand side of bulkhead

Disconnect heater hoses from pipe branches on bulkhead.

Open union between hose and pipe on fuel line.


Soak up fuel spillage with paper.

N.B. Seal open ends to prevent entry of dirt into fuel line.

AA7

Disconnect speed pick-up lead


Open cable clip on bulkhead.
Open connector.



AA8

Release throttle cable from pulley


Release locking clip on cable tensioner.
Unhook cable from pulley.



AA9

Remove:


- brake servo vacuum hose from branch on intake manifold
- EVAP valve hose from branch on bottom of intake manifold
- return line from fuel distribution pipe




AA10

Free engine wiring harness on left-hand side

Cut steering servo hose and wiring harness ties.
Undo cable clip at left-hand wheel housing.
Unhook servo reservoir from mounting bracket.
Open cable clip at connectors.
Separate wiring connectors at servo reservoir.






AA11

Disconnect knock sensor lead

Open cable clips on left-hand suspension strut housing.

Separate connectors at diagnostic unit.

Work wiring free of servo hoses.



AA12

Remove servo pump


Remove drive belt.

Remove pump from mounting bracket.

Place pump on left-hand wheel housing.

Use paper or other material to protect wheel housing from scratches.

N.B. Do not open any hose connections.




AA13

Attach lifting lug 5871 to rear of cylinder block

Remove dipstick tube support.

Remove flat washer on bolt.

Tighten lifting lug.



AA14

Support engine at rear

Use two support bars 5033, lifting yoke 5006, and lifting hooks 5115 and 5186.

Lift engine using rear lifting lug 5871.



AA15

Disconnect battery leads from body

Undo clips on front crossmember and right-hand side member.

Work wiring free of anti-roll bar.

N.B. On cars equipped with AC: Unbolt AC compressor from mounting bracket.



Manual gearbox

(See procedure AD for removal of automatic gearbox)


AA16

Remove clutch slave cylinder

Remove cylinder circlip.

Withdraw cylinder carefully from location in housing.

N.B. Rubber boot retains plunger in cylinder. Secure boot with circlip.



Remove propeller shaft


Use socket 5244.

Separate front and rear universal joints.

Unbolt intermediate bearing from member.

Withdraw propeller shaft backwards.

AA17




Free gearbox wiring

Cut rear tie at gear lever mounting.

Separate wiring connectors.

AA18



Release gear lever

Undo lever locking bolt.


Remove pivot pin between lever and gear selector rod.

Remove circlip from lever sleeve under mounting.

Push up lever.

Remove bearing bushings and O-ring.


AA19



Undo bolted joint at front of catalytic converter

Release oxygen sensor lead from rear clip.

AA20




Remove front exhaust pipe

Remove nuts in flanged joint with exhaust manifold.

Remove manifold.

AA21




Remove gearbox support member

Remove gearbox bump stop nut and bolts attaching member to side members.

AA22

AA23




Support gearbox on jack

Remove lifting attachments (5006, 5033, 5115 and 5185).

On cars equipped with AC: Tie aside compressor.

AA24




Lift engine

Use lifting tool **2810**, and lifting hooks **5185** and **5186**.

Adjust lifting yoke to ensure engine is balanced.

Remove jack under gearbox.

AA25




Lift out engine and gearbox

Adjust angle of lift throughout operation.

N.B. Carefully check that drive unit is free of radiator, body and extra equipment (if any).

AB. Crankshaft main bearings, replacement

Special tools: 1426, 4090, 5006, 5033, 5111, 5112, 5115, 5186, 5244, 5972



Disconnect battery earth lead


AB1



Unbolt front exhaust pipe from bracket

Remove upper bolts between flywheel housing and cylinder block.

AB2



Relieve weight on gearbox rear mounting

Use support bars 5033, lifting yoke 5006, and lifting hooks 5115 and 5186.

Raise unit using rear left-hand lifting lug.

Take care to **avoid damage** to wiring harness.

AB3


AB4

Remove clutch slave cylinder

Remove cylinder circlip.

Withdraw cylinder carefully from location in housing.

N.B. Rubber boot retains plunger in cylinder. Secure boot with circlip.



AB5


Remove propeller shaft

Use socket 5244.

Separate front and rear universal joints.

Unbolt intermediate bearing from member.

Withdraw propeller shaft backwards.




AB6

Free gearbox wiring

Cut rear tie at gear lever mounting.

Separate wiring connectors.



AB7

Release gear lever


Undo lever locking bolt.

Remove pivot pin between lever and gear selector rod.

Remove circlip from lever sleeve under mounting.

Push up lever.


Remove bearing bushings and O-ring.



AB8

Undo bolted joint at front of catalytic converter

Release oxygen sensor lead from rear clip.




AB9

Remove gearbox support member and bracket

Unbolt bracket.

Unbolt gearbox support member from side members.



AB10

Remove gearbox


Undo remaining bolts in flywheel housing.

Place fixture **5972** under gearbox.

Separate flywheel housing from cylinder block and turn gearbox clockwise in fixture.

Draw gearbox backwards to separate input shaft completely from clutch plate.

Lower gearbox.




AB11

Remove pressure plate and clutch plate


Use gear sector **5112**.

Undo pressure plate joint evenly all round.



AB12


Remove clutch release bearing circlip



AB13

Withdraw clutch release bearing from crankshaft


Use extractor 4090.



AB14

Install:

- new clutch release bearing using drift 1426
- circlip




AB15


Refit clutch plate and pressure plate

Use centering tool 5111 and gear sector 5112.

Tighten pressure plate in stages. Work around circumference tightening diagonally-opposite bolts alternately.

Remove centering tool and gear sector.





AB16

Install gearbox


Use fixture 5972.

Align input shaft, insert and turn gearbox into position.

Tighten gearbox in position.

Remove fixture.

(Tighten two uppermost bolts from engine compartment. See operation AB24.)




AB17

Install gear lever

Insert gear lever sleeve in mounting.

Install:

- bearing bushings and O-ring on gear selector rod; replace selector circlip
- gear selector/lever pivot pin; tighten set screw
- circlip on gear lever sleeve; pull selector rod downwards when fitting circlip




AB18

Reconnect gearbox wiring

Reconnect wiring connectors.


Install cable tie.



AB19

Install clutch slave cylinder

Secure cylinder with circlip.




AB20

Install gearbox support member and reinstate rear mounting

Rebolt rear mounting to gearbox.

Rebolt support member to side members.

Ensure that oxygen sensor lead is above support member.



AB21

Install propeller shaft

Reassemble front universal joint at gearbox.

Reassemble rear universal joint at differential.


Use socket 5244.

Reattach intermediate bearing to member.



AB22


Remake bolted joint at front of catalytic converter



AB23

Remove lifting attachments


Remove tools 5006, 5033, 5115 and 5186.



AB24

Tighten two uppermost bolts in flywheel housing

Reattach front exhaust pipe to bracket.




AB25

Check operation

Replace battery earth lead.

AC. Ring gear, replacement


Special tools: 5111, 5112



Ring gear replacement applies only to cars with manual gearboxes

Strip gearbox to expose flywheel as described in operations AB1-11.

On cars with **automatic gearboxes**, carrier plate is replaced complete with ring gear. (See procedure AD. Crankshaft rear seal, replacement.)




AC1

Remove speed pick-up and unbolt flywheel

Use gear sector 5112.

Remove flywheel.

N.B. Remove speed pick-up **before** flywheel.



**+230 C°
(450 F°)**


AC2

Heat new ring gear to +230°C (450°F)

Heat component in oven or using torch flame.

If using oven, commence procedure by heating component.

If using torch flame, heat component immediately prior to fitting.




AC3

Drill hole between two teeth

Use 10 mm drill.

Drill hole to depth of approx. 9 mm (³/₈").

Caution! Avoid penetrating flywheel, otherwise out-of-balance may result.




AC4

Remove ring gear

Clamp flywheel in vice between soft jaws.

Pry ring gear loose with screwdriver. If necessary, split component at drilled hole.

Clean mating surface on flywheel.



AC5

Fit new ring gear


Check temperature with solder (40% tin and 60% lead). Solder melts at 220–230°C (430–450°F).

Place gear in position.

Tap gear fully home as required using brass drift.

Allow gear to cool.

Important! Bevelled edge must face flywheel.




AC6

Turn crankshaft to TDC (ignition) in No. 1 cylinder

Align crankshaft pulley (vibration damper) marking with 0 mark on transmission cover.

Check that No. 1 cylinder cams on exhaust camshaft are pointing upwards at approx. 60° to centre line of engine.

AC7



Replace flywheel

Use gear sector **5112**.

At TDC, mark on flywheel should be positioned between the two lower bolt holes on right-hand side of cylinder block.


Caution! If flywheel is not marked, new position is indicated by pins **A** and **B** at rear.

Pins **A** and **B** are located respectively approx. 15° on either side of marking position.

Use new bolts and thread locking compound.

Tighten to **70 Nm** (52 ft.lb).

AC8




Install speed pick-up

Use thread locking compound.

Tighten to **5 Nm** (3.5 ft.lb).

AC9



Refit clutch plate and pressure plate

Use centering tool **5111** and gear sector **5112**.


Tighten pressure plate in stages. Work around circumference tightening diagonally-opposite bolts alternately.

Remove centering tool and gear sector.

Install gearbox and propeller shaft as described in operations **AB16-26**.

AD. Crankshaft rear seal, replacement

Special tools: 1801, 5006, 5033, 5111, 5112, 5115, 5186, 5244, 5276, 5972



Procedure applies to cars equipped with automatic gearboxes


Manual gearbox:

Remove gearbox as described in operations AB1-11.

Automatic gearbox

AD1

Disconnect battery earth lead




AD2


Remove bolts securing front exhaust pipe to bracket

Remove upper mounting bolts in torque converter housing.

Remove retaining clip for oil cooler lines.



AD3




Release kickdown cable

Remove transmission oil dipstick.

N.B. Cover open end of dipstick tube.

AD4




Relieve weight on gearbox rear mounting

Use support bars **5033**, lifting yoke **5006**, and lifting hooks **5115** and **5186**.

Raise unit using rear left-hand lifting lug.

Take care to avoid damage to wiring harness.

AD5



Remove propeller shaft


Use socket **5244**.

Separate front and rear universal joints.

Unbolt intermediate bearing from member.

Withdraw propeller shaft backwards.


AD6



Free gearbox wiring

Cut lower cable tie at lever mounting.

Separate wiring connectors.




AD7

Release gear selector lever

Remove clips from pivoted joints between selector lever and selector rod/reaction arm.


Withdraw selector rod and reaction arm from mounting.



AD8

Undo bolted joint at front of catalytic converter


Remove front exhaust pipe bracket.



AD9

Remove gearbox support member

Separate member from gearbox bump stop and side members.




AD10

Disconnect transmission oil lines at gearbox

Collect leakage oil in container or mop up with paper.

Plug connections.


AD11



Remove:

- splashguard under engine
- reinforcing bracket between engine and gearbox
- bolts securing torque converter to carrier plate
- ventilation grille over torque converter

AD12



Remove gearbox

Place fixture **5972** under gearbox.


Remove remaining bolts in torque converter housing.

Carefully prise torque converter free of carrier plate.

Lower gearbox, inclining unit backwards very slightly to prevent torque converter slipping off shaft.

N.B. Position fixture **5972** with fork at front under gearbox.

AD13




**Remove speed pick-up and unbolt flywheel/
carrier plate**

Use gear sector **5112**.

Remove flywheel/carrier plate.

N.B. Speed pick-up must be removed **before** flywheel/
carrier plate.



146 614

AD14

Remove crankshaft seal


Prise out seal **carefully** with screwdriver.

Take care to avoid damaging sealing faces on shaft and seating flange.

Clean seat in flange and inspect shaft for grooving, indicating wear.

Important! Note position of seal in relation to seating flange.

ProCarManuals.com



146 615

AD15

Press seal into rear seating flange

Assemble standard handle **1801** and assembly tool **5276**.

Oil mating surfaces between flange and seal, and between lips of seal.

Place seal on drift.


Locate seal further in than before if wear mark is present on crankshaft.

Remove **one** spacer from drift if original seal was flush with flange.

Remove **two** spacers from drift if original seal was located 3 mm inside flange.

Leave both spacers in position if crankshaft is undamaged.

Tap in seal until drift meets crankshaft.



146 559


AD16

Turn crankshaft to TDC (ignition) in No. 1 cylinder

Align vibration damper marking with 0 mark on transmission cover.

Check that No. 1 cylinder cams on exhaust camshaft are pointing upwards at approx. 60° to centre line of engine.

AD17



Replace flywheel/carryer plate

Use gear sector **5112**.

At TDC, mark on flywheel/carryer plate should be positioned between the two lower bolt holes on right-hand side of cylinder block.


Caution! If flywheel is not marked, new position is indicated by pins **A** and **B** at rear.

Pins **A** and **B** are located respectively approx. 15° on either side of marking position.

Use **new bolts** and **thread locking compound**.
Tighten to **70 Nm** (52 ft.lb).

Automatic gearbox: Note location of support plates. Outer plate must be installed with edge facing outwards.

AD18



Install speed pick-up


Use thread locking compound.

Tighten to **5 Nm** (3.5 ft.lb).

Cars equipped with manual gearboxes:

Install clutch and gearbox as described in operations **AB15-26**.

AD19



Install gearbox

Use fixture **5972**.


Lift gearbox, tilting unit slightly backwards.

Align torque converter with carrier plate.

Tighten gearbox in position.

Reattach front exhaust pipe bracket to torque converter housing.

Remove fixture **5972**.




AD20

Reconnect gear selector lever

Reattach selector rod and reaction arm to lever mounting.

Install locking clips.

N.B. Fit selector rod with flat washer.




AD21

Reconnect gearbox wiring

Reconnect wiring connectors.

Install cable tie at gear selector mounting.




AD22

Install gearbox support member

Rebolt support member to side members.

Tighten bump stop. (Ensure that oxygen sensor lead is above member.)




AD23

Reconnect transmission oil lines

Reconnect and tighten unions on gearbox.


AD24



Tighten torque converter on carrier plate

Finger-tighten all bolts.
Tighten bolts alternately.
Tightening torque 45 Nm (33 ft.lb).


AD25



Install reinforcing bracket

Tighten bracket in stages.
Attach bracket first to torque converter housing and
then to cylinder block.
Install ventilation grille.
Install splashguard under engine.


AD26



Install propeller shaft


Use socket 5244.
Tighten front and rear universal joints.
Rebolt intermediate bearing to member.

AD27



**Retighten bolted joint in front of catalytic
converter**


Install front exhaust pipe bracket.



AD28

Remove lifting attachments


Remove tools 5006, 5033, 5115 and 5186.



AD29

Tighten two uppermost bolts on torque converter housing

Reattach front exhaust pipe to bracket.



AD30


Connect kickdown cable to throttle pulley

Check cable adjustment.

Replace transmission oil dipstick.

N.B. See procedure AS for checking/adjustment of kick-down cable.

AD31



Check operation

Reconnect battery earth lead.


Check gear selector play in **D** and **N** positions.

Play should be the same or somewhat less than in positions 1 and 2.

Check transmission oil level.

AE. Crankshaft pulley (vibration damper), replacement


Special tool: 5284



AE1

Remove:

- battery earth lead
- alternator drive belt
- radiator fan and pulley
- fan shroud
- servo pump and (if fitted) AC compressor drive belts




AE2

Remove crankshaft pulley (vibration damper) from crankshaft

Lock pulley using counterhold 5284.

Secure counterhold using implement such as drift placed against cylinder head over coolant pump.

N.B. Counterhold 5284 must not be locked against pump throat.



AE3

Replace pulley on crankshaft


Use counterhold 5284.

Check that slot in damper engages projection on timing belt pulley.

Secure counterhold using implement such as drift placed against auxiliary mounting bracket.

Tighten crankshaft bolt in two stages:

1. Tighten to **60 Nm** (44 ft.lb).
2. Tighten through further **60°**.



AE4


Install:

- fan shroud
- radiator fan and pulley
- all drive belts
- battery earth lead

Start engine and check operation.

AF. Crankshaft front seal, replacement

Special tools: 5283, 5284, 5872




144 898

Check that flame trap is not blocked

Flame trap blockage restricts crankcase ventilation and increases crankcase pressure.

Symptoms of flame trap blockage:

- Oil dipstick tends to lift in tube.
- Oil leakage from cylinder block seals.
- Seals do not always require renewal if leakage is due to this cause. Overhaul flame trap, clean engine and reinspect for seal leakage.
- Engine knocks.




146 566

Remove timing/balance shaft belts as described in operations C1-9.

AF1

Remove timing belt right-hand idler

AF2



146 567

Remove crankshaft pulley (vibration damper)

Use counterhold 5284 and guide 5872.


Mount counterhold using M8 × 80 mm flanged bolt, using guide as spacer between counterhold and cylinder head, in right-hand idler bolt hole.

AF3

Remove timing/balance shaft drive pulleys

Remove timing belt outer guide, pulley and inner guide.

Remove balance shaft pulley.




AF4

Remove seal

Pry out seal **carefully** using screwdriver, taking care to avoid damaging sealing faces on shaft and in seating flange.

Clean crankshaft end and seating flange. Inspect shaft for signs of wear.



AF5

Fit new seal


Use tool 5283.

Grease seal.

Place seal on tool.

Tap seal home into seating flange.


N.B. Face of seal should normally be flush with chamfered edge in housing. However, if shaft end shows signs of wear, seal may be located approx. 3 mm further in.




AF6

Install balance shaft drive pulley

N.B. Guide must face outwards.






AF7

Install timing belt pulley and guides

Install:

- inner guide
- drive pulley
- outer guide

N.B. Slot in pulley must face cylinder block and must engage guide pin on balance shaft drive pulley.



AF8

Install crankshaft pulley (vibration damper)

Use counterhold **5284** and guide **5872**.


Check that slot in damper engages projection on timing belt pulley.

Mount counterhold using M8 × 80 mm flanged bolt, using guide as spacer between counterhold and cylinder head, in right-hand idler bolt hole.

Tighten crankshaft bolt in two stages:

1. Tighten to **60 Nm** (44 ft.lb).
2. Tighten through further **60°**.

Turn crankshaft to TDC in No. 1 cylinder.



AF9

Install right-hand idler

Tighten to **25 Nm** (18.5 ft.lb).

Install timing/balance shaft belts as described in operations **C10-37**.


N.B. See table of tension values in specifications (page 11) if replacing existing timing/balance shaft belts.

Group 22 Lubrication system


Contents

	Procedure	Page
Design/function.....	–	212
Oil and oil filter, changing.....	AG1–3	213
Oil pressure, checking.....	AH1–3	214
Oil pressure regulator, checking.....	AI1–7	216


Lubrication system Design/function



146 706



146 707



146 708

Oil supply

Driven by the timing belt, the **oil pump** (1) draws oil through a strainer in the sump.

The **oil filter** (2) (to which the oil flows through a passage at the front of the cylinder block) is mounted on the opposite side to the pump. The filter is of the conventional type.

The **oil pressure regulator** (3) limits the pressure in the system to 0.86 MPa (122 psi).

Located in the passage downstream of the filter, the **oil pressure switch** (4) operates the low oil pressure warning lamp.

The **crankshaft** (5) is lubricated in conventional manner through passages cast and drilled in the block, and oil-ways in the shaft itself.

The **pistons and cylinder walls** are lubricated by oil mist and by splash lubrication from the crankshaft.

Lubrication for the **right-hand balance shaft** (6) is supplied through a passage formed in the right-hand side of the block.

The **left-hand balance shaft** (7) is lubricated from the third main crankshaft bearing through a milled slot.

The **camshafts and hydraulic tappets** are supplied with lubricating oil under pressure through a channel adjacent to the second cylinder head bolt on the right-hand side. Within the head, the channel is integral with the bolt for half of its length, following which the oil is conveyed through a drilled passage to the gallery on the right-hand side of the camshaft carrier.

The left-hand gallery, which supplies the camshaft and tappets on that side, is supplied with pressurized oil through a passage connecting it with the right-hand gallery.


Oil pump.

A higher oil flow is required to supply the new components – balance shafts, second camshaft and hydraulic tappets – particularly when the engine is hot.

The new pump is an Eaton type – essentially an internal gear pump consisting of a 4-lobed rotor running inside a 5-lobed ring. The pumping action is achieved by the continuous increase and decrease in volume which occurs as the elements rotate. Although the capacity is comparable to that of earlier gear pumps, it is higher at low speeds and when the oil is hot (120°C/250°F). The capacity at an engine speed of 4000 r/min is approximately 360 l/min (95 US gpm).

AG. Oil and oil filter, changing

Special tool: 2903



Changing engine oil

Always use oil of the correct grade:

As per API-Service..... min. **SF***
As per CCMC..... class **G2/G3**

*Oils designated SF/CC and SF/CD fulfil this requirement.

Ensure engine is hot before draining oil.

Use **new** sump plug seal.

Torque 60 Nm (44 ft.lb).

Capacity, excl. oil filter..... **3.5 l** (3.7 US qt)
incl. oil filter..... **4.0 l** (4.2 US qt)



Oil filter, replacement

AG1

Remove oil filter

Use tool 2903.

Remove filter from engine compartment side. Use paper or waste to mop up oil spillage.



AG2

Install new oil filter

Coat face of seal with oil.



AG3

Tighten oil filter

Screw home filter by hand until seal makes firm contact. Tighten a further $\frac{1}{2}$ - $\frac{3}{4}$ turn.

Fill engine with oil.

Start engine.


Inspect filter for leakage.

When replacing filter only:

Top up engine with **0.5 l** (0.5 US qt) of oil.


AH. Oil pressure, checking

Special tool: 5270



Check oil pressure with engine hot and oil at correct level

Engine oil must be of recommended grade and type. Genuine Volvo oil filter must be fitted.



AH1

Check engine oil level

Top up as required.

If grade/type of oil and filter condition **cannot** be ascertained, replace filter and change oil.



AH2


Check oil pressure switch

If pressure indication is absent:

- check switch lead and connector
- check switch type and function; fit new switch if necessary
- check for faulty lead between switch and warning lamp

N.B. Use new gasket between switch and cylinder block when switch is finally reinstalled.

AH3



Check oil pressure

Use instrument kit 5270.

Connect adapter C (B11-14), tube 5272 and instrument 5271 to pressure switch tapping on cylinder block.

Connect rev counter.

Start engine and read oil pressure at different speeds.

N.B. Use **new** gasket between switch and cylinder block when switch is finally reinstalled.


Minimum oil pressure

15 r/s (900 r/min)	0.10 MPa
33 r/s (2000 r/min)	0.25 MPa
50 r/s (3000 r/min)	0.50 MPa


Maximum oil pressure (with relief valve open): 0.80 MPa

If readings are not satisfactory:

Check oil pressure regulator as described in operations AI1-7.




A1. Oil pressure regulator, checking



A1/1

Remove:


- battery earth lead
- alternator drive belt
- servo pump and (if fitted) AC compressor drive belts



A1/2

Detach alternator bracket from cylinder block

Tie up bracket out of way..




A1/3

Remove relief valve

- Remove plug over spring.
- Remove spring and plunger.

A14




146 665

Clean and inspect components

Check plunger for wear.

Measure spring length:

Length, unloaded.....	47.6 mm (1.87 in)
(44±4 N/10±0.9 lb	32.0 mm/1.25 in)
(61±6 N/14±1.4 lb	26.0 mm/1.02 in)




146 664

A15

Install relief valve

Fit **new** sealing washer.

Tighten to **40±4 Nm** (29.5±3 ft.lb).




146 663

A16

Install:

- alternator bracket
- all drive belts
- battery earth lead



144 867

A17

Check operation/inspect for leaks

Test run engine.


See procedures **H**, **I** and **J** for details of other work on lubrication system.

Group 25 Intake and exhaust systems

Contents

	Procedure	Page
Design/function.....	–	219
Air cleaner, maintenance/replacement.....	AJ1-3	220
Preheating function, checking.....	AK1-8	221
Intake manifold, replacement.....	AL1-14	224
Crankcase ventilation, checking/overhaul.....	AM1-9	228
Exhaust system, inspection/overhaul.....	AN1-10	231

Design/function



Catalytic converter


The three-way catalytic converter is used to purify the exhaust gases of unburnt residues of
 carbon monoxide (CO)
 hydrocarbons (HC)
 nitrous oxides (NOx)
 by chemical reaction i.e. combustion with unburnt oxygen.

The unit converts 90-95% of these noxious substances into innocuous

water (H₂O)
 carbon dioxide (CO₂)
 nitrogen (N₂)

The active surface area of the unit is 32 000 m² and the noble metal content is 4 g of platinum/rhodium.

N.B. Any trace of lead in the fuel will quickly damage the catalytic converter beyond repair.




Oxygen sensor (Lambdasond®)

The ideal air/fuel ratio is usually given as 14.7 kg of air to 1 kg of fuel. The oxygen sensor is used to measure the oxygen content of the exhaust gases as a means of achieving these conditions.

Since the device functions only above a certain temperature, it is heated electrically to ensure that the specified value is reached quickly and maintained more efficiently. Current is supplied to the heating element when the system relay operates.


AJ. Air cleaner, replacement



146 666

Air cleaner is normally replaced every 40 000 km (25 000 miles)

Cleaner should be replaced at shorter intervals if car is frequently driven on unsurfaced roads or under abnormally dusty conditions.




146 667

Remove air cleaner cover

Release catches.

AJ1




146 668

Replace cleaner element

Inspect inside of cleaner housing.

Clean as required.

AJ2




146 669

Reassemble air cleaner

Ensure that sealing flange is correctly seated.

AJ3

AK. Intake air preheating function, checking




146 677

The preheating function consists essentially of a thermostatically controlled damper housed in the air cleaner.

The thermostat senses the temperature of the intake air and alters the position of the damper to vary the proportions of hot and cold air entering the cleaner. This enables the intake air temperature to be maintained at a constant value, irrespective of the outside temperature.

Proceed as follows if any of the following problems are encountered:

- juddering
- loss of power
- high fuel consumption




146 670

AK1

Check attachment and sealing of:

- heat shield
- preheating hose
- air cleaner housing



146 671


Damper operation, checking

AK2

Remove air cleaner housing

Undo air duct connections.

Remove housing carefully from mountings.




146 672

AK3

Remove damper housing from air cleaner

Remove cover and cleaner element.

Depress damper housing catches and withdraw housing.



138 529


AK4

Check operation of preheating components:

- bushings and mountings
- spring
- thermostat (for example, with cooling spray)

Damper position at different outside temperatures:

- A** = $< +5^{\circ}\text{C}/41^{\circ}\text{F}$ (preheated air only)
- B** = approx. $10^{\circ}\text{C}/50^{\circ}\text{F}$
- C** = $+15^{\circ}\text{C}/59^{\circ}\text{F}$ (cold air only)




146 673

AK5

Reassemble air cleaner

Install:

- damper housing
- cleaner element
- cover



146 674

AK6

Install air cleaner in car


Place unit on mountings.

Reconnect all air ducts.

AK7

Check attachment of front intake


If required, remove grille and tighten intake mountings.




AK8

Check operation

Start and test run engine.



AL. Intake manifold, replacement




146 279

AL1

Remove air mass meter and air inlet hose

Undo connector at air mass meter and hose connections to oil trap and idling (air control) valve.




146 625

AL2

Detach throttle pulley from intake manifold

Detach pulley link rod from throttle lever.

Loosen bolt securing intake manifold support to engine mounting.




146 626

AL3

Separate throttle housing from intake manifold


Cut cable tie holding throttle switch wiring to vacuum servo hose connection.



AL4

Disconnect following hoses/lines from intake manifold:

- vacuum servo
- EVAP valve (F engines only)
- oil trap
- fuel pressure regulator
- idling (air control) valve
- vacuum tank (applies only to cars equipped with CU/ CU + AC heater)



AL5

Remove fuel distribution pipe and injectors


Disconnect fuel return line at distribution pipe.

Mop up fuel spillage with paper.

Disconnect injector connectors.

Carefully withdraw distribution pipe/injector assembly.


N.B. Protect injectors from entry of dirt.



AL6

Remove intake manifold from cylinder head


Remove gasket between manifold and cylinder head, and clean joint as required.



AL7

Transfer hose nipples and plugs (if any) to new manifold:

- vacuum servo
- EVAP valve (F engines only)
- oil trap
- fuel pressure regulator
- idling (air control) valve
- vacuum tank (applies only to cars equipped with CU/ CU + AC heater)




AL8

Install and tighten new intake manifold in position

Use **new** gasket.


Tighten bolts from centre outwards.



AL9

Reconnect following hoses/lines:

- vacuum servo
- EVAP valve (F engines only)
- oil trap
- idling (air control) valve
- vacuum tank (applies only to cars equipped with CU/ CU + AC heater)



AL10

Install fuel distribution pipe and injectors


Inspect injector O-rings. Lubricate O-rings with water-free vaseline.

Position injector wiring between No. 2 and No. 3 cylinder connections.

Reconnect injector connectors.

Attach and tighten fuel distribution pipe and earth leads to intake manifold.

Reconnect fuel pressure regulator line to intake manifold.




AL11

Install throttle pulley

Position pushrod under upper mounting points.

Tighten support under manifold and at engine mounting.



AL12


Install throttle housing

Use new gasket.

Reattach pulley pushrod to throttle lever.

Check operation of throttle switches and stops.


Secure wiring using cable tie attached to vacuum servo hose nipple.



AL13

Install air mass meter and air inlet hose

Reconnect air meter connector, oil trap hose and idling (air control) valve hose.




AL14

Check operation

Test run engine.

AM. Crankcase ventilation, checking/overhaul



Blocked flame trap/ventilation system


Blockage of the flame trap may be caused by:

- excessive interval between engine oil changes
- use of inferior grade engine oil
- excessive interval between flame trap services

Flame trap blockage restricts crankcase ventilation and increases crankcase pressure.

Symptoms of flame trap blockage:

- Oil dipstick tends to lift in tube.
- Oil leakage from cylinder block seals. Seals do not always require renewal if leakage is due to this cause. Overhaul flame trap, clean engine and reinspect for seal leakage.
- Engine knocks.



Flame trap, inspection

AM1

Remove oil trap T-piece

Disconnect hoses from intake manifold and air inlet hose.

Disconnect bottom T-piece hose from oil trap.


AM2

Inspect flame trap

Disconnect hoses from T-piece.

Cut tie around top T-piece hose.

Remove flame trap from T-piece.




AM3


Blow hoses and flame trap clean

Replace flame trap if blocked.

Check hose connection under intake manifold.



146 680




146 681

AM4

Install/reconnect:

- flame trap in T-piece
- hoses to T-piece
- tie around upper hose
- T-piece and hoses in oil trap

Connect hoses to intake manifold.



146 678


Oil trap seals, replacement

AM5

Detach T-piece from oil trap

Disconnect hoses from intake manifold and oil trap.

Remove oil trap from cylinder block.




146 682

AM6

Remove intake manifold

Undo support at left-hand engine mounting.

Separate manifold from cylinder head.




AM7

Remove oil trap

Lift trap out of cylinder block.

Lift intake manifold when oil trap has been removed.

N.B. Ensure that seals do not fall into crankcase.




146 684

AM8

Install/reconnect:

- O-rings on oil trap (use **new** rings)
- oil trap in cylinder block
- gasket between intake manifold and cylinder head (use **new** gasket)
- intake manifold and support
- T-piece and hoses to oil trap

Reconnect hoses to intake manifold.




AM9

Check operation

Start engine.

Inspect for leakage.

AN. Exhaust system, inspection/overhaul




Sealing

The system must not only be well sealed, but must also be assembled from components made to manufacturer's specifications, to ensure optimum engine performance and guarantee the cleaning efficiency of the catalytic converter.*

New gaskets **must** be used when fitting components.

* Engines supplied to certain markets (E engines) may not be fitted with catalytic converters.




Exhaust manifold, replacement

AN1

Release front exhaust pipe

Remove nuts in joint with manifold.

Undo joint between catalytic converter and front silencer.




AN2

Remove heat shields

Disconnect air preheating hose.

Remove top and bottom heat shields.


Disconnect front exhaust pipe from bracket on flywheel housing.



AN3

Remove exhaust manifold and gasket

Inspect faces of joints with cylinder head and front exhaust pipe.




AN4

Install exhaust manifold

Use new gasket.

Tighten manifold on cylinder head.

Attach lifting lug to upper row of bolts between No. 2 and No. 3 exhaust branches.




AN5

Install front exhaust pipe

Use new gasket.

Tighten joint with manifold.

Tighten joint at front of catalytic converter/silencer.



AN6

Install heat shields

Tighten exhaust pipe to bracket on flywheel housing.

Reconnect air preheating hose.

Check operation

Start engine.

Check system for leaks.

Exhaust pipe, replacement

General

Use **new** gaskets.


Replace conical steel ring in clamped joint on front exhaust pipe only if damaged.

Inspect rubber mountings and replace if necessary.


Pipe sections should overlap by approx. 40 mm (1 1/2 in).

Clearance between exhaust system and body should not be less than 20 mm (3/4 in).


N.B. Ensure that oxygen sensor wiring is protected against strain when replacing exhaust systems on cars with catalytic converters.



146 639



146 640



146 641

AN7

Installation of complete system

Follow procedure below to avoid stresses in system:

Install front pipe and tighten bolted joint with manifold.

Insert and tighten mounting bolts in front pipe bracket.

Offer up and align other components.

Tighten pipe/silencer clamps.

Tighten nuts at front pipe pivot point.


Check clearance between system and body. Adjust as required.

AN8

Check operation

Start engine.

Check system for leaks.




Catalytic converter

General

Different catalytic converters are used depending on engine type, model year and market.

Each converter provided with a plate stating the part number and other details.

The unit is also marked with an arrow to indicate the direction of flow.




AN9

Connection to front exhaust pipe

Catalytic converter flange is fitted with fixed bolts.

Bolts may be replaced with separate bolts in the event of damage.



AN10

Check catalytic converter

Converter efficiency may be checked by measuring and comparing CO content before and after unit.


Converter reduces CO content on reaching ignition temperature (450°C/840°F).

Group 26 Cooling system

	Procedure	Page
Design/function	–	236
Cooling system, checking/overhaul	AO1–9	237
Coolant pump, inspection/replacement	AP1–11	240
Thermostat, checking/replacement	AQ1–7	243
Drive belts	AR1–2	245

Design/function

Cooling system



The liquid-cooled engine is equipped with a closed cooling system.

The system consists of an inner and an outer circuit, the latter including the radiator and expansion tank. Other parts of the system and of the car heating system are considered part of the inner circuit.

The outer circuit is isolated when the engine temperature is below the thermostat opening temperature. Under these conditions, coolant is returned to the pump inlet through a by-pass in the cylinder head.

The system is filled (either when empty or when topping up) through the expansion tank.


Genuine Volvo coolant diluted with **clean** water in proportions of **50/50** is the only coolant guaranteed by Volvo to prevent corrosion and freezing damage.

Type C (blue-green) coolant may not be mixed with any other type.

The coolant must be replaced **every second year** to ensure protection against corrosion.

AO. Cooling system, checking/overhaul

Special tools: 998-5496



Coolant

Since some engine components are made of aluminium, the coolant must contain an active corrosion inhibitor to prevent corrosion damage.


Genuine Volvo coolant diluted with **clean** water in proportions of **50/50** is the only coolant guaranteed by Volvo to prevent corrosion and freezing damage.

Type C (blue-green) coolant may not be mixed with any other type.

The coolant must be replaced **every second year** to ensure protection against corrosion.

Only **type C** coolant should be used as a replacement.

Capacity, **manual gearbox**..... **9.5 l** (10 US qt)
automatic gearbox..... **9.3 l** (9.8 US qt)



Coolant, changing

AO1

Drain coolant

Set heater control to max. heat.


Remove expansion tank cap.

Open cock on right-hand side of cylinder block. Fit hose to cock to collect coolant.

Disconnect bottom radiator hose.

Close drain cock and replace radiator hose.

AO2




Fill system with coolant

Fill system through expansion tank.

Run engine up to temperature and top up as required.

Inspect system for leaks.



Checking system for leaks

A03


Pressure test cooling system

Use pressure tester **998 5496**.

Connect tester to T-piece on vent line between expansion tank and radiator.

Increase pressure and check opening pressure and tightness of filler cap:

- correct pressure is **150 kPa** (22 lb/in)
- pressure in system should be steady




Radiator, cleaning/checking operation

A04

Cleaning of radiator

Clean off insects and other dirt by flushing from the rear with water and blowing clean with compressed air.

N.B. Excessive pressure will damage cooling fins.



Inspection of radiator

A05

Run engine up to working temperature. Continue running for another few minutes.

Stop engine.

Remove top section of fan shroud from radiator.


Feel radiator with hand. Presence of cold areas indicates that unit is partially blocked.

A06

Checking/adjustment of radiator position

Radiator must be fitted tight against front panel, otherwise air leakage may occur at sides.

Adjust position of air baffles as required.



Coolant temperature sensors


A07

Location of sensors

Sensors are located on left-hand side of cylinder head under intake manifold.

Front sensor supplies signal to ignition and fuel injection systems.

Rear sensor is connected to temperature gauge.



Radiator fan

A08


Fan blades, replacement

Remove top section of fan shroud.

Remove blades from clutch housing.

Install:

- new fan blades
- fan shroud



A09


Fan replacement

Slacken alternator drive belt.

Withdraw fan from driver on water pump.


Replace fan

Adjust alternator belt tension.



AP. Coolant pump, inspection/replacement

Special tool: 998 5496



Coolant pump, inspection

AP1

Run engine until hot

Continue running until thermostat opens.

Stop engine.

N.B. Lower pressure in cooling system. Open expansion tank cap **carefully!** Retighten cap when pressure has been reduced.


AP2

Pressure test cooling system

Use pressure tester **998 5496**. Fit T-piece in vent line between radiator and expansion tank.

Increase pressure to **150 kPa**.


Pressure must not drop significantly in 3 minutes.



AP3

Proceed as follows in case of leakage: (Numbers refer to locations indicated on illustration)

1. Replace all gaskets.
2. Replace all gaskets.
3. Replace complete pump.
4. Replace all gaskets.
5. Overhaul hose connection:
 - clean off corrosion, if any
 - replace hose clip, if necessary
 - replace hose, if necessary



Coolant pump, replacement

AP4

Drain coolant



Set heater control to max. heat.

Remove expansion tank cap.

Open cock on right-hand side of cylinder block. Fit hose to cock to collect coolant.

Disconnect bottom radiator hose.


Close drain cock and replace hose.



AP5

Remove:


- alternator drive belt
- radiator fan and pulley



AP6

Remove coolant pump

Remove all bolts, washers and nuts.




AP7

Clean joint faces and mating surfaces

Scrape all gasket remains from cylinder block.

Clean mating surface of rubber seal with cylinder head.



AP8

Replace coolant pump


Use **new** gaskets between pump housing and cylinder block, cylinder head and return pipe.

Place O-ring on return pipe and gasket on block.

Ensure that O-ring is located in groove in pump housing.

Tighten both mounting nuts.

Tighten nuts sufficiently to eliminate play while permitting adjustment of pump position.



AP9

Press pump upwards against cylinder head


Place drift in bolt hole in cylinder block under pump housing.

Use screwdriver to press pump housing upwards against cylinder head.

Replace remaining washers and bolts.

Tighten pump housing.


Reconnect return pipe.



AP10

Install:

- bottom radiator hose
- radiator fan and pulley
- alternator drive belt



AP11



Fill system with coolant

Fill system through expansion tank.

Run engine up to temperature and top up as required.

Inspect system for leaks.

AQ. Thermostat, checking/replacement



Thermostat replacement

AQ1

Drain off approx. 2 litres (2 US qt) of coolant

Remove expansion tank cap.

Open cock on right-hand side of cylinder block. Fit hose to cock to collect coolant.

Close drain cock.

AQ2

Undo thermostat housing

Remove thermostat and gasket.

Clean joint surfaces on cylinder head and thermostat housing.

AQ3


Install new thermostat

Use new gasket.

Place gasket on thermostat.

Place thermostat in housing.


Replace and tighten housing.



AQ4

Check upper radiator hose

Clearance between alternator drive belt and hose must not be less than 25 mm (1 in).



AQ5


Fill system with coolant

Fill system through expansion tank.

Run engine until thermostat opens and top up as required.

Inspect system for leaks.

ProCarManuals.com




Checking thermostat

AQ6

Check opening function

Thermostat may be tested in hot water. Maximum opening must be reached within 2 minutes in water at operating temperature.

Marking	Opening commences at	Fully open at
87	86–88°C (187–190°F)	97°C (207°F)



AQ7

Top radiator hose, position marking


Top radiator hose, replacement

Position front marking (radiator end) facing straight upwards.

Position rear marking (thermostat end) opposite joint on thermostat housing.

Check that clearance between normally adjusted alternator drive belt and hose is at least 25 mm (1 in).


AR. Auxiliary drive belts



General

When correctly tensioned, free movement of belt between pulleys should be 5–10 mm (3/16–3/8 in).

N.B. Replace **both** belts when renewing parts on engines with twin drive belts.




AR1

Adjust belt tension

Loosen auxiliary mounting bolts.

Tension belts by operating adjusters 1 (alternator) and 2 (servopump/AC compressor).

Tighten mounting bolts.



AR2

Cars equipped with AC are fitted with twin compressor and servo pump drive belts

1. Crankshaft pulley
2. Alternator
3. Radiator fan
4. Servo pump
5. AC compressor

Group 27 Engine controls

Contents

	Procedure	Page
Design/function	-	247
Throttle/kickdown cable, inspection/adjustment	AS1-5	248
Cruise control	AT1-11	250


Cruise control

Design/function

Warning! Cruise control must **not** be used on wet or slippery road surfaces, or in dense traffic.



146 747



146 748



146 747

In the system, a regulator is used to control a vacuum pump in response to signals from the speedometer and from a control lever. The pump, in turn, operates a vacuum servo connected to the throttle pulley by a cable.

The system maintains the speed of the car constant by continuously adjusting the vacuum in the servo in response to variations in speed.

Speed adjustment

Set switch to **ON**.

Accelerate to required speed (at least 40 km/h/25 mph).

Press **SET SPEED** button in the end of the direction indicator stalk. Release button and remove foot from accelerator.

To reduce set speed

Set switch to **OFF**. When car has slowed to required speed, reset switch to **ON** and operate **SET SPEED** button.

To increase set speed

Accelerate to required speed and press **SET SPEED** button. Car will now maintain the higher speed.

Temporary speed increase

Operate accelerator in usual manner.

Car will return to previous speed setting when pedal is released.


Disengagement of system

Press brake or clutch pedal lightly or set switch to **OFF**.

Return to set speed

After braking, the car will return to the previous speed setting if the switch is held in the **RESUME** position for a brief instant.

AS. Throttle/kickdown cable, inspection/adjustment



AS1

Basic adjustment of throttle

Disconnect air inlet hose from throttle housing.


Remove throttle pulley link rod.

Undo adjuster locknut.

Screw out adjuster until throttle is fully closed. If throttle does **not** close, remove throttle switch.

Screw in adjuster until it is just in contact with throttle lever. Screw in a further ~~with~~ *half turn*

Lock adjuster with locknut. Ensure that adjuster does not move during this procedure.



AS2


Check throttle switch setting

Open throttle slightly and listen to switch. Switch should emit a click (indicating opening of idling contacts) as soon as throttle opens.

Adjust as follows:

- undo mounting screws
- turn switch slightly clockwise
- turn switch anticlockwise until click is heard
- tighten screws
- check setting

AS3



Inspect/adjust throttle pulley and cable

Pulley should turn easily without sticking.


Cable should be taut in idling position without preventing pulley from bearing against idling stop.

Adjust as required.

Press **accelerator** to floor and check that pulley rotates to meet full-load stop.

146 585

AS4



Connect and inspect/adjust link rod

Insert **1 mm** (0.04 in) feeler gauge between projection on throttle pulley and idling stop.


Clearance between throttle lever and adjuster should now be **0.2 ± 0.1 mm** (0.008 ± 0.004 in).

Adjust link rod as required.

Check throttle switch. Switch **must** open immediately when link rod lifts.

146 586

AS5



Kickdown cable, inspection/adjustment

Check that cable:

- is seated in groove in pulley
- is taut in idling position without exerting pull on pulley
- moves easily in sleeve

Pull cable out approx. 10 mm (3/8 in) and release suddenly. Metallic click should be heard from kickdown cam (in gearbox) as it returns to idle position.

Cable over-taut: No clicking sound.

Cable slack: No kickdown action.


Correct by adjusting cable tensioner.

N.B. Throttle pulley must return to stop as described in AS3.

146 587

AT. Cruise control, location of components

AT1




146 473

ProCarManuals.com

AT2

Automatic gearbox



146 456

Cruise control, wiring diagram


Components

- 1 Vacuum pump and regulator
- 2 11-pole connector at right-hand A-post (located in black box containing three connectors)
- 3 Control unit
- 4 Connector
- 5 Switch (in direction indicator stalk)
- 6 From busbar +15 (in central electrical unit), across fuse No. 12
- 7 Earth terminal (in central electrical unit)
- 8 Speedometer
- 9 To gear change relay (manual gearbox only)
- 10 To brake lights
- 11 Clutch pedal air valve
- 12 Brake pedal air valve
- 13 Brake light switch

Colour codes

- R = red
- Y = yellow
- BL = blue
- GN = green
- W = white
- OR = orange
- SB = black


Manual gearbox



146 455

Cruise control, checking/fault tracing

AT3



135 519

Important! Cruise control function will not operate if speedometer is out of order.

Control unit should be replaced only if remainder of system is fault-free. Replacement of unit without rectifying other system faults will result in damage to new unit.


AT4

Inspect/adjust throttle and cruise control cables

Both cables should be taut in idling position without altering position of pulley. Pulley should bear against idling stop.

Adjust cables as required.

Press **accelerator** to floor and check that pulley moves to full-load stop.




146 474

AT5

Check fuses No. 4 and 12

Check wiring and vacuum hoses

Hoses must be correctly connected and must not be crimped or damaged. Connections must be correctly made.




143 429

AT6


Check that brake lights are operating and that switch is correctly adjusted

Control unit is connected to earth across brake lights. Unit will not operate if both brake light bulbs are faulty.

Brake lights should operate before brakes engage when pedal is depressed by **8-14 mm** ($1/4$ - $1/2$ in). Adjust as required.



135 520



135 521


AT7

**Check that brake pedal air valve is correctly adjusted and is not leaking
(Repeat check for clutch pedal valve on manuals)**

Valve must close, without leaking, when pedal is released, and must open when pedal is operated.

Check each valve by connecting and blowing into a tube.

Adjust as required.




135 522

AT8

Check that air valve switches are operating correctly

Connect ohmmeter across switch terminals. Resistance must be low (circuit closed) when pedal is released and infinite (open circuit) when pedal is operated.



135 523

AT9

Check vacuum pump and regulator; check system for leaks

Three separate leads are required for checking purposes.


Remove vacuum pump connector.

Connect one lead between 12V power source and pump terminal 3. Connect remaining two leads between earth and pump terminals 1 and 2. Pump should start and vacuum servo should pull cable to bottom limit. Disconnect earth lead from terminal 2. Pump should stop and vacuum servo should remain in actuated position. Absence of servo movement when pump is operated indicates leakage in system or pump fault.

Disconnect earth lead from terminal 1. Vacuum servo should return to original position. Failure to do so indicates pump fault.

Disconnect supply lead.

Replace vacuum pump connector.



Check wiring


Switch off ignition and disconnect control unit.
Test connector pins using test lamp as described below.

(Also see wiring diagram.)

Test procedure	Fault symptom	Cause/action
<ul style="list-style-type: none"> • Ignition off • Switch on Connect test lamp across earth and terminals 1 to 9 in turn Lamp must not light when connected to any of terminals	Lamp lights at certain terminal(s)	– Faulty wiring connection – Flashover
<ul style="list-style-type: none"> • Ignition off • Switch on Connect test lamp across earth and terminals 1 to 9 in turn Lamp should light when connected to terminals 1, 9 and 4	Lamp does not light when connected to terminal 1	– Check fuse No. 2 – Wiring open-circuit
	Lamp does not light when connected to terminal 9	– Check switch – Wiring open-circuit
	Lamp does not light when connected to terminal 4	– Vacuum pump not connected – Wiring open-circuit
<ul style="list-style-type: none"> • Ignition off • Switch on Connect test lamp across earth and terminals 1 and 8 in turn Lamp should light	Lamp does not light	– Faulty earth connection
<ul style="list-style-type: none"> • Ignition off • Switch on Connect test lamp across earth and terminals 1 and 9 in turn Lamp should light when pedals are released and go out when pedals are operated	Lamp does not light when pedals are released	– Wiring open-circuit – Brake light switch not connected
	Lamp does not go out when pedals are operated	– Check control switch – Wiring open-circuit
<ul style="list-style-type: none"> • Ignition off • Switch on • Press SET SPEED button Connect test lamp across earth and terminal 2. Press SET SPEED button. Lamp should light	Lamp does not light	– Check control switch – Wiring open-circuit

Test procedure	Fault symptom	Cause/action
<ul style="list-style-type: none"> • Ignition off • Switch on Connect test lamp across earth and terminal 6. Set switch to RESUME position. Lamp should light	Lamp does not light	– Check control switch (see AT11) – Wiring open-circuit
<ul style="list-style-type: none"> • Ignition off • Switch on Connect lead across earth and terminal 7. Vacuum pump in engine compartment should emit click . Connect second lead across earth and terminal 4. Vacuum pump should start	Click not heard and pump does not start	– Wiring open-circuit

AT11



Check cruise control switch


Open connector at switch.

Connect lead between 12 V power supply and terminal 1.

Connect test lamp across earth and terminals 2 to 4 in turn.

Lamp should light as indicated in table below. Replace switch if faulty.

Terminal	Switch position and test lamp function			
	OFF	ON	ON SET SPEED depressed	RESUME
2	not lit	lit	lit	lit
3	not lit	not lit	not lit	lit
4	not lit	not lit	lit	not lit



Index

	Proce- dure	Page		Proce- dure	Page
Air cleaner			Cylinder head		
Replacement	AJ1-3	240	Gasket, replacement	N1-21	83
Air preheating function			Dismantling/inspection	O1-10	89
Checking	AK1-8	221	Reconditioning	P1-26	92
Auxiliary drive belts (cooling system)	AR1-2	245	Reassembly	Q1-4	99
Balance shafts			Design/function		
Left-hand, replacement	R1-15	101	Group 21 Engine	-	27
Right-hand, replacement	R16-35	105	Group 22 Lubrication system	-	212
Overhaul	R36-49	110	Group 25 Intake and exhaust systems	-	219
Seals, replacement	E1-6	53	Group 26 Cooling system	-	236
Belt tension gauge			Group 27 Engine management	-	247
Function/calibration	-	23	Engine		
Camshaft carrier			Design/function	-	27
Cylinder head joint, resealing	M1-6	81	Removal	T1-30	119
Camshafts			Transfer of components	U1-35	127
Seals, replacement	F1-24	55	Installation	V1-35	137
Shaft, replacement	K1-6	71	Stripped engine, removal	AA1-25	181
Compression testing	A1-9	34	Engine mountings		
Coolant pump			Left-hand, overhaul	S1-9	114
Inspection/replacement	AP1-11	240	Right-hand, overhaul	S10-S19	116
Cooling system			Exhaust system		
Design/function	-	236	Exhaust manifold	AN1-6	231
Inspection/overhaul	AO1-9	237	Exhaust manifold, replacement	AN7-8	233
Crankcase assembly			Catalytic converter	AN9-10	234
Dismantling	X1-32	153	Important information	-	2
Inspection/cleaning	Y1-22	162	Intake and exhaust systems		
Reassembly	Z1-46	169	Design/function	-	219
Crankcase ventilation			Intake manifold		
Inspection/overhaul	AM1-9	228	Replacement	AL1-14	224
Crankshaft main bearings			Lubrication system		
Replacement	AB1-25	188	Design/function	-	212
Crankshaft pulley			Oil and oil filter		
Replacement	AE1-4	207	Changing/replacement	AG1-3	213
Crankshaft seals			Oil pressure		
Front, replacement	AD1-3	198	Checking	AH1-3	214
Rear, replacement	AF1-9	208	Oil pressure regulator		
Cruise control			Inspection	AI1-7	216
Design/function	-	247	Oil pump		
Location of components	AT1	250	Seal, replacement	G1-4	63
Wiring diagram	AT2	250	Pump, replacement	H1-7	64
Fault tracing	AT3-11	251	Inspection	I1-9	66
			Oil sump		
			Gasket, replacement	W1-25	146

	Proce- dure	Page
Ring gear		
Replacement	AC1-8	195
Special tools		
	-	16
Specifications		
	-	4
Tappets		
Replacement	K1-26	71
Inspection	L1-6	79
Thermostat		
Checking/replacement	AQ1-2	243
Throttle/kickdown cable		
Inspection/adjustment	AS1-5	248
Timing belt		
Inspection/adjustment	B1-11	37
Replacement	C1-37	40
Tensioner, inspection/replacement ..	D1-6	51
Valve cover		
Gasket, replacement	J1-6	69
Vibration damper		
(See 'Crankshaft pulley')	-	2

TP 31311/1
3000.12.88
Printed in U.S.A.