

# TRIUMPH

## HERALD 1200, 12/50, VITESSE AND SPITFIRE

### WORKSHOP MANUAL

#### GROUP 2

*Comprising :*

Clutch .. .. .	Section 1
Gearbox .. .. .	Section 2
Overdrive .. .. .	Section 3
Propeller Shaft .. .. .	Section 4

GROUP 2

# TRIUMPH

## HERALD 1200, 12/50, VITESSE

and

## SPITFIRE MODELS

### GROUP 2


---

### CONTENTS

	Page
<b>Section 1</b>	
Clutch data (Herald 1200, 12/50 and Spitfire) .. .. .	2-101
Sectioned clutch and gearbox unit .. .. .	2-102
Clutch Data (Vitesse) .. .. .	2-103
Master cylinder .. .. .	2-104
Slave cylinder .. .. .	2-106
Bleeding the hydraulic system .. .. .	2-106
Clutch release bearing .. .. .	2-107
Clutch unit .. .. .	2-107
Diaphragm spring clutch .. .. .	2-112
<b>Section 2</b>	
Gearbox dimensions and tolerances .. .. .	2-201
Exploded arrangement of gearbox details .. .. .	2-204
Gearbox removal .. .. .	2-205
Gearbox dismantling .. .. .	2-206
Gearbox assembly .. .. .	2-212
<b>Section 3</b>	
Overdrive .. .. .	2-301
<b>Section 4</b>	
Propeller shaft .. .. .	2-401




CLUTCH



C.381

Fig. 2. Section of clutch (Vitesse) and gearbox unit. The gearbox is identical for the Herald 1200, 1250, Vitesse and Spitfire



**CLUTCH DATA**

TYPE .. .. .	8A6 "Single Dry Plate"
OPERATION .. .. .	Hydraulic
ADJUSTMENT .. .. .	Self adjusting
DRIVEN PLATE .. .. .	Belleville washer type, cushioned by white/light green springs
FACINGS .. .. .	Wound yarn (RY2)
1. Spline diameter (O/D) .. .. .	0.996"/0.998" (25.3/25.35 mm.)
2. Splines .. .. .	1.00" (25.4 mm.) × 10 SAE splines
3. Maximum travel available .. .. .	0.42" (10.67 mm.)
4. Minimum travel to release .. .. .	0.37" (9.4 mm.)
5. Release lever plate height .. .. .	2.18" (53.54 mm.) using a 0.33" (8.38 mm.) gauge plate in place of driven plate
6. Maximum height of adjusters .. .. .	2.70" (68.58 mm.)
7. Thrust springs — 6 Light Grey .. .. .	195/205 lbs. (88.45/92.98 kgs.)

Fig. 3. Sectional view of the clutch (Vitesse)

MASTER CYLINDER OPERATION

A. Clutch Driving Condition


When the clutch pedal is released, the push rod (9) is returned to its stop (12) by the pedal return spring. This permits the plunger (7) to move rearwards under pressure of the spring (5). The flange on the end of the valve shank (4) contains the spring retainer (6) and as the plunger continues to move rearwards, the valve shank (4) lifts the seal (1) from its seat on the end of the cylinder bore and compresses the spring (2). Hydraulic fluid can then flow past the three-legged distance piece (3) and seal (1) either to or from the reservoir.

B. Clutch Released Condition

Initial movement of the push rod (9) and plunger (7) releases the valve shank (4) and permits the spring (2) to press the valve shank (4) and seat (1) against its seat. This cuts off communication between the cylinder and reservoir. Continued movement of the plunger displaces fluid through the hydraulic pipelines and releases the clutch.

Maximum stroke available—  
1.38" (35.05 mm.)

Stroke position at maximum cut off—  
0.099" (2.5 mm.)



- |                         |                   |                    |
|-------------------------|-------------------|--------------------|
| 1 Valve seal            | 6 Spring retainer | 11 Circlip         |
| 2 Spring (valve seal)   | 7 Plunger         | 12 Push rod stop   |
| 3 Distance piece        | 8 Plunger seal    | 13 Plunger seal    |
| 4 Valve shank           | 9 Push rod        | 14 Fluid reservoir |
| 5 Plunger return spring | 10 Dust cover     |                    |

Fig. 4. Section through clutch master cylinder

## CLUTCH MASTER CYLINDER

**To Remove (Fig. 5)**

Proceed as follows:—

1. Empty the master cylinder through the clutch slave cylinder bleed nipple.
2. Pull back the rubber dust excluder.
3. Withdraw the clevis pin securing the push rod to the pedal.
4. Uncouple the hydraulic pipeline from the master cylinder.
5. Remove the bolts (16) from the master cylinder mounting flange and withdraw the unit from the bulkhead.

**NOTE :** Extreme cleanliness is essential when dealing with any part of the hydraulic system. Component parts should be cleaned in hydraulic fluid or alcohol.

**To Dismantle (Fig. 6)**

1. Remove the circlip (11) and the push rod stop (12) and push rod (9).
2. Withdraw the plunger (7) and recuperation valve assembly (19) from the cylinder bore.
3. Using a small screwdriver, lift the tag on the spring retainer (6) over the flanged end of the plunger (7) and detach the recuperating valve assembly.
4. Release the valve shank (4) from the spring retainer (6) by manoeuvring the flange on the stem through the eccentrically positioned hole in the end face of the spring retainer. The spring (5), distance piece (3) and spring (2) may now be withdrawn from the valve shank (4).
5. Remove the valve seal (1) from the shank (4) by carefully easing it off with the fingers.
6. Similarly, detach the rubber seals (8) and (13) from the piston grooves.


**To Re-assemble**

Reverse the dismantling procedure and note the following:—

1. When fitting the rubber seals, apply hydraulic fluid to ease their entry into the bore of the cylinder and ensure that their lips face forward.
2. Avoid trapping the spring (2) between the valve shank locating shoulder and the distance piece (3). The washer must be fitted with its domed side adjacent to the valve shank face.

**To Refit**

Reverse the removal operations, refill with hydraulic fluid and bleed the system as described on page 2-106.



- |                    |                            |
|--------------------|----------------------------|
| 1 Master cylinder  | 10 Pedal bracket           |
| 2 Bolt             | 11 Rubber dust excluder    |
| 3 Spring washer    | 12 Split pin               |
| 4 Return spring    | 13 Plain washer            |
| 5 Pivot pin        | 14 Clevis pin              |
| 6 Circlip          | 15 Master cylinder bracket |
| 7 Pedal rubber     | 16 Bolt                    |
| 8 Pedal            | 17 Spring washer           |
| 9 Pedal pivot bush |                            |

Fig. 5. Exploded clutch pedal and bracket assembly




Fig. 6. Exploded clutch master cylinder  
Annotations are given under Fig. 4.




Fig. 7. Location of clutch slave cylinder (Vitesse)




Fig. 8. Clutch release bearing (Vitesse)




Fig. 9. Clutch release lever attachment (Vitesse)

### SLAVE CYLINDER (Fig. 12)

#### To Remove

Drain the hydraulic system by attaching a tube to the bleed nipple (25) and pumping the clutch pedal. Remove the tube and disconnect the hydraulic feed pipe (26).

Release the slave cylinder by removing the bolt/s (34).

#### To Refit

Reverse the removal procedure, ensuring that the push rod is correctly engaged in the piston cup. Re-connect the hydraulic feed pipe, refill and bleed the system.

#### To Dismantle

Remove the cover (32), circlip (31) and shake out the piston (30) and spring (28). Detach the seal (29) from the piston.

#### To Re-assemble

Lubricate the components with hydraulic fluid and assemble the seal (29) to the piston (30), placing the sealing lip towards the closed end of the cylinder (27). Insert the spring (28) and piston (30) into the cylinder bore. Spring the circlip (31) into position and re-attach the rubber cover (32).

#### Bleeding the Hydraulic System

The presence of air in the system will prevent the proper functioning of the clutch and will necessitate bleeding to expel the air.

During the bleeding operation, keep the reservoir topped-up with new brake fluid and ensure that the level does not fall below half full. If the reservoir is allowed to empty, air will be drawn into the system, necessitating re-bleeding.

With the aid of a second operator, bleed the system as follows:—

Wipe the bleed nipple clean, attach a length of rubber tubing to the nipple and allow the end of the tube to hang in a glass jar partly filled with brake fluid.

Unscrew the bleed nipple about a quarter turn, and, giving fast full strokes with a slight pause between each stroke, pump the clutch pedal until the clutch fluid entering the glass container is free from air bubbles.

**IMPORTANT.** Ensure that the piston returns to its maximum travel at the end of each stroke. A sticking piston will be obvious from the feel of the pedal.

Finish with a few slightly faster applications of the pedal, using the bottom half of the stroke, until it is apparent that all air has been excluded. Close the bleed screw during the last pedal application, or with the pedal fully depressed,






Fig. 10. Clutch release bearing and operating lever (Herald 1200, 12/50 and Spitfire)

### CLUTCH RELEASE BEARING

#### To Remove

Referring to Fig. 11 for Herald 1200, 12/50 and Spitfire vehicles:— drive the pin (17) from the clutch housing and remove the operating lever (22). Drive out the pins (20) and release the bearing sleeve (15) by extracting the plugs (16). Withdraw the bearing (14) from the sleeve.

Referring to Fig. 9 for Vitesse vehicles: - remove the slave cylinder attachment bolts (1) and move the push rod (2) clear of the release lever (3). Unclip the lever from its spherical pivot pin (4), withdraw the bearing sleeve (5) and take off the bearing (6).

#### To Refit

Reverse the removal procedure.

### CLUTCH

#### Removal

Remove the gearbox as described on page 2-205. Progressively unscrew the clutch attachment setscrews and detach the cover assembly and driven plate from the flywheel face.




Fig. 11. Exploded operating lever assembly (Herald 1200, 12/50 and Spitfire)




Fig. 12. Exploded slave cylinder details




Fig. 13. Exploded clutch unit (Herald 1200, 12/50 and Spitfire)





Fig. 14. Clutch assembly fixture No. 99A

**Dismantling (Fig. 14)**

The Churchill clutch assembly fixture No. 99A is recommended for servicing the clutch units fitted to the Herald 1200, 12/50, Spitfire and Vitesse models. The method of dismantling is as follows:--

1. Position the spacers (6) on the baseplate and place the clutch unit over the spacers, with the release levers as near as possible over the spacers.
2. Mark the pressure plate, cover and toggles to facilitate re-assembling them to their original positions. Fit the operating handle (8) to the baseplate, and clamp the clutch unit by levering the handle. Secure the unit to the baseplate with six setscrews (7). Remove the operating handle.
3. Referring to Fig. 13, hold the release lever plate (13) down and detach the retaining springs (9). Remove the release lever plate.



4. Continue to dismantle the clutch as follows: --

(a) HERALD 1200, 12/50 AND SPITFIRE (Fig. 13)

Release the lockplates (11) and remove the nuts (12), lockplates (11), bridge pieces (10) and toggle levers (8). Progressively slacken the setscrews retaining the cover to the baseplate and lift off the cover (5), retainers (4), springs (9) and pressure plate (2).

(b) VITESSE (Fig. 15)

Break the staking on the adjusting nuts (12) and remove them. Progressively release the baseplate setscrews and detach the cover (11), toggle levers (4), eyebolts (6), pins (3), struts (5) and springs (9). Detach the pressure plate (2).




Fig. 16 Attaching clutch unit to Churchill fixture (Herald and Spitfire).




Fig. 17 Releasing lockplates (Herald and Spitfire).




Fig. 18. Removing clutch cover assembly (Herald and Spitfire)




Fig. 19. Adjusting toggle height (Herald and Spitfire)




Fig. 20. Assembling toggles to pressure plate (Herald and Spitfire)



Fig. 21. Gauge finger fitted prior to adjusting toggle height (Vitesse)

#### Re-assembly

##### (a) HERALD 1200, 12/50 AND SPITFIRE


Position the pressure plate (2) on the baseplate, with the distance pieces positioned under the lever fulcrum studs. Fit the springs (3), cups (4) and cover (5). Tighten the cover down to the baseplate.

Assemble the toggle levers (8), bridge pieces (10), lockplates (11) and nuts (12). Fit the gauge finger (4), Fig. 14, with adaptor No. 5 and adjust the nuts (12) until the gauge finger just contacts the ends of each lever (8), Fig. 19. Remove the gauge and stud, fit the operating lever and operate the clutch a few times. Refit the stud and gauge, re-check the lever height and adjust if necessary. When correctly adjusted, bend up the lock-plates (11) against the nuts (12). Fit the release plate (13) and secure it with the springs (9). Check the run-out of the release plate with a clock gauge as shown on Fig. 23. This must not exceed 0.015" (0.38 mm.). If satisfactory, remove the clutch from the baseplate.

##### (b) VITESSE

Position the pressure plate (2) on the baseplate with the distance pieces positioned under the lever fulcrum studs. Assemble the pressure plate (2), springs (9), eyebolts (6), pins (3), studs (5), toggles (4), anti-rattle springs (10) and fit the cover (11). Secure the cover to the baseplate with setscrews and fit the nuts (12) to the eyebolt threads (6).

Adjust the toggle height as described under "Adjustment" and fit the release plate (7) and springs (8). Check the run-out of the release plate with a clock gauge (Fig. 23). This must not exceed 0.015" (0.38 mm.). If satisfactory, remove the clutch from the baseplate.



1972

Fig. 22. Using a press and wood blocks as an alternative to Churchill fixture No. 99A

#### Refitting the Clutch Unit

Check the clutch driven plate for run-out by mounting it on a mandrel between lathe centres and rotating it slowly whilst the plunger of a dial indicator bears against the outside face of the friction lining.

The maximum run-out must not exceed  $0.035''$  ( $0.23$  mm.). Prise the plate in the required direction until the run-out is within specified limits.

Check the flywheel clutch face for satisfactory condition, and refit the clutch unit as follows:—

With the longer boss of the splined hub towards the gearbox, offer the driven plate up to the flywheel and centralise it by using a special shaft which fits the splined bore of the hub and locates in a bush at the rear of the crankshaft. A discarded input shaft sawn off to suit can be conveniently used for this purpose.

Locate the cover assembly over the two dowels and secure the cover pressing by evenly tightening the setscrews to the correct torque. Remove the centring shaft.




Fig. 23. Using a dial gauge to check run-out of release plate





Fig. 24. Centralizing the clutch driven plate



- 1 Driven plate
- 2 Pressure plate
- 3 Rivet
- 4 Fulcrum ring
- 5 Diaphragm spring
- 6 Rivet
- 7 Drive strap
- 8 Cover pressing
- 9 Retaining clip
- 10 Rivet
- 11 Rivet
- 12 Balance weight

Fig. 25. Clutch details

#### SPITFIRE MK. II

#### CLUTCH UNIT

The diaphragm spring clutch unit fitted to the Spitfire Mk. II must not be dismantled for any reason.

Should any fault develop in the unit, a complete replacement assembly must be fitted.

## DIMENSIONS AND TOLERANCES

PARTS AND DESCRIPTION	DIMENSIONS NEW		CLEARANCE NEW		REMARKS
	ins.	mm.	ins.	mm.	
<b>Input Shaft</b>					
Input shaft spigot bush. Length ..	1.06	26.924			
Bore in crankshaft. . . . .	0.754	19.1516	0.002	0.0508	
	0.753	19.1262	0.0005	0.0127	
Number of splines . . . . .	10				
Dia. of journal for front ball race ..	1.0005	25.4127	-0.0008	-0.0103	
	1.0001	25.4025	-0.0001	-0.0025	
Input shaft spigot race ball dia. . .	0.688	17.475			Torrington needle roller bearing. Press fit in bore.
	0.687	17.449			
<b>Mainshaft</b>					
Spigot dia. . . . .	0.5000	12.7			Runs in Torrington needle roller bearing.
	0.4995	12.6873			
2nd/3rd gear bush journal dia. . .	0.8738	22.1945	0.0027	0.0686	
	0.8733	22.1818	0.0012	0.0305	
Centre ball race journal dia. . . .	1.0004	25.4101	+0.0002	0.0051	Transition fit
	1.0000	25.4	-0.0002	-0.0051	
Mainshaft 2nd/3rd gear circlip groove width . . . . .	0.079	2.0066	0.010	0.254	
	0.076	1.9304	0.004	0.1016	
Mainshaft 2nd/3rd gear circlip groove bottom dia. . . . .	0.795	20.193			
	0.790	20.0660			
Mainshaft length between front end of 1st gear splines and front face of 2nd/3rd gear circlip groove ..	2.609	66.2686			
	2.607	66.2178			
Mainshaft rear ball race journal dia. . .	0.7504	19.067	0.0006	0.0152	
	0.7501	19.055	0.0001	0.0025	
<b>Mainshaft Gears and Bushes</b>					
3rd speed gear—I.D. . . . .	1.0945	27.8003	0.0037	0.0940	
	1.0935	27.7749	0.0007	0.0178	
Width of hub between thrust faces ..	0.996	25.2984			
	0.998	25.3492			
3rd speed bush—I.D. . . . .	0.876	22.2504	0.0027	0.0686	
	0.875	22.2250	0.0012	0.0305	
3rd speed bush—O.D. . . . .	1.0928	27.7571	0.0037	0.0940	
	1.0908	27.7063	0.0007	0.0178	
Length of bush . . . . .	1.002	25.4508	0.002	0.0508	End float of gear on bush.
	1.000	25.4	0.006	0.1524	
2nd speed gear—I.D. . . . .	1.0945	27.8003	0.0027	0.0686	
	1.0935	27.7749	0.0012	0.0305	
Width of hub between thrust faces ..	1.121	28.4734			
	1.123	28.5242			
2nd speed bush—I.D. . . . .	0.876	22.2504	0.0027	0.0686	
	0.875	22.2250	0.0012	0.0305	
2nd speed bush—O.D. . . . .	1.0928	27.7571	-0.0037	-0.0940	
	1.0908	27.7063	-0.0007	-0.0178	

The minus sign indicates an interference fit

## GEARBOX — DIMENSIONS AND TOLERANCES — continued

PARTS AND DESCRIPTION	DIMENSIONS NEW		CLEARANCE NEW		REMARKS
	ins.	mm.	ins.	mm.	
HERALD 1200, 12/50 & SPITFIRE					
Countershaft gear cluster bore—both ends	0.7815	19.85			
	0.7805	19.825			
Depth of bore (rear)	1.53	38.862			
Depth of bore (front)	1.44	36.576			
VITESSE					
Countershaft gear cluster bore—both ends	0.8434	21.3224			
	0.8439	21.4351			
Depth of bore (rear)	1.025	26.035			
Depth of bore (front)	0.962	24.4348			
Clutch Release Bearing Details					
O.D. front cover extension	1.249	31.725	-0.045	-1.143	
	1.247	31.673	0.0015	0.0381	
Release bearing sleeve— I.D.	1.2515	31.788	0.0035	0.0889	
	1.2505	31.7627	0.0015	0.0381	
Release bearing sleeve journal— O.D.	1.5007	38.1177	0.0012	0.03048	
	1.5002	38.1051	0.0002	0.00508	
Clutch release bearing— I.D.	1.500	38.1	0.0012	0.03048	
	1.4995	38.0873	0.0002	0.00508	
Clutch release bearing— O.D.	2.625	66.675			
—Length	0.670	17.018			
Ball and Needle Roller Bearing Details					
Front and centre ball races—			0.0035	0.0889	
Hoffman MS. 10K.—O.D.	2.4995	63.487	Nil	Nil	
	2.4990	63.475	-0.001	-0.0254	
I.D.	1.0002	25.405	-0.0008	-0.02032	
	0.9997	25.392	-0.001	-0.0254	Transition fit.
Mainshaft spigot bearing					
Torrington needle roller No. B.810 :					
I.D.	0.5	12.7			
O.D.	0.6875	17.4625			
Length	0.625	15.875			Stamped end must face outwards.
Depth of press fit into constant pinion shaft end face	0.47	11.938			
Rear extension ball race					
Hoffman I.S.8—O.D.	1.8747	47.617	-0.001	-0.0254	
	1.8742	47.605	-0.000	-0.0000	
—I.D.	0.7502	19.055	-0.0006	-0.0152	
	0.7498	19.045	-0.0007	-0.0175	



GEARBOX — DIMENSIONS AND TOLERANCES — continued

PARTS AND DESCRIPTION	DIMENSIONS NEW		CLEARANCE NEW		REMARKS
	ins.	mm.	ins.	mm.	
<b>Mainshaft Gears and Bushes—continued</b>					
Length of bush	1-127	28-6258	0-002	0-0508	End float of gear on bush.
	1-125	28-575	0-006	0-1524	
2nd/3rd gear thrust washer	0-154	3-9116			
	0-152	3-8608			
2nd gear thrust washer	0-124	3-1496			
	0-122	3-0988			
3rd gear circlip washer	0-124	3-1496			
	0-122	3-0988			
2nd/3rd gear mainshaft circlip thickness	0-072	1-8288	0-010	0-254	
	0-069	1-7526	0-004	0-1016	
2nd/3rd mainshaft circlip—I.D.	0-79	20-066			
2nd/3rd mainshaft circlip—O.D.	0-94	23-876			
Mainshaft maximum permissible end float of 2nd/3rd gears and bushes, thrust washers and circlip on mainshaft	0-004	0-1016	0-012	0-3048	Recommended end float 0-004" to 0-010" (0-1016 to 0-254 mm.). Obtain if necessary by selective assembly of components.
	0-019	0-4824	0-004	0-1016	
Hub width between thrust faces	0-849	21-5646			
	0-839	21-3106			
<b>Reverse Gear</b>					
Pinion—I.D. bush	0-6580	16-7132	0-003	0-0762	
	0-6573	16-6954	0-0018	0-04572	
Reverse gear spindle—Main dia.	0-6555	16-6497	0-003	0-0762	
	0-6550	16-6370	0-0018	0-04572	
End dia.	0-5618	14-2697	0-0015	0-0381	
	0-5613	14-2570	0-0002	0-0051	
<b>Countershaft and Gears</b>					
Countershaft O.D.	0-6555	16-6497	0-003	0-0762	
	0-6550	16-6370	0-018	0-0457	
Countershaft—Length	8-75	222-25			
Countershaft bushes—Length	1-385	35-18			
	1-365	34-67			
I.D. Bushes—Countershaft gears	0-6580	16-713	0-003	0-0762	
	0-6573	16-6954	0-018	0-0457	
Distance between end thrust faces	5-971	151-6634			
	5-969	151-6126			
Thickness of front thrust washer	0-125	3-175			
	0-123	3-1242			
Thickness of rear thrust washer	0-068	1-7272			
	0-066	1-6764			
Thickness of rear rotating thrust washer	0-0665	1-6891			
	0-0635	1-6129			
Overall permissible end float			0-0125	0-3125	Obtain if necessary by selective assembly of thrust washers.
			0-0015	0-0381	

**EXPLODED ARRANGEMENT OF GEARBOX  
DETAILS**

GEARBOX




Fig. 1. Exploded Arrangement of Gearbox Details

Key to Fig. 1

- |                                 |                                  |  |
|---------------------------------|----------------------------------|--|
| 1 Knob                          | 45 Nut                           | 88 Thrust washer   |
| 2 Locknut                       | 46 Remote control shaft (rear)   | 89 2nd speed mainshaft gear  |
| 3 Gear change lever             | 47 Bolt                          | 90 Thrust washer   |
| 4 Cover                         | 48 1st/2nd selector fork         | 91 Bushes  |
| 5 Shield                        | 49 Reverse selector              | 92 3rd speed mainshaft gear  |
| 6 Plate                         | 50 Interlock ball                | 93 Thrust washer   |
| 7 Spring                        | 51 Interlock plunger             | 94 Circlip   |
| 8 Circlip                       | 52 Top/3rd selector fork         | 95 3rd/top synchro sleeve  |
| 9 Spring                        | 53 Taper locking pin             | 96 3rd speed synchro cup   |
| 10 Nylon sphere                 | 54 Clutch housing                | 97 3rd/top inner synchro hub   |
| 11 Stepped nylon washer         | 55 Pin                           | 98 Top synchro cup   |
| 12 Bush                         | 56 Clutch release mechanism      | 99 Circlip   |
| 13 Washer                       | 57 Wedge lock bolt               | 100 Distance washer  |
| 14 Lever end                    | 58 Plain washer                  | 101 Circlip  |
| 15 Reverse stop pin             | 59 Bolt                          | 102 Ball race  |
| 16 Locknut                      | 60 Gasket                        | 103 Oil deflector  |
| 17 Bolt                         | 61 Dowel                         | 104 Input shaft  |
| 18 Welch plug                   | 62 Rear extension                | 105 Torrington needle roller bearing   |
| 19 Gasket                       | 63 Rubber "O" ring               | 106 Mainshaft  |
| 20 Spring                       | 64 Peg bolt                      | 107 Distance washer  |
| 21 Plunger                      | 65 Speedo drive gear housing     | 108 Driving flange   |
| 22 Taper locking pin            | 66 Speedo drive gear             | 109 Spring washer  |
| 23 1st/2nd selector shaft       | 67 Extension ball race           | 110 Nut  |
| 24 3rd/top selector shaft       | 68 Oil seal                      | 112 Countershaft   |
| 25 Reverse selector shaft       | 69 Gearbox mounting rubber       | 113 Peg bolt   |
| 26 Interlock ball               | 70 Mounting bracket              | 114 Spring Washer  |
| 27 Nut                          | 71 Nut                           | 115 Rear fixed thrust washer   |
| 28 Rubber "O" ring              | 72 Bolt                          | 116 Rear rotating thrust washer  |
| 29 Top cover                    | 73 Gasket                        | 117 Countershaft gear cluster  |
| 30 Gasket                       | 74 Clutch slave cylinder bracket | 118 Countershaft bush  |
| 31 Selector ball-end            | 75 Sump plug                     | 119 Front fixed thrust washer (Vitesse has needle rollers and retaining rings) |
| 32 Bolt                         | 76 Speedo driving gear           | 120 Reverse gear bush  |
| 33 Dowel                        | 77 Circlip                       | 121 Reverse gear   |
| 34 Washer                       | 78 Distance washer               | 122 Reverse gear actuator  |
| 35 Bonded rubber bush           | 79 Ball race                     | 123 Actuator pivot   |
| 36 Gear change extension        | 80 1st speed gear                | 124 Plain washer   |
| 37 Reverse stop                 | 81 Spring                        | 125 Nylon nut  |
| 38 Bolt                         | 82 Shim                          | 126 Reverse gear shaft   |
| 39 Nylon nut                    | 83 Synchronesh ball              | 127 Reverse shaft retaining bolt   |
| 40 Screw                        | 84 Plunger                       | 128 Spring washer  |
| 41 Mills pin                    | 85 Ball                          |  |
| 42 Remote control shaft (front) | 86 2nd speed synchro hub         |  |
| 43 Taper locking pin            | 87 2nd speed synchro cup         |  |
| 44 Fork                         |                                  |  |

### GEARBOX REMOVAL

#### To Remove Gearbox Leaving Engine in Position

Raise the vehicle on a ramp or support it on axle stands. Disconnect the battery, drain the gearbox and remove the front seats and carpets.

Referring to Fig. 2, release the casting (2), fitted only to the Spitfire, by removing the bolts (1) and (3) and by detaching the tachometer drive cable from the instrument.

The following instructions are common to all models:—

Remove the gear lever knob and grommet (4).

Release the gearbox cover (7) by removing the fasteners (5), and (6) and three screws on the engine side of the bulkhead.

Remove the attachments (8), withdraw the slave cylinder (9) and allow it to hang on its pipe (10).

Take out the bolts (11) and completely remove the propeller shaft.

Release the front exhaust pipe from the manifold and clutch housing.

Remove the starter motor and release the speedo drive (12) from the gearbox extension.

Remove the nuts (13), lift off gear change extension (14) and fit a cardboard cover to prevent the entry of foreign matter.

Remove the nuts (15), jack up under the sump until the gearbox extension clears the mounting bracket and take off the mountings (16).

Remove the clutch housing flange attachments (17) and withdraw the gearbox.

#### To Refit

Reverse the removal procedure.

**IMPORTANT:** Do not allow the gearbox to hang on the clutch spigot shaft whilst fitting it to the engine.

Refill the gearbox with oil.

Fig. 2.  
Spitfire facia  
support  
attachments




Fig. 3.  
Gearbox cover  
fixings





Fig. 4. Herald 1200, 12/50 and Spitfire gearbox attachments




Fig. 5. Vitesse gearbox attachments



Release cap (4) as shown on Fig. 9. Lift the lever assembly out of the extension and remove the cups (5) and (6), together with the outer spring (7).

Remove the snap ring (8) from the gear lever and detach the inner spring (9) and Nylon sphere (10). Detach the reverse stop plate (37) by removing the two countersunk screws (40). Unscrew reverse stop bolt (15) from gear lever.

Remove the threaded taper locking pin (43) and withdraw the shaft (42) from the extension casing (36) and selector (31).

Remove the rubber 'O' rings from the extension casing bore (Fig. 11).

Detach the locknut (45) and unscrew the pivot bolt (32) from the coupling fork (44). Withdraw the shaft (46) from the coupling, together with fibre washers (34).

Detach the coupling fork from shaft (42) by drifting out the hollow spring steel pin (41).

Dismantle the selector shaft and fork assemblies by driving out the Welch plugs (18) with a  $\frac{1}{8}$ " (3.17 mm.) dia. pin punch as shown in Fig. 10 ensuring that the selector shafts are clear.

Remove the threaded tapered locking pins (53) and (22) from the selector shafts and forks.

Push the selector shaft (25) out of the cover, followed by items (23) and (24). Remove the two interlock balls (26), (50), plunger (51), three selector plungers (21) and three springs (20).

Fig. 8.  
Control shaft  
to gearlever  
attachment  
details




Fig. 9.  
Turning the  
cover to release  
the gearlever  
assembly




Fig. 10.  
Removing  
selector shaft  
welch plugs





Fig. 11.  
Removing  
rubber 'O' ring  
from extension







Fig. 13.



### Clutch Housing

#### HERALD 1200, 12/50 AND SPITFIRE

Drift out the pivot pin (55) from the clutch housing (54) and remove the operating lever assembly (56). Release the clutch housing by removing the slave cylinder bracket (74), four bolts (59) and one Wedglock bolt (57).

#### VITESSE

Unclip the release lever pressing (1) from the pivot ball (2) and remove the lever and bearing (3). Remove the bolts (59) and (57) to release the clutch housing.




Fig. 14.  
Withdrawing  
speedometer  
driving pinion




Fig. 15.  
Removing  
rear extension

### Rear Extension

Remove the nut (110), and spring washer (109) and withdraw the driving flange (108) from the mainshaft (106).

Withdraw six bolts (72) and one longer bolt securing the extension (62) to the gearbox. Remove the extension by lightly tapping the mounting lugs with a hide-faced hammer. Remove the paper joint washer (73) and distance washer (107) from the mainshaft.

Remove the peg bolt (64) and withdraw the housing (65) from the extension (62). Remove the gear and shaft from the housing and detach the rubber 'O' ring.

Eject the ball race (67) and oil seal (68) from the extension.




Fig. 16. Using Churchill main tool 4235A with adaptor S.4235A-2 to remove input shaft assembly

**Countershaft**

**HERALD 1200, 12/50 AND SPITFIRE**

Extract the countershaft locating bolt (113) and eject the countershaft (112), permitting the countershaft gear cluster to drop clear of the mainshaft gear.

**VITESSE**

Eject the countershaft and retain the needle roller bearings by inserting a length of rod 0.655" (16.64 mm.) dia. x 5.5" (139.7 mm.) long.

**Input Shaft**

Utilizing Churchill tool as shown in Fig. 16, withdraw the input shaft assembly from the gearbox.

Remove the two circlips (99), (101), the distance washer (100), then place in a press and extract the ball race (102) and oil deflector (103), Fig. 18.

**Mainshaft and Gears**

Using a hollow drift, drive the mainshaft (106) rearwards, as shown on Fig. 20, until the rear ball race (79) is clear of its housing.

Tilt the mainshaft assembly (Fig. 19) and extract the synchro unit (92), (95) and the synchro cups (96) and (98).




Fig. 7. Withdrawing the layshaft




Fig. 18. Using Churchill press and adaptors to remove input shaft bearing




Fig. 19. Tilting the mainshaft and removing synchro unit






Fig. 20. Driving the mainshaft rearwards to allow the shaft to be tilted






Re-position the mainshaft and, using a special extractor, remove the circlip (94).

**Fig. 21.** Using Churchill tool S.144 to remove mainshaft circlip




Again drive the mainshaft rearwards and as this is now being finally withdrawn remove the mainshaft details as they are released from the shaft.

**Fig. 22.** Removing mainshaft details



Completely dismantle the mainshaft by removing the nylon speedo driving gear (76), the circlips (77) and (101), distance washer (78) and ball race (79).

**Fig. 23.** Using Churchill press and adaptors to remove speedometer driving gear




Eject the reverse idler gear (121) rearwards. Remove the dowel bolt (127) and withdraw the reverse idler gear shaft (126).

Remove the rear thrust washer (115) and, after lifting the gear cluster (117) from the casing, remove the front thrust washer (119) and the rear rotating thrust washer (116).

**Fig. 24.** Ejecting the reverse pinion


Drift out worn countershaft bushes and fit new ones.

Fig. 25. Showing (left) the Torrington needle roller bearings fitted to Vitesse countershaft and (right) the bushes fitted to Herald 1200 and Spitfire.




Complete the dismantling of the transmission case by unscrewing the nut (125) and removing the operating lever (122) and pivot pin (123).

Fig. 26. Reverse pinion and lever details




Both synchro units are dismantled by withdrawing their outer synchro sleeves. It should be noted that spring-loaded balls are retained by these sleeves and to prevent losing any balls or springs it is advisable to cover each unit with clean rag whilst withdrawing its sliding member.

Fig. 27. Dismantled "Top" and "Third" synchro unit



In addition to the synchro balls and springs fitted to the second speed synchro unit, this is also provided with an interlock plunger and ball.

Fig. 28. Dismantled second gear synchro unit






Fig. 29.  
Using the  
layshaft to  
centralise the  
front thrust  
washer




Fig. 30.  
Using feeler  
gauges to  
measure  
countershaft  
end float




Fig. 31.  
Inserting  
reverse pinion




Fig. 32. Exploded countershaft and reverse pinion details

## ASSEMBLY OPERATIONS

Having thoroughly cleaned and carefully examined the gearbox components, renew all defective and doubtful items and proceed to re-assemble them as follows:

### Countershaft

Using heavy grease to support it, smear the steel face of the front countershaft thrust washer (119) and locate this in the gearcase, placing the bronze face towards the gear with its tag in the recess provided. Centralise the washer by inserting the rear end of the countershaft (112) through the gearcase as shown on Fig. 29.

Attach the rear rotating thrust washer (116) in a similar manner, engaging its tags in the rear slotted face of the countershaft gear cluster, then lower the assembly into the casing.

Push the gear cluster towards the front thrust washer until this is nipped, then having smeared the rear thrust washer (115) with grease, insert this between the casing and the rotating thrust washer (116) and correctly position its tag in the recess provided.

To enable the countershaft gear end-float to be measured, it will now be necessary to align the thrust washers and the gear cluster with appropriate holes in the gearbox, then install the countershaft (112).

Using feeler gauges inserted between the rear fixed thrust washer (115) and the adjacent rotating washer (116) measure the gear end-float as shown on Fig. 30.

Although permissible limits of 0.0015" to 0.0125" (0.04 to 0.31 mm.) are quoted on page 2-203, an end-float of 0.006" (0.15 mm.) is recommended. Adjust by selective assembly of available thrust washers. If it is necessary to reduce the thickness of any thrust washer, **DO NOT REMOVE METAL FROM THE BRONZE FACE.**

Eject the countershaft (112) allowing the gear cluster to drop to permit installation of the mainshaft assembly.

### Reverse Idler Gear

Screw the pivot pin (123) into the reverse idler gear selector lever (122) until a thread protrudes through the attached boss on the lever, then assemble this in the gearcase and secure it with a nut (125) and plain washer (124).

Position the reverse idler gear shaft into the casing and, having aligned its locating hole, secure the shaft by inserting the locking pin (127) with lock washer (128) and tightening.

Slide the reverse idler gear (121) over the shaft and engage its annular groove with the pin attached to the lower end of the operating lever (122) as shown on Fig. 31.

**Synchro Units**

1. Assemble synchro springs (81), balls (83) and shims (82) to the 3rd/Top synchro hub (97). Fit the outer sleeve (95).
2. Repeat with 2nd synchro unit.
3. Test axial release load which should be:  
 3rd/Top: 19/21 lbs. (8.618/9.525 kg.);  
 2nd: 19/21 lbs. (8.618/9.525 kg).

**NOTE:** If the actual release loads differ from those specified, adjust the number of shims beneath each synchro spring to give the correct loading.




Fig. 33. Checking Top/3rd synchro release load. A spring balance is attached to the hook and the pull pressure increased to the point of release




Fig. 34. Second speed synchro unit, showing "master" spline (1), the interlock ball (2) and the synchro ball (3)




Fig. 35. Measuring gear end-float

**2nd and 3rd Mainshaft Gear End Float on Bushes**

Measure the end float of each gear on its respective bush as shown on Fig. 35. This should be 0.002" to 0.006" (0.05 to 0.1524 mm.). Fit a new bush to increase float; decrease float by reducing bush length.

**CAUTION:** Reduced bush length will increase end float of bushes on mainshaft.

**Overall End Float of Bushes (Mainshaft)**

Assemble the thrust washer (88), bush (91), washer (90), bush (91) and thrust washer (93) to the mainshaft. Secure the assembly with a discarded half-circlip (94) and measure the total end float of the bushes and thrust washers on the mainshaft. If necessary, adjust the end float by selective use of thrust washers to give 0.004" to 0.010" (0.1016 to 0.254 mm.).




Fig. 36. Measuring overall bush end-float




Fig. 38. Refitting the speedometer drive gear.




Fig. 37. Exploded mainshaft details




Fig. 39. Refitting the mainshaft bearing




Fig. 40. Assembling the thrust washer with its scrolled face towards the gears




Fig. 41. Using Churchill tool S.145 to install the mainshaft circlip

#### Mainshaft Assembly

Placing the circlip groove to the rear, press the ball race (79) on the mainshaft (106), followed by the distance washer (78) and the Seeger circlip (77), which must be correctly located in the mainshaft groove.

Next press the speed drive gear (76) on to the mainshaft as shown on Fig. 38 and spring the large circlip (101) into the ball race groove.

Pass the mainshaft through the gearbox and, holding it as shown on Fig. 40, thread the mainshaft components on to the shaft in this order:—

1. Second gear synchro unit assembly with gear portion forward (make sure that the interlock plug (82) and ball (83) are correctly located in this unit).
2. Second speed synchro cup (make sure that the three lugs locate in the synchro hub).
3. Rear thrust washer (88) with its scrolled face forward.
4. Second speed gear (89) and bush (91).
5. Centre thrust washer (90).
6. Third speed gear (92) and bush (91).
7. Front thrust washer (93) with its scrolled face rearward.

Utilising a special tool as shown on Fig. 41 install the circlip (94). Placing the longer boss of the inner synchro member forwards, slide the "top and third" synchro unit with baulk rings attached over the mainshaft and complete the installation by driving the rear ball race into its housing.




Fig. 42. Exploded input shaft details




Fig. 43. Details of drift used for driving the needle bearing into the pinion

**Input Shaft**

Removal of the needle roller bearing (105) is not possible and necessitates replacement of the input shaft (104). Use a special drift, detailed on Fig. 43, to ensure that the new bearing is positioned at the correct depth.

Smear the oil deflector plate (103) with grease and place it over the spigot on the input shaft. Avoiding any disturbance of this plate, press the ball race (102) on to the shaft as shown on Fig. 44. Secure the ball race by fitting the distance washer (100) and the circlip (99) ensuring that the latter is correctly located in its annular groove in the shaft.

Having installed the large circlip (101) on the ball race outer member and placed the "top" synchro cup (93) over its cone on the input shaft, offer up the assembly and as the ball race is being driven into its housing, simultaneously locate the baulk-ring lugs in their respective slots in the synchro hub as shown on Fig. 45.

**Countershaft**

Align the thrust washers and countershaft gear cluster by pushing a 0.655" (16.64 mm.) dia. rod, having a short taper on one end, through the gearbox and countershaft assembly. Then eject this tool with the actual countershaft, taking care to maintain contact between the two shafts whilst the former is being driven out. Secure the shaft by aligning the lock pin holes and inserting the lock pin (113) with the lock washer (114).

Fig. 44. Pressing the ball race onto the input shaft




Fig. 45. Installing the input shaft assembly




Fig. 46. Installing the layshaft and locking pin






Fig. 47.  
Fitting the  
rear oil seal




Fig. 48.  
Using a torque  
wrench to  
tighten the  
driving flange  
nut




Fig. 49.  
Inserting the  
speedometer  
drive pinion




Fig. 50.  
Position of  
front cover  
oil seal (Vitesse)

#### Rear Extension

Drive the ball race (67) into its bore in the rear end of the housing, followed by the oil seal (68) with the sealing lip facing forward (see Fig. 47).

Lubricate the speedometer drive shaft and insert this into its housing (65). Renew the rubber 'O' ring (63) if it is torn or perished.

Insert the drive gear assembly into the rear extension, aligning the location hole with the corresponding hole in the extension. Insert and tighten the peg bolt (64) and spring washer as shown in Fig. 49.

Feed the distance washer (107) over the end of the mainshaft and, after smearing the joint washer (73) with grease, locate this on the rear face of the gearbox.

Using a hollow drift to drive the rear ball race over the mainshaft, install the extension and fit the securing setscrews (72) with lockwashers.

Fit the driving flange (108), spring washer (109) and nut (110), tightening the latter to the correct torque.

#### Front Cover Oil Seal (VITESSE)

If necessary, extract the front cover oil seal and drive in new seal, with its sealing lip facing the rear of the gearbox, into the recess in the clutch housing.

Coat the paper joint washer (60) with grease, then assemble the washer and clutch housing (54) to the gearbox. In the case of the Vitesse, protect the oil seal by wrapping the input shaft clutch splines with adhesive tape. Secure the cover with one wedge-lock bolt (57), plain washer (58) and 4 bolts (59) with spring washers.

#### Re-Assembly

To re-assemble the clutch housing and clutch release mechanism, reverse the removal sequence and note the following:—

To prevent oil leakage, fit a new copper plated steel washer (58) beneath the lower bolt (57).

**Top Cover**

Having inserted the plungers and springs into the cover (Fig. 51) slide the "third and top" selector shaft (24) into the front end of the cover (29) whilst feeding the shaft into position, press down on the selector plunger, thus enabling the shaft to pass over it and through the appropriate selector fork. Continue to insert the shaft until its middle indent registers with the plunger, *i.e.*, the neutral position.

Repeat the procedure with the "reverse" shaft (25) and selector (49) until this also has reached the neutral position.

Insert the interlock plunger (51) into the "first and second" speed shaft (23) and assemble this and its selector fork (48) into the cover by adopting a similar procedure, except that this shaft also passes through the "third and top" selector fork.

Before the shaft (23) has been pushed to its neutral position, insert the two interlock balls (50) and (26) into the transverse bore connecting the shaft bores at the rear of the casting as shown on Fig. 53 then push the shaft further into the cover until its selector plunger registers with the middle indent, and the interlock balls and plunger are retained by the shafts.

Secure the forks and reverse selector by inserting threaded tapered locking pins. Using sealing compound around the edges of the Welch plugs (18) drift these into the ends of the selector shaft bores.

Ensure that all selectors and gears are in their neutral position, then place the joint washer and top cover assembly over the two dowels on the gearbox. Secure these items with setscrews and lockwashers, placing the longer ones at the rear.

Fig. 51.  
Fitting selector  
plunger and  
spring to  
top cover




Fig. 52.  
Inserting 1st/2nd  
speed selector  
shaft showing  
interlock  
plunger at  
position (a)




Fig. 53.  
Lid cut away to  
show interlock  
plunger and balls





Fig. 54. Fitting top cover assembly to gearbox





DIMENSIONS, CLEARANCES AND SPECIAL TOOLS

	Dimensions New		Clearances New	
	ins.	mm.	ins.	mm.
<b>Pump</b>				
Plunger diameter	.3742	9.504	-.0002	-.005
	.3746	9.514	-.0016	-.041
Pump body bore	.3748	9.52	-.0002	-.005
	.3758	9.545	-.0016	-.041
Pin for roller diameter	.2497	6.342	-.0007	-.018
	.2502	6.355	-.0022	-.056
Roller bore diameter	.251	6.375	-.0007	-.018
	.252	6.4	-.0022	-.056
<b>Pump Roller Bush</b>				
Outside diameter of bush	.3736	9.49	-.0005	-.013
	.3745	9.512	-.0023	-.058
Inside diameter of roller	.375	9.525	-.0005	-.013
	.3759	9.548	-.0023	-.058
Inside diameter of bush	.251	6.375	-.0007	-.018
	.2518	6.396	-.002	-.051
Outside diameter of pin	.2497	6.342	-.0007	-.018
	.2502	6.355	-.002	-.051
<b>Relief Valve</b>				
Relief valve plunger diameter	.3122	7.93	-.0002	-.005
	.3127	7.942	-.0013	-.033
Relief valve body bore diameter	.3129	7.958	-.0002	-.005
	.3135	7.963	-.0013	-.033
Operating piston diameter	.8735	22.187	-.0003	-.008
	.8742	22.205	-.002	-.051
Operating piston bores	.8745	22.212	-.0003	-.008
	.8755	22.237	-.002	-.051
Operating valve diameter	.2494	6.335	-.0003	-.008
	.2497	6.342	-.0012	-.03
Operating valve bore	.25	6.35	-.0003	-.008
	.2506	6.365	-.0012	-.03
<b>Gearbox Mainshaft</b>				
Diameter at hub bush	.9236	23.46	-.004	-.102
	.9244	23.48	-.006	-.152
Bush internal diameter	.9284	23.581	-.004	-.102
	.9296	23.612	-.006	-.152
Diameter at sunwheel	.873	22.174	-.003	-.076
	.874	22.2	-.005	-.127
Inside diameter of sunwheel bush	.877	22.276	-.003	-.076
	.878	22.301	-.005	-.127
Diameter at steady bearing	.562	14.275		
	.5625	14.287		
Planet pin diameter; 0.802 to 1 ratio (25%)	.4372	11.105		
	.4375	11.112		
<b>Miscellaneous</b>				
Clutch movement from direct to overdrive	.04	1.016		
	.06	1.524		
Hydraulic operation pressure				510 – 530 lbs/sq. in. (35.853 – 37.259 kg/cm.)
Ratio				25%

## SPECIAL TOOLS

L.178	Assembly ring for uni-directional clutch	L.208	Annulus spigot bearing remover
L.201	Dummy mainshaft	L.209	Annulus spigot bearing replacer
L.202	Annulus tail shaft remover and replacer (use with hand press RG.4221B)	L.210A	Clutch thrust ring bearing remover adaptor (use with adjustable puller No. 55)
L.203	Planet gear needle bearing remover and replacer	L.211	Tailshaft bearing nut wrench
L.204	Tail shaft oil seal remover adaptors (use with main tool 7657)	L.212	Tailshaft oil seal replacer
L.205	Oil pump body remover adaptor	L.213	Oil pump body key
L.183A	Oil pump body remover (main tool)	L.214	Speeds drive gear and bearing remover
L.183A2	Oil pump body remover adaptor	L.215	Clutch thrust ring bearing replacer
L.206A	Pump body replacer	7657	Oil seal remover (main tool)
L.207	Operating piston "O" ring fitting tool	RG.4221B	Handpress
		S.4221A	Handpress
		No. 55	Adjustable puller
		L.252	Operating piston remover

LAYCOCK DE NORMANVILLE OVERDRIVE

The overdrive is an additional gear unit, mounted on the rear face of the gearbox in place of the normal extension. When in operation, the unit provides a higher overall gear ratio than is available with the standard transmission. Reduced engine speed, resulting from the higher ratio, will reduce fuel consumption, increase engine life, and ensure greater driving comfort, providing the unit is used correctly.

The overdrive is operated by an electrical solenoid, controlled by a switch mounted on the steering column. An inhibitor switch, fitted in the electrical circuit, prevents engagement of overdrive in reverse, first and second gears.

Suggested minimum engagement speeds are: Top gear . . . . . 40 m.p.h.  
Third gear . . . . . 30 m.p.h.

Maximum disengagement speeds are: Top gear . . . . . At driver's discretion.  
Third gear . . . . . 70 m.p.h.

Disengagement of the overdrive at a speed higher than stated may cause damage from "over-revving".

WORKING PRINCIPLES

Overdrive Gears

The epicyclic gear train of the unit consists of a central sun gear, meshing with three planet gears which in turn mesh with an internally toothed annulus

Overdrive Disengaged (Fig. 1)

A cone clutch (A), mounted on the externally splined extension of the sun gear (G) is spring-loaded, by four clutch springs (L), via a thrust ring (K) and bearing (M), against the annulus (E) thus locking the gear train and permitting over-run and reverse torque to be transmitted.




Fig. 1. Overdrive disengaged

Overdrive Engaged (Fig. 2)

When overdrive is selected, two hydraulically operated pistons (I) acting against bridge pieces (J), move forward and, overcoming the spring pressure, cause the cone clutch (A) to engage the brake ring (B) with sufficient load to hold the sun gear (G) at rest. The planet carrier (D) can now rotate with the input shaft (H) causing the planet gears (F) to rotate about their own axis to drive the annulus at a faster speed than the input shaft, this being allowed by the free-wheeling action of the uni-directional clutch (C).




Fig. 2. Overdrive engaged





Fig. 3. Operating valve



- 1 Filter cover plate
- 2 Drain plug
- 3 Non-return valve plug
- 4 Relief valve plug

Fig. 4. Front casing viewed from underneath

### HYDRAULIC SYSTEM

Hydraulic pressure is developed by a plunger pump, cam operated, from the input shaft. The pump draws oil through a wire mesh filter and delivers it to the operating valve. A relief valve, incorporated in the system, controls the working pressure.

#### Operating Valve (Fig. 3)

In direct drive position, the ball valve (G) is seated in the casing thereby isolating the supply (B) from the operating cylinders (F).

When overdrive is selected, a solenoid causes cam (D) to rotate lifting the ball from its seat in the casing, and sealing the top of the valve, thus directing oil under pressure from port (B) to the operating cylinders (F).

When the valve is returned to the direct drive position, oil from the operating cylinders is exhausted down the hollow valve stem through the restrictor (E).

### LUBRICATION

Being interconnected, the gearbox and overdrive unit have a common oil level, indicated by a plug on the side of the gearbox. When draining the oil, remove the overdrive unit drain plug and gearbox drain plug. Access to the gauze filter, which must be removed and cleaned prior to refilling with oil, is effected by removing plate (1) (Fig. 4) retained by four setscrews.

Spill oil, from the relief valve, is diverted through drilled passages to a bush in the front casing, then into the mainshaft and along a central drilling to the rear bearing in the annulus. From the bearing, oil is passed, due to centrifugal force, through the uni-directional clutch to an oil thrower, from which it is picked up by a catcher on the planet carrier and then to the planet gears via the hollow bearing pins.

**NOTE :** All gearbox and overdrive units fitted to new cars are filled with a special oil, formulated to give all necessary protection to new gears. Under normal circumstances, this oil should not be changed, but may be topped up with any of the approved oils. If a new unit is fitted, or parts of an existing unit are renewed, the unit should be replenished with new special oil, supplied with a new unit, or ordered separately from the Spares Division.

Should difficulty be experienced in obtaining the special oil, use one of the approved lubricants listed on page 74. **ON NO ACCOUNT SHOULD ANTI-FRICTION ADDITIVES BE PUT INTO THE OIL.**

After refilling the gearbox and running the car for a short distance, re-check and top up the oil level to replace the oil which has been distributed around the hydraulic system. Always use clean oil and take great care to prevent the entry of foreign matter when any part of the casing is opened.

## SERVICING

## The Operating Valve

Access to the valve plug, on top of the unit, is gained by removal of the gearbox cover (page 2-205, Fig. 3). Operate the solenoid several times to release the hydraulic pressure. Unscrew the valve plug and, with the aid of a small magnet, remove the spring, plunger and valve. Taking great care to avoid damage to the valve seat, remove the operating valve, by inserting a length of stiff wire down its centre and drawing it up. Ensure that the small hole at the bottom of the valve, breaking through to the central drilling, is not choked. This hole provides a passage for oil exhausted from the operating cylinders when the valve is moved to the "direct drive" position.

If necessary the ball can be re-seated as follows:

Place the ball on a block of wood, position the seat of the valve on the ball and give the valve a sharp gentle tap. Clean the valve seat in the casing, locate the ball on its seat and gently tap the ball using a copper drift. Tapping the ball too hard will close the mouth of the valve seat and prevent valve re-assembly.

## Adjustment of Solenoid Operating Lever

The operating valve, referred to above, is raised by a cam pinned on a transverse shaft. A solenoid-operated lever is attached to the opposite end of the shaft (Fig. 6).

Remove the cover plate from the solenoid housing, move the operating lever until a  $\frac{1}{16}$ " (4.762 mm.) setting pin, pushed through the hole in the lever aligns with a hole in the casing. With the solenoid energised, screw the adjusting nut until it just contacts the operating lever. Remove the setting pin and de-energise the solenoid. Energise the solenoid and re-check the alignment of the holes.

Check that the current consumption is approximately 2 amps. A reading of 20 amps. indicates that the solenoid plunger is not moving far enough to switch from the solenoid operating coil to the holding coil of the solenoid and the operating lever must be re-adjusted.

**CONTINUOUS HIGH CURRENT WILL CAUSE PREMATURE SOLENOID FAILURE.**

With the solenoid de-energised, re-align the setting holes and insert the setting pin. Hold the solenoid plunger against the blanking plug (Fig. 7) and check that dimension "A" is .150" to .155" (3.81 to 3.937 mm.). Obtain this dimension by varying the thickness of the washer between the blanking plug and the casing, as necessary.

If an adjustable type of solenoid stop is fitted, proceed as follows:—

With the solenoid de-energised, re-align the setting holes and insert the setting pin. Hold the solenoid plunger against the adjustable stop, then adjust the stop until, with the plunger hard up





Fig. 5. Operating valve components



- |                   |                    |
|-------------------|--------------------|
| 1 Operating lever | 3 Adjusting nut    |
| 2 Setting pin     | 4 Solenoid plunger |

Fig. 6. Adjustment of operating lever




Fig. 7. Dimensional checks




Fig. 8. Testing oil pressure




Fig. 9. Relief valve components

against the stop there is a gap of  $.150^{\circ}$  to  $.155^{\circ}$  ( $3.81$  to  $3.937$  mm.) between the fork of the lever and the nut. When this gap has been obtained, tighten the locknut against the solenoid bracket until one of the slots in the locknut is in alignment with the drilled hole in the stop then secure with locking wire.

#### Testing Oil Pressure

Release the hydraulic pressure by switching on the ignition, engaging top gear and operating the overdrive switch several times, remove the operating valve plug and replace it with the hydraulic test equipment (Churchill Tool L.188).

Jack up the rear wheels of the car securely, start the engine and run up to about 20 m.p.h. on the speedometer. Check the hydraulic pressure in overdrive. See page 2-301.

Lack of pressure when overdrive is selected may indicate that the pump non-return valve requires cleaning and re-seating and/or the relief valve and filter cleaning.

#### Relief Valve

Access to the relief valve is gained by removing the plug at the bottom of the front casing adjacent to the solenoid housing cover plate. Remove the spring. The relief valve body can be withdrawn by inserting a length of stiff wire, shaped into a hook form, into the hole in the side of the body and pulling out.

The relief valve plunger can then be pushed out of the relief valve body.

#### Pump — Functional Check

To check that the pump is working, jack up the rear wheels of the car securely, remove the operating valve plug and start the engine. Engage top gear and with the engine running slowly, watch for oil being pumped into the valve chamber. If none appears the pump is not functioning and its non-return valve should be cleaned and re-seated. To re-seat **FIRST REMOVE** the valve body using Tool No. L.213, then, after cleaning, tap the ball sharply onto its seat. A flow of oil does not necessarily indicate that the hydraulic pressure is correct.

#### Sticking Clutch

If overdrive cannot be disengaged after carrying out the procedure outlined on page 2-305, the fault may result from a sticking cone clutch. This condition is more likely to occur on a new unit, due to insufficient "bedding in" of the clutch, than on a unit which has been in service for some time.

The clutch can usually be freed by giving the brake ring several sharp blows with a hide mallet from underneath when the car is on a hoist.

**The Electrical Circuit**

Because many operational failures are due to corroded terminals and faulty wiring, check the wiring and connections before dismantling any part of the overdrive unit.

Good earth connections are essential on all earthed components. This applies particularly to the solenoid because of the heavy current passed momentarily each time the overdrive is engaged.


Incorrect adjustment of the solenoid, resulting in failure of the main winding contact to open, may cause damage to the solenoid and relay.

If the overdrive fails to operate after checking all the electrical connections, refer to Fig. 10, and proceed as follows:

1. Switch on the ignition and engage top gear. Set the column control switch (1) to overdrive position. Check that the battery voltage is present at terminals C.1 and W.2.
2. Short out the terminals on C.1 and C.2 on the relay unit (3). If the solenoid (4) operates then the relay unit, column switch and gearbox isolator switch are suspect. Remove short circuiting link from between terminals C.1 and C.2.
3. Earth terminal W.1 on the relay unit. If the overdrive solenoid operates, then the gearbox isolator switch is suspect. If the relay unit does not operate, renew the relay unit.
4. Earth the yellow/green cable on the switch. If the solenoid operates, renew the control switch.

**OVERDRIVE REMOVAL**

Remove the eight nuts securing the unit to the gearbox adaptor plate. Break the connector adjacent to the solenoid valve and withdraw the units.



- |                               |                           |
|-------------------------------|---------------------------|
| 1 To SW on coil               | 4 Solenoid                |
| 2 Overdrive switch            | 5 Relay                   |
| 3 To No. 1 on ignition switch | 6 Gearbox isolator switch |

Fig. 10. Overdrive circuit




Fig. 11. Location of relay




Fig. 12. Location of (1) overdrive switch, (2) gearbox isolator switch

**EXPLODED ARRANGEMENT OF OVERDRIVE UNIT**





**DISMANTLING (Fig. 13)**

To prevent damage or faulty operation resulting from the inclusion of foreign matter, scrupulous cleanliness must be observed during all service operations. Prepare a clean area in which to lay out the dismantled unit and clean containers to receive the smaller parts.

With the front casing uppermost, secure the unit in suitably protected vice jaws. Release the tab washers securing the four bridge piece retaining nuts, remove the nuts, washers, bridge pieces (27) and, from the operating piston bores, remove the bias springs (28).

Loosen the two solenoid securing screws to prevent the rubber solenoid cover fouling during front casing removal.

Progressively loosen, to ensure gradual release of the clutch spring loading, the eight nuts securing the front casing (21) and brake ring (51) to the rear casing (56). Remove the nuts, spring washers and lift off the front casing. If the brake ring remains with the rear casing, tap gently to remove.

Remove the four clutch return springs (29) and withdraw the clutch sliding member complete with thrust bearing (11), thrust ring (10), retaining plate (12) and sun gear (9).

**Operating Valve and Relief Valve**

Remove as detailed on pages 2-305 and 2-306 respectively.

**Pump**

**IMPORTANT:** Remove the pump locating screw (33) before extracting the pump body.

Remove the pump plug (42), non-return valve spring (40) and ball (39), and the pump locating screw (33), see note above. Unscrew the non-return valve body (38) using tool L.213. Using tools L.183A, L.183A2 and adaptor L.205, extract the pump body as follows (Fig. 14):—

Screw the spindle into the pump body, position the adaptor against the casing and screw the wing nut down.

**Filter**

Remove the cover plate (23), retained by four setscrews and withdraw the filter (24), three magnetic rings (25), and the rubber/steel bonded sealing washer (26).

**Operating Pistons**

Withdraw the operating pistons (30) from their respective housings using tool L.252.

**Sliding Clutch Member**

Remove the sun gear retaining circlip (14) from its groove in the sun gear extension and withdraw the sun gear (9).

Remove the thrust bearing retaining plate (12), bearing circlip (13) from its groove on the cone clutch hub and press the hub from the bearing (11) and thrust ring (10). Extract the bearing from the thrust ring using tool L.210A.




Fig. 14.  
Extracting  
pump body

D939




Fig. 15.  
Clutch sliding  
member  
assembly

0478

0758




Fig. 16.  
View of unit  
from right-hand  
side showing  
solenoid cover  
removed




Fig. 17.  
Planet carrier  
assembly and  
oil pick-up ring




Fig. 18.  
Removal of  
coupling  
flange nut




Fig. 19.  
Removing  
needle bearing  
from annulus

### Solenoid

Remove the cover plate (54), retained by four setscrews, blanking plug (32), and unscrew the adjusting nut. Unscrew the two solenoid retaining screws and remove the solenoid (52) and plunger (50).

### Planet Carrier Assembly

Inspect the gear teeth for damage and wear and check for excessive movement indicating needle bearing or retaining pin wear.

If necessary, renew the complete carrier assembly (64).

### Annulus, Removal from Rear Casing

Remove the speedometer bush locating screw (61) and, to avoid damage to threads, use tool L.214 to extract speedometer drive bush (58) and pinion (57) from the rear casing.

Remove the split pin (1) and nut (2) securing the coupling flange (4) and press the annulus forward out of the rear case (56). The rear bearing (76) and oil seal (77) will remain in situ while the front bearing (72), speedometer drive gear (73), distance piece (74) and spacer washer (75) will be withdrawn with the annulus.

Remove circlip (67) and brass oil thrower ring (68) and withdraw the uni-directional clutch from the annulus.

The needle bearing (5) in the centre of the annulus may be withdrawn using tool L.208 as follows:—

Withdraw the central bolt from the tool and locate the outer part of the tool inside the bearing, ensuring the four tangs register behind it. Insert the central bolt and screw against the annulus.

Tap out the oil seal and rear bearing from the rear casing.

**RE-ASSEMBLY (Fig. 13)**

Renew gaskets, "O" rings, seals and tab washers, as necessary, during re-assembly operations.

**Operating Valve**

Locate the operating valve (19) within its orifice in the front casing and check that its hemispherical end abuts the flat of the operating cam (48). Position the steel ball (18), plunger (17) and spring (16) and secure with blanking plug (15).

**Relief Valve**

Insert the relief valve plunger (46) in the relief valve body and locate the assembly within its orifice at the base of the front casing. Insert the spring (45), locating it on the boss of the plunger, and secure with the relief valve blanking plug (43).

**Pump**

Assemble the pump plunger (35), spring (36) and body (37) and locate the assembly within its orifice in the front casing, locating the flat of the plunger roller fork against the thrust button situated below the centre bush. Press the pump body home, using tool L.206A, until the annular groove in the pump body is in alignment with the locating screw orifice. Insert the dowelled locating screw and tighten, ensuring that the dowel locates in the groove.

Screw in the non-return valve body (38), using tool L.213, position the ball (39) and spring (40) in the body and fit the retaining plug, ensuring that the spring locates correctly in the plug recess.

**Filter**

Position the three magnetic rings (25) in the mouth of the filter (24) and the bonded steel/rubber sealing ring (26) in the filter housing with its steel face against the casing.

Locate the filter in its housing, open end against the rubber surface of the bonded washer, fit the cover plate (23) and secure with the four retaining setscrews. Fit the drain plug (34).

**Operating Pistons**

Replace the pistons with the open end of the piston bore facing forward, carefully easing the sealing rings into the cylinder bores.

Fig. 20.  
View of front casing showing pump installed





Fig. 21.  
Annulus prior to fitting to rear casing



Fig. 22.  
Fitting rollers to uni-directional clutch






Fig. 23. Fitting uni-directional clutch to annulus




Fig. 24.  
Uni-directional  
clutch in position




Fig. 25.  
Planer gear  
alignment

#### Annulus and Rear Casing

Locate the front bearing (72) over the annulus tail shaft and press into position against the locating shoulder at the rear of the annulus.

Position the speedometer drive gear (73), distance piece (74), and, if fitted, the spacing washer (75) on the tail shaft. Fit the assembly to the rear casing.

**NOTE:** Where new parts have been fitted, make a dimensional check between the distance piece and abutment shoulder for the rear bearing. Fit spacing washers, as required, to give a .005" to .010" (.127 to .254 mm.) end float between the rear bearing and the casing.

Press the rear bearing (76) on the tail shaft and into the rear casing simultaneously. Fit the oil seal (77) using tool L.212.

Press the rear coupling flange (4) on the tail shaft, locate the washer (3) and secure with nut (2) and split pin (1).

Insert the speedometer drive pinion (57) and bush (58) turning the annulus as necessary to engage the gear. Align the bush and casing holes and fit the dowelled locating screw (61).

Insert the needle bearing (5) in the centre of the annulus using Tool L.209.

Fit the spring (66) in the roller cage (69) of the uni-directional clutch, engaging one end in the cage. Insert the inner member (70), engaging the opposite end of the spring, and ensure that the slots of the inner member engage the tongues of the cage.

Place the assembly, front face down, in the assembly tool L.178 (Fig. 22) and fit the rollers. Check that the spring rotates the cage to drive the rollers up the inclined faces of the inner member.

Refit the thrust washer (71) and uni-directional clutch (Fig. 23) transferring the clutch direct from the assembly tool. Fit the brass oil thrower ring (68) and secure with circlip (67).

#### Planet Gears

Rotate the gears until the ETCHED lines on the gear and carrier coincide (Fig. 25). **NOTE:** On one of the three gears the etched line occurs on the same tooth as the centre pop mark. Insert the sun gear and recheck the etched lines for alignment. Position the assembly within the annulus and remove the sun gear.

#### Clutch Sliding Member

Press the thrust bearing (11) into the thrust ring and fit the four bolts ensuring the heads are correctly positioned. Press the assembly on the cone clutch hub and secure with circlip (13). Fit the retaining plate (12).

Insert the sun gear (9) in the splined bore of the cone clutch and secure with circlip (14). Locate the assembly within the annulus and fit the four clutch return springs (29).

#### Front Case to Rear Case

Position the brake ring, both faces coated with suitable jointing compound, on the rear face of the front case, ensuring the kidney-shaped slot in the brake ring is located at the bottom (Fig. 26).

Fit the front casing to the rear casing. Clutch spring pressure will now be felt and it will be necessary to exert a slight pressure to bring the two casings together sufficiently to start the nuts. Tighten diametrically opposed nuts until the two faces meet.

Locate the bias springs (28) within the piston bores, fit the bridge pieces (27) and secure with nuts and tab washers.

Position the solenoid plunger (50) in the fork of the operating lever (49) and screw on the adjusting nut, replace the solenoid and secure with the two screws. Adjust as detailed on page 2-305 and, on completion, refit cover plate (54) and blanking plug (32).

#### Refitting Overdrive to Gearbox

Align the splines of the planet carrier and uni-directional clutch using a long screwdriver. Check the alignment by inserting dummy mainshaft (Tool No. L.201) (Fig. 27).

ROTATE THE GEARBOX MAINSHAFT AND POSITION THE PUMP OPERATING CAM WITH ITS HIGHEST POINT UPPERMOST. Engage first gear to retain this position. Check that the spring clip (7) is correctly located in its groove on the mainshaft and does not protrude above the splines.

NOTE : It is essential that rotation of gearbox mainshaft and overdrive coupling flange is avoided until the unit is fitted to the gearbox.

Remove the dummy mainshaft and fit the unit to the gearbox, secure with spring washers and nuts. Reconnect the solenoid cable.




Fig. 26. Offering front case to rear case




Fig. 27.  
Alignment  
check using  
Tool No. L.201




Fig. 28.  
Overdrive  
support bracket  
(1) and flexible  
mounting (2)





Fig. 29. Overdrive mounting platform



X — Grease as specified below

Fig. 1. Strap drive propeller shaft

VEHICLE AND STANDARD-TRIUMPH PART NUMBER	OVERALL LENGTH CLOSED— DIMENSION (1)		EXTENSION— DIMENSION (2)	
	ins.	cms.	ins.	cms.
<b>Herald 1200 and 12/50 206275</b> 207410 (BRD) .. .. . 208033 (Hardy Spicer) .. .. . 212549 (BRD Strap drive) .. .. .	50-250 50-130	127-64 127-33	Zero	
<b>Vitesse 208942</b> .. .. . (BRD Ordinary sliding spline) .. .. .	47-110 46-990	119-66 119-35	1-68 1-58	4-27 4-02
<b>Vitesse with overdrive 208338</b> .. .. . (BRD ordinary sliding spline) .. .. .	43-650 43-530	110-87 110-57	1-68 1-58	4-27 4-02
<b>Spitfire 210508</b> (Frictionless BRD) .. .. .	41-375	105-09	0-50	1-27
<b>Spitfire with overdrive 210985</b> (Frictionless BRD) .. .. .	38-00	96-52	0-50	1-27

For lubricating the rollers in the bearing cups (3), Fig. 8, use Shell Dentax 250 or Retinax A, or equivalent. Lubricate at "X", Fig. 1, with this grease, when assembling.

For lubricating splines, sliding and frictionless, use Duckham's grease Grade No. Q5648 or Rocol Molytone 320, or equivalent.




Fig. 2. Frictionless shaft sectioned




Fig. 3. Telescopic section exploded




Fig. 4. Arrangement of rollers

## Key to Fig. 3

- |             |                |
|-------------|----------------|
| 1 Rollers   | 5 Stop washer  |
| 2 Dust cap  | 6 Sliding yoke |
| 3 Washer    | 7 Shaft        |
| 4 Felt ring | 8 Restrainers  |

## FRICTIONLESS PROPELLER SHAFT

## Dismantling

Unscrew the dust cap (2), carefully slide off the yoke (6), collect forty rollers (1) and remove the restrainers (8). Remove the split stop washer (5), felt sealing ring (4), washer (3) and dust cap (2).

## Assembling

Fit the dust cap (2) and the washer (3). Before fitting the new felt sealing ring (4), soak it in clean engine oil. Fit the split washer (5), and use pliers to make it flat again.

Fill the four grooves along the shaft (7) with the grease specified on page 2-401. Fit the roller end-travel restrainers (8), and through their slots stack ten rollers into each groove as shown in Fig. 4.

Align the arrows on the shaft (7) and the yoke (6) so that the front and rear yokes are in the same plane. Very carefully slide on the yoke (6), ensuring that all rollers remain correctly positioned within the restrainer slots. Screw the dust cap (2) securely on to the yoke (6).

See page 2-403 for universal joint servicing.



### PROPELLER SHAFT

Herald 1200 and 1250 models are fitted with propeller shafts having a needle bearing universal joint at each end and the telescopic section, whilst propeller shafts fitted to Vitesse and Spitfire models incorporate a telescopic section at the front end.

#### To Remove

Raise the vehicle on stands or a ramp.

Remove the carpet and gearbox cover as described on page 2-205.

Remove the bolts and nyloc nuts securing the propeller shaft flanges to the gearbox and rear axle unit.

Detach the propeller shaft.

On Herald and Spitfire models, it may be necessary to lever the engine/gearbox unit forward to disengage the propeller shaft from the gearbox and axle driving flanges.

#### To Refit

Reverse the removal procedure, using new nyloc nuts if the original nuts can be screwed on to the bolts with finger pressure.

#### To Dismantle

##### Universal Joints (Fig. 8)

Individual parts of the needle roller bearing assemblies should not be renewed. If necessary, fit a new set of bearing parts, comprising:—

Spider, oil seals, retainers, needle bearing assemblies and retaining rings.

Remove the circlips (2). If the circlips cannot readily be removed from the yokes, remove paint from the holes and tap the end of the bearing cup, thus relieving pressure on the circlip.

Support the forked end of the shaft as shown (Fig. 6) and by striking the flange with a soft mallet, drive out the needle bearing cup until it is sufficiently exposed to be removed with a pair of grips. Reverse the shaft and extract the opposite cup in a similar manner. Remove the seals (4, Fig. 8).

Support the two exposed trunnions of the spider on wooden blocks (Fig. 7) and, by striking the radiused portion of the forked end of the shaft, drive out the needle bearing cup until it is sufficiently exposed to be removed. Repeat the operations to remove the remaining cup. Remove the spider from the forked end of the shaft.

Dismantle the universal joint at the opposite end in a similar manner.



Fig. 5. Removing a circlip




Fig. 6. Removing a bearing cup from the flange




Fig. 7. Removing a bearing cup from the shaft




Fig. 8. Universal coupling details




Fig. 9. Fitting spider journal seal retainer

**To Re-assemble**

Apply jointing compound to the journal shoulders on the new spider. Fit the oil seal retainers over the trunnions using a tubular drift (Fig. 9).

Smear the spider journals and the seal retainers with the grease recommended on page 2-401. Coat the inside of the races with this grease to retain the needle rollers, then one-third fill with grease.

Fit the oil seals.

Insert the spider into the flange yoke, ensuring that the lubricator boss is fitted away from the yoke. Using a soft-nosed drift, about  $\frac{1}{2}$  in. (.8 mm.) smaller in diameter than the hole in the yoke, tap the bearing into position. It is essential that the bearing races are a light drive fit in the yoke trunnions.

Repeat this operation with the remaining bearings and retain them with the circlips (2).

Re-assemble the opposite end universal joint by repeating the above procedure.